


Parts Catalog

Mazda RX-7
U.S.A.
('95)



FD333 - 400001~500000

Feb. '97 (FINAL)


Catalog No. AU-FA06-04

MAZDA

© 1997 Mazda Motor Corporation

LAYOUT OF CONTENTS / DISPOSITION TYPOGRAPHIQUE DE CONTENU / DISPOSICION DEL CONTENIDO / ANORDNUNG DES INHALTS



















- The following is a typical example of the layout of contents on Mazda microfiche parts catalog.
- Voici un exemple typique de la disposition typographique de contenu dans les microfiches de catalogue des pièces de Mazda.
- El siguiente es un ejemplo típico de la disposición del contenido en una microficha del catálogo de repuestos de Mazda.
- Folgendes ist ein typisches Beispiel der Inhaltsanordnung des Mazda-Mikrofiche-Teilekatalogs.

















Remark : The items listed under ④ have been deleted from each fiche since Dec. '93

- | | | |
|--|---|---|
| ① • Layout of contents
• Disposition Typographique de Contenu
• Disposición del contenido
• Anordnung des Inhalts | ② • Pictorial Index
• Index par Schémas
• Índice Gráfico
• Illustrierter Index | ③ • Master Section No. Index
• Index des Numéros des Sections Totale
• Índice del Número de la Sección Maestra
• Hauptabschnittsnummer-Index |
| ④ • Section No. Index for the Column
• Index des Numéros des Sections pour les Colonnes
• N° de la Sección para el Índice
• Abschnittsnummer-Index für die Spalte | ⑤ • Illustration & Text
• Illustrations et Textes
• Ilustración y Texto
• Abbildung und Text | ⑥ • Part No. Index
• Index des Numéros des Pièces
• Índice del N° de Pieza
• Teile-Nr.-Index |
| ⑦ • Alphabetical Index
• Index Alphabétique
• Índice Alfabetico
• Alphabetischer Index | ⑧ • Model Identification
• Identification des Modèles
• Identificación del Modelo
• Modell-Kennzeichnung | ⑨ • Vehicle Identification System
• Système d'Identification de Véhicule
• Sistema de Identificación de Vehículo
• Fahrzeug-Identifikations-system |
















PICTORIAL INDEX

1000  ENGINE & GASKET SETS	1 1030  ROTOR HOUSINGS	2 1040  OIL PAN, FRONT & REAR HOUSING	3 1100  EGCENTRIC SHAFT & FLYWHEEL	4 1110  ROTORS & RELATED PARTS	5 1400  OIL PUMP & FILTER	
ENGINE (1/2)  As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.						6 1600  CLUTCH DISC & COVER (MANUAL)
17 4600 Given in Chassis Group  CHANGE CONTROL SYSTEM (AT)					7 1700  TRANSMISSION CASE (MANUAL)	
16 3900 Given in Chassis Group  ENGINE & T/MISSION MOUNTINGS					8 1710  TRANSMISSION GEARS (MANUAL)	
				9 1720  CHANGE CONTROL SYSTEM (MANUAL)		
15 1960  GASKET & SEAL KIT (AUTOMATIC)	14 1950  MANUAL LINKAGE SYSTEM (AUTOMATIC)	13 1940  GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)	12 1930  CLUTCHES & PLANFARY GEARS (AUTOMATIC)	11 1920 & 1925  TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)	10 1910  TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)	

PICTORIAL INDEX














1 1300  INLET MANIFOLD	2 1310  EXHAUST MANIFOLD	3 1311  INTER COOLER	4 1312  TURBO CHARGER	5 1320  FUEL SYSTEM	6 1325  FUEL DISTRIBUTOR
18 1850  BATTERY 17 1840  STARTER 16 1830  ALTERNATOR 15 1800  ENGINE ELECTRICAL SYSTEM 14 1580  BRACKET, PULLEY & BELT 13 1500  COOLING SYSTEM 12 11 1380  EMISSION CONTROL SYSTEM 10 1371  AIR PUMP & AIR CONTROL VALVE 9 1364  THROTTLE BODY 8 1313  TWIN TURBO AIR INTAKE SYSTEM 7 1330  AIR CLEANER ENGINE (2/2)  As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.					

PICTORIAL INDEX





















1 2505  REAR PROPELLER SHAFT	2 2550  REAR DRIVE SHAFT	3 2600  REAR AXLE	4 2610  REAR BRAKE MECHANISMS	5 2710  REAR DIFFERENTIALS	6 2800  REAR SUSPENSION MECHANISMS
20 4000  EXHAUST SYSTEM	21 4600  CHANGE CONTROL SYSTEM	22 1720 Given in Engine Group  CHANGE CONTROL SYSTEM (MANUAL TRANSMISSION)	CHASSIS (1/2) 		7
19 3900  ENGINE & T/MISSION MOUNTINGS				8 2810  REAR STABILIZER	
18 3410  CROSSMEMBER & STABILIZER				9 2830  REAR LOWER ARMS & SUB FRAME	
17				10 3200  STEERING WHEEL	
As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.					
16 3400  FRONT SUSPENSION MECHANISMS	15 3310  FRONT BRAKE MECHANISMS	14 3300  FRONT AXLE	13 3240  POWER STEERING SYSTEM (FRONT)	12 3220  STEERING GEAR	11 3210  STEERING COLUMN & SHAFTS

As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.























PICTORIAL INDEX

1 3700  TIRES & JACK	2 4140  CLUTCH RELEASE & MASTER CYLINDERS	3 4145  CLUTCH PIPINGS	4 4160  ACCELERATOR CONTROL SYSTEM	5 4200  FUEL TANK	6 4210  FUEL LID OPENER	
CHASSIS (2/2)  As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.						7 4300  CLUTCH & BRAKE PEDALS
						8 4340  BRAKE MASTER CYLINDER & POWER BRAKE
						9 4360  BRAKE PIPINGS
						10 4370  ANTILOCK BRAKE SYSTEM
				12 4500  FUEL PIPINGS	11 4400  PARKING BRAKE SYSTEM	

PICTORIAL INDEX

1 0900  KEY SETS	2 	3 5100  HEAD LAMPS	4 5103  HEAD LAMP RETRACTORS	5 5105  FRONT COMBINATION LAMPS	6 5110  REAR COMBINATION LAMPS
19 6704  WIRING HARNESS CLAMPS	20 6720  WINDSHIELD WASHER	21 6730  WINDSHIELD WIPERS	22 6750  WINDOW WIPER & WASHER (REAR)		7 5120  LICENSE LAMPS
18 6703  WIRING HARNESSSES (DOOR, FLOOR/CEILING)	BODY (1/4)  As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.				8 5125  INTERIOR LAMPS
17 6702  WIRING HARNESSSES (DASHBOARD)					9 5130  OVERHEAD CONSOLE
16 6700  WIRING HARNESSSES (FRONT & REAR)					10 6600  SWITCHES & RELAYS (ENGINE)
15 6701  WIRING HARNESSSES (ENGINE & T/MISSION)	14 6640  AUTO CRUISE CONTROL SYSTEM	13 6635  DOOR SWITCH & HORNS	12 6630  RELAYS & UNIT (BODY)	11 	












PICTORIAL INDEX

1 5000  FRONT BUMPER	2 5010  REAR BUMPER	3 5030  WINDOW MOULDINGS	4 5040  BODY MOULDINGS	5 5170  ORNAMENTS	6 5180  COWL & EXTRACTOR GRILLES
20 6300  WINDOW GLASSES	21 6330  SUNROOF	22 7800  SPOILERS & RELATED PARTS	BODY (2/4) 		7 5230  BONNET
19 6230  LIFT GATE MECHANISMS				8 5310  FRONT PANELS	
18 5840  FRONT DOOR TRIMS & RELATED PARTS				9 5320  FENDER & WHEEL APRON PANELS	
17 5830  FRONT DOOR MECHANISMS				10 5330  DASH & COWL PANELS	
16 5800  FRONT DOORS				11 5340  SIDE PANELS	
15 5390  FLOOR ATTACHMENTS	14 5380  FLOOR ATTACHMENTS (HOLE COVERS)	13 5370  FLOOR PANELS	12 5360  ROOF PANELS		

As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.














As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.

PICTORIAL INDEX

1 5500  DASHBOARD EQUIPMENTS	2 5520  METER HOOD	3 5540  METER COMPONENTS	4 5560  DASHBOARD & RELATED PARTS	5 5570  CONSOLE	6  6120  6100  6110  6115 HEATER
					7  6135  6130  6130  6140  6150 AIR CONDITIONER
			11 5795  AIR BAG	10 6615  POWER WINDOW SWITCHES	8 6610  DASHBOARD SWITCHES
					9 6611  COMBINATION SWITCH

As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.

PICTORIAL INDEX

1 5580  VENTILATOR	2 5700  FRONT SEATS	3	4 5790  SEAT BELTS	5 6680  AUDIO SYSTEMS (RADIO & TAPE DECK)	6 6682  AUDIO SYSTEMS (ANTENNA & SPEAKER)
	BODY (4/4) 				7
					8 6800  CEILING TRIMS
					9 6820  PILLAR TRIMS
17 7250  QUARTER WINDOW & TRIMS					10
16 6930  CAUTION PLATES & LABELS	15 6900  VISORS, ASSIST HANDLES & MIRRORS	14 6870  SERVICE TOOLS	13 6860  FLOOR MATS & PADS	12 6845  STORAGE BOX	11 6840  TRIMS & SCUFF PLATES

As this illustration is prepared to be applicable to all models, some parts are different in specifications from parts listed in this parts Catalog.

SECTION NAME INDEX (ENGINE)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	ENGINE & GASKET SETS	1-H11	1940	AUTOMATIC TRANSMISSION GOVERNO R, LOW & REVERSE PISTON			
1-D03	1030	ROTOR HOUSING	1-K11	1950	AUTOMATIC TRANSMISSION MANUAL LINKAGE SYSTEM			
1-G03	1040	OIL PAN, FRONT & REAR HOUSING	1-M11	1960	AUTOMATIC TRANSMISSION GASKET & SEAL KIT			
1-I03	1100	ECCENTRIC SHAFT & FLYWHEEL						
1-L03	1110	ROTORS & RELATED PARTS						
1-N03	1300	INLET MANIFOLD						
1-C04	1310	EXHAUST MANIFOLD						
1-D04	1311	INTER COOLER						
1-E04	1312	TURBO CHARGER						
1-G04	1313	TWIN TURBO AIR INTAKE SYSTEM						
1-I04	1320	FUEL SYSTEM						
1-K04	1325	FUEL DISTRIBUTOR						
1-M04	1330	AIR CLEANER						
1-D05	1364	THROTTLE BODY						
1-F05	1371	AIR PUMP & AIR CONTROL VALVE						
1-H05	1380	EMISSION CONTROL SYSTEM						
1-D06	1400	OIL PUMP & FILTER						
1-G06	1500	COOLING SYSTEM						
1-N06	1580	BRACKET, PULLEY & BELT						
1-C07	1600	CLUTCH DISC & COVER						
1-E07	1700	MANUAL TRANSMISSION CASE						
1-J07	1710	MANUAL TRANSMISSION GEARS						
1-D08	1720	MANUAL TRANSMISSION CHANGE CON TROL SYSTEM						
1-F08	1800	ENGINE ELECTRICAL SYSTEM						
1-I08	1830	ALTERNATOR						
1-K08	1840	STARTER (MT)						
1-M08	1840 A	STARTER (AT)						
1-C09	1850	BATTERY						
1-D09	1910	AUTOMATIC TRANSMISSION TORQUE CONVERTER, OIL PUMP & PIPINGS						
1-I09	1920	AUTOMATIC TRANSMISSION CASE & MAIN CONTROL SYSTEM						
1-C10	1925	AUTOMATIC TRANSMISSION CONTROL VALVE						
1-K10	1930	AUTOMATIC TRANSMISSION CLUTCHE S & PLANETARY GEARS						


SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C03	2505	REAR PROPELLER SHAFT						
2-D03	2550	REAR DRIVE SHAFT						
2-E03	2600	REAR AXLE						
2-G03	2610	REAR BRAKE MECHANISMS						
2-J03	2710	REAR DIFFERENTIALS						
2-N03	2800	REAR SUSPENSION MECHANISMS						
2-C04	2810	REAR STABILIZER						
2-D04	2830	REAR LOWER ARMS & SUB FRAME						
2-G04	3200	STEERING WHEEL						
2-H04	3210	STEERING COLUMN & SHAFTS						
2-I04	3220	STEERING GEAR						
2-K04	3240	POWER STEERING SYSTEM						
2-M04	3300	FRONT AXLE						
2-N04	3310	FRONT BRAKE MECHANISMS						
2-C05	3400	FRONT SUSPENSION MECHANISMS						
2-F05	3410	CROSSMEMBER & STABILIZER						
2-G05	3700	TIRES & JACK						
2-C06	3900	ENGINE & T/MISSION MOUNTINGS						
2-D06	4000	EXHAUST SYSTEM						
2-G06	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
2-I06	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
2-J06	4160	ACCELERATOR CONTROL SYSTEM						
2-K06	4200	FUEL TANK						
2-C07	4210	FUEL LID OPENER						
2-D07	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
2-F07	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
2-G07	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
2-I07	4360	BRAKE PIPINGS						
2-L07	4370	ANTILOCK BRAKE SYSTEM						
2-N07	4400	PARKING BRAKE SYSTEM						
2-C08	4500	FUEL PIPINGS						
2-F08	4600	CHANGE CONTROL SYSTEM (AT)						


SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C10	0900	KEY SETS	2-L16	5840	FRONT DOOR TRIMS & RELATED PARTS	3-K07	6704	WIRING HARNESS CLAMPS
2-E10	5000	FRONT BUMPER	3-C03	6100	HEATER	3-L07	6720	WINDSHIELD WASHER
2-H10	5010	REAR BUMPER	3-D03	6110	HEATER UNIT COMPONENTS	3-N07	6730	WINDSHIELD WIPERS
2-J10	5030	WINDOW MOULDINGS	3-E03	6115	HEATER CONTROLS COMPONENTS	3-D08	6740	WIPER MOTOR COMPONENTS (FRONT)
2-K10	5040	BODY MOULDINGS	3-F03	6120	HEATER BLOWER COMPONENTS	3-E08	6750	WINDOW WIPER & WASHER (REAR)
2-L10	5100	HEAD LAMPS	3-G03	6130	AIR CONDITIONER (DENSO MAKE)	3-H08	6760	WINDOW WIPER MOTOR COMPONENTS (REAR)
2-N10	5103	HEAD LAMP RETRACTORS	3-J03	6130A	AIR CONDITIONER (MANA MAKE)	3-I08	6800	CEILING TRIMS
2-D11	5105	FRONT COMBINATION LAMPS	3-M03	6135	AIR CONDITIONING COOLING PIPE 'O' RING	3-J08	6820	PILLAR TRIMS
2-I11	5110	REAR COMBINATION LAMPS	3-C04	6140	AIR CONDITIONING COMPRESSOR COMPONENTS (DENSO MAKE)	3-K08	6840	TRIMS & SCUFF PLATES
2-N11	5120	LICENSE LAMPS	3-E04	6140A	AIR CONDITIONING COMPRESSOR COMPONENTS (MANA MAKE)	3-N08	6845	STRAGE BOX
2-C12	5125	INTERIOR LAMPS	3-G04	6150	AIR CONDITIONING COOLING UNIT (DENSO MAKE)	3-C09	6860	FLOOR MATS & PADS
2-D12	5130	OVERHEAD CONSOLE	3-H04	6150A	AIR CONDITIONING COOLING UNIT (MANA MAKE)	3-F09	6870	SERVICE TOOLS
2-E12	5170	ORNAMENTS	3-J04	6230	LIFT GATE MECHANISMS	3-G09	6900	SUNVISORS, ASSIST HANDLES & MIRRORS
2-F12	5180	COWL & EXTRACTOR GRILLES	3-M04	6300	WINDOW GLASSES	3-J09	6930	CAUTION PLATES & LABELS
2-H12	5230	BONNET	3-N04	6330	SUNROOF	3-L09	7250	QUARTER WINDOW & TRIMS
2-J12	5310	FRONT PANELS	3-G05	6600	ENGINE SWITCHES & RELAYS	3-N09	7800	SPOILERS & RELATED PARTS
2-K12	5320	FENDER & WHEEL APRON PANELS	3-L05	6610	DASHBOARD SWITCHES			
2-N12	5330	DASH & COWL PANELS	3-M05	6611	COMBINATION SWITCH			
2-C13	5340	SIDE PANELS	3-N05	6615	POWER WINDOW SWITCHES			
2-G13	5360	ROOF PANELS	3-C06	6630	BODY RELAYS & UNIT			
2-H13	5370	FLOOR PANELS	3-E06	6635	DOOR SWITCH & HORNS			
2-J13	5380	FLOOR ATTACHMENTS (HOLE COVERS)	3-F06	6640	AUTO CRUISE CONTROL SYSTEM			
2-L13	5390	FLOOR ATTACHMENTS	3-G06	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-C14	5500	DASHBOARD EQUIPMENTS	3-J06	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-D14	5520	METER HOOD	3-N06	6700	FRONT & REAR WIRING HARNESSES			
2-E14	5540	METER COMPONENTS	3-F07	6701	ENGINE & TRANSMISSION WIRING HARNESSES			
2-G14	5560	DASHBOARD & RELATED PARTS	3-H07	6702	DASHBOARD WIRING HARNESSES			
2-K14	5570	CONSOLE	3-J07	6703	DOOR, FLOOR & CEILING WIRING HARNESSES			
2-N14	5580	VENTILATOR						
2-C15	5700	FRONT SEATS						
2-D16	5790	SEAT BELTS						
2-E16	5795	AIR BAG						
2-F16	5800	FRONT DOORS						
2-I16	5830	FRONT DOOR MECHANISMS						






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-A51		CLIP, HEATER UNIT			
FD01-61-A18	2				
61-A70		ACTUATOR, MODE-HEATER UNIT			
FD01-61-A70	1				
61-130		HEATER UNIT			
FD01-61-130B	1				
61-415		ACTUATOR, TEMP			
FD01-61-A60	1				
76-401		CASE, HEATER			
FD01-61-A80	1				
76-403F		RING, 'O'			
FD01-61-A19	2				
76-405		CORE, HEATER			
FD01-61-A10	1				
76-406D		PIPE, HEATER UNIT			
FD01-61-A15A	1				
76-409B		PIPE, HEATER UNIT			
FD01-61-A16A	1				
76-510C		LINK SET, TEMP			
FD01-61-A20	1				
76-550		LINK SET, MODE			
FD01-61-A30	1				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-220		PANEL,CENTER			
FD15-55-21X	1				
61-C50		SWITCH,FAN-HEATER CO NTROL			
FD01-61-C50	1				
61-C95		BULB,MODE CONTROL			
FD01-61-C95	4	(ILLUST. NO.1)			
FD02-61-C95	2	(ILLUST. NO.2)			
FD03-61-C95	1	(ILLUST. NO.3)			
61-190		CONTROL,HEATER			
FD15-61-19ZA	1				
00	INT-	FE5 FE6 FE7 BLACK			
61-191A		KNOB NO.1			
FD01-61-191	2				
61-195B		KNOB,FAN SWITCH			
FD01-61-195	1				
66-170D		SWITCH,HAZARD			
FD01-66-4H0	1				
66-260		RESISTOR			
FD01-55-190A	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-B10		MOTOR,FAN-BLOWER UNIT			
FD01-61-B10	1				
61-B15		RESISTOR,BLOWER UNIT			
D061-61-B15	1				
61-B16		HARNESS,BLOWER UNIT			
FD01-61-B16A	1				
61-B20		LINK,RECYCLE & FRESH			
FD01-61-B20	1				
61-B60		ACTUATOR,RECYCLE & FRESH			
FD01-61-B60	1				
61-140		BLOWER UNIT			
FD01-61-140B	1				
61-690		RELAY			
FB03-61-691	1	W/IG.RELAY BLOWER			
76-451C		CASE(R),BLOWER			
FD01-61-B01	1				
76-452C		CASE(L),BLOWER			
FD01-61-B02	1				



AUFA06




(PIPE & CONDENSER)



6130 -1 AIR CONDITIONER
(DENSO MAKE)


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-786B		CLIP, HOSE			
N3A3-13-786	1				
56-181D		CLIP			
S083-56-181	1				
61-280A		HOSE, DRAIN			
FD15-61-280	1				
61-461		HOSE, FLEXIBLE-HIGH			
FD15-61-461	1				
61-462		HOSE, FLEXIBLE-LOW			
FD15-61-462	1				
61-463		PIPE NO.1, COOLER			
FD15-61-464	1				
61-464		PIPE NO.2, COOLER			
FD15-61-465A	1				
61-465		PIPE NO.3, COOLER			
FD15-61-466	1				
61-466		PIPE NO.4, COOLER			
FD15-61-467A	1				
61-467		PIPE NO.5, COOLER			
FD15-61-468	1				
61-473		CLIP, PIPE			
FD01-61-473	4				
61-479		GROMMET			
FB01-61-478A	1				
61-479B		CLIP			
FD04-61-479A	1	(ILLUST. NO.1)			
FD05-61-479	1	(ILLUST. NO.2)			

(CLIP & BRACKET)




6130 -2 * AIR CONDITIONER
(DENSO MAKE)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-480		CONDENSER			
F110-61-480	1				
61-481B		RUBBER, INSULATOR			
FD04-61-481	2				
61-483A		BRACKET, CONDENSER			
FD04-61-483A	1				
61-500		TANK, LIQUID			
FD15-61-500	1 (ILLUST. NO.1)				
N026-61-501	1 (ILLUST. NO.2)				
61-502		BRACKET, TANK			
FD04-61-502	1				
61-558		GROMMET, UNIT-COOLING			
LA01-61-558A	1				
61-731A		BOLT, AIR CON.			
FD05-61-731	4				
67-7403		RELAY, N.O.			
H270-67-740	1	30A			
78-834		REFRIGERANT DRUM			
W257-61-R13	1	200G			
W323-61-R13	1	300G			



AUFA06




AUF-A06

6130A -1 AIR CONDITIONER
(MANA MAKE)




997-01






Five part numbers of XXXX-61-J1X under the D-CODE 61-J1XB include 10 pieces of O ring each.




(DENSO MAKE)




6135 -1 * AIR CONDITIONING COOLING PIPE 'O' RING


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-J1X		RING, 'O'-NO.1			
W257-61-J17	2	(ILLUST. NO.1) (DENSO MAKE)			
W326-61-J17	6	(ILLUST. NO.2) (DENSO MAKE)			
W329-61-J17	3	(ILLUST. NO.3) (DENSO MAKE)			
61-J1XB		RING, 'O'-NO.3			
LB51-61-J1X	1	(A) (ILLUST. NO.1) (OPTION) (MANA MAKE)			
LB54-61-J1X	1	(A) (ILLUST. NO.2) (OPTION) (MANA MAKE)			
LB55-61-J1X	1	(A) (ILLUST. NO.3) (OPTION) (MANA MAKE)			
LB56-61-J1X	1	(A) (ILLUST. NO.4) (OPTION) (MANA MAKE)			
LB57-61-J1X	1	(A) (ILLUST. NO.5) (OPTION) (MANA MAKE)			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-K00		COMPRESSOR, AIR CON.			
FD15-61-K00	1				
61-K1X		VALVE, RELIEF			
FD15-61-K1X	1				
61-K10		SHAFT, CYL -COMPRESSOR			
FD15-61-K10	1				
61-K11		HEAD, CYL. -COMPRESSOR			
FD15-61-K11	1				
61-K12		HEAD, CYL. -COMPRESSOR			
FD15-61-K12	1				
61-K19		SEAL, SHAFT-COMPR.			
FD15-61-K19	1				
61-K20		GASKET KIT, COMPRESSOR			
FD15-61-K2X	1				
61-K23		PLUG, COMPRESSOR			
FD15-61-K23	1				
61-K24		GASKET, COMPRESSOR			
FD05-61-K24	1				
61-K25		BOLT, COMPRESSOR-AIR CON.			
F065-61-K25	5				
61-K31		BOLT, COMPRESSOR			
F065-61-K31	2				
61-K39		OIL, COMPRESSOR			
FD15-61-K39	1				
61-L10		CLUTCH, MAGNET			
FD15-61-L10	1				
61-L11		ARMATURE, MAGNETIC CLUTCH			
FD15-61-L11	1				



PART NO	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-L12		PULLEY,MAGNET CLUTCH			
FD15-61-L12	1				
61-L13		COIL,FIELD-MAGNET CLUTCH			
FD15-61-L13	1				
61-L14		BOLT,MAGNET CLUTCH			
F065-61-L14	1				
61-L16		RING,SNAP-MAGNET CLUTCH			
F065-61-L16	1				
61-450		COMPRESSOR			
FD15-61-450	1				
76-833B		WASHER			
B001-76-734	1				
76-877A		RING,SNAP			
B001-76-725	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-K00 FD31-61-K00	1	COMPRESSOR, AIR CON.			
61-K1X NA75-61-K1X	1	VALVE, RELIEF (A)			
61-K10 FD31-61-K10	1	SHAFT, CYL -COMPRESSOR			
61-K11 NA75-61-K11	1	HEAD, CYL. -COMPRESSOR (A)			
61-K12 NA75-61-K12	1	HEAD, CYL. -COMPRESSOR (A)			
61-K19 NA75-61-K19	1	SEAL, SHAFT-COMPR. (A)			
61-K20 NA75-61-K2X	1	GASKET KIT, COMPRESSOR (A)			
61-K23 NA75-61-K23	1	PLUG, COMPRESSOR (A)			
61-K24 NA02-61-K24	1	GASKET, COMPRESSOR (A)			
61-K25 F065-61-K25	5	BOLT, COMPRESSOR-AIR CON.			
61-K31 F065-61-K31	2	BOLT, COMPRESSOR			
61-K39 NA75-61-K39	1	OIL, COMPRESSOR (A)			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-L10		CLUTCH, MAGNET			
FD31-61-L10	1				
61-L11		ARMATURE, MAGNETIC CLUTCH (A)			
NA75-61-L11	1				
61-L12		PULLEY, MAGNET CLUTCH			
FD31-61-L12	1				
61-L13		COIL, FIELD-MAGNET CLUTCH (A)			
NA75-61-L13	1				
61-L14		BOLT, MAGNET CLUTCH			
F065-61-L14	1				
61-L16		RING, SNAP-MAGNET CLUTCH			
F065-61-L16	1				
61-450		COMPRESSOR (A)			
FD31-61-450	1				
76-833B		WASHER			
B001-76-734	1				
76-877A		RING, SNAP			
B001-76-725	1				

6150 AIR CONDITIONING COOLING UNIT
(DENSO MAKE)


6150 -1 * AIR CONDITIONING COOLING UNIT
(DENSO MAKE)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-J01		CASE 'A', COOLING UNIT			
FD15-61-J01	1				
61-J02		CASE 'B', COOLING UNIT			
FD15-61-J02	1				
61-J10		EVAPORATOR			
FD15-61-J10	1				
61-J14		VALVE, EXPANSION			
FD15-61-J14	1				
61-J15		PIPE, COOLING UNIT			
FD15-61-J15	1				
61-J18B		HARNESS, COOLING UNIT			
FD15-61-J43	1				
61-J20		THERMOSTAT, COOLING UNIT			
FD15-61-J20	1				
61-520		UNIT, COOLING			
FD15-61-520	1				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-J01 FD17-61-J01	1	CASE 'A', COOLING UNIT (A)			
61-J02 FD17-61-J02	1	CASE 'B', COOLING UNIT (A)			
61-J03 FD01-61-J03	1	CASE 'C', COOLING UNIT (A)			
61-J08 GJ51-61-J08	1	CLIP, COOLING UNIT (G)			
61-J09 G213-61-J09	2	CLIP, COOLING UNIT			
61-J1XB H261-61-J17	1	RING, 'O'-NO. 3			
61-J10 FD17-61-J10	1	EVAPORATOR (A)			
61-J14 FD31-61-J14	1	VALVE, EXPANSION (A)			
61-J15 FD17-61-J15	1	PIPE, COOLING UNIT (A)			
61-J20 FD01-61-J20	1	THERMOSTAT, COOLING U NIT			
61-J23 GJ51-61-J23	5	SCREW, COOLING UNIT (G)			
61-520 FD31-61-520	1	UNIT, COOLING			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
76-707E		INSULATOR			
HA14-76-707	2				
76-714F		CLIP			
H001-76-714	1				
76-717C		SCREW			
H001-76-717	1				



a	b	c	d	e	f	g
68-AD1	68-AD2	68-D21	68-172H	68-305B	68-865Q	68-865S

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
62-010		BODY, LIFT GATE			
FD01-62-020E A (FD01-62-020F)	1	((W/O SUN ROOF))>(NOR SUSP)			-5301
FD03-62-020E	1	((W/O SUN ROOF))>(HAR D SUSP)			-5301
FD04-62-020E A (FD04-62-020F)	1	(W/GLASS SUN ROOF)			-5301
FD01-62-020F	1	((W/O SUN ROOF))>(NOR SUSP)			5301-
FD03-62-020G	1	((W/O SUN ROOF))>(HAR D SUSP)			5301-
FD04-62-020F	1	(W/GLASS SUN ROOF)			5301-
62-210C		HINGE, GLASS HATCH			
FD01-62-210C	2				
62-212		GASKET, HINGE-LIFT GA TE			
B001-62-212	2				
62-310		LOCK, LIFT GATE			
FD01-62-310	1				
62-361		STRIKER, LOCK			
KA01-62-361	1				
62-605B		COVER, DAMPER STAY			
FB01-62-615	2				
62-610A		STAY(R), DAMPER			
8BF9-62-620	1	((W/O SUN ROOF))>(HAR D SUSP)			
8BF9-62-620	1	(W/GLASS SUN ROOF)			
8BF9-62-620	1	((W/O SUN ROOF))>(NOR SUSP)			
8BF9-62-620	1	(W/STEEL SUN ROOF)			
62-681		WEDGE, LIFTGATE			
FD01-62-681B	2				
62-761		WTHSTYP, LIFT GATE			
FD01-62-761	1				


5301 FD333 -400027



a	b	c	d	e	f	g
68-AD1	68-AD2	68-D21	68-172H	68-305B	68-865Q	68-865S

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
62-864		TAPE, PROTECTOR-STOPPER			
B467-62-864B	2				
63-610A		STAY(L), DAMPER			
8BF5-63-620	1	((W/O SUN ROOF))>(NOR D SUSP)			
8BF6-63-620	1	((W/O SUN ROOF))>(HARD SUSP)			
68-AD1		CLIP, SLIDE			
B499-68-AD1A	2				
*B499-68-AD1A	1				
68-AD2		CLIP			
B455-68-AD2	2				
68-D21		CLIP, TRIM			
LA10-68-D21	2				
68-172H		FASTENER, CTR. P/UPP.			
B100-68-215A	2				
68-305B		HANGER, STRAP			
FD01-68-301	2				
02	INT-	FE5 FE6 FE7 BLACK			
68-865Q		FASTENER			
GJ21-68-885B	8				
00	INT-	FE5 FE6 FE7 BLACK			
68-865S		CLIP, TRIM			
GJ12-68-865	17				
GJ12-68-865	18				
68-930		TRIM(R), LIFT GATE-SIDE			
FD01-68-940B	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-930Z		TRIM(L), LIFT GATE-SIDE			
5403 FD333 -40002B					

-5403
5403--5403
5403-





(a)	(b)	(c)	(d)	(e)	(f)	(g)
68-AD1	68-AD2	68-D21	68-172H	68-305B	68-865Q	68-865S

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
FD01-68-950B	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-950		TRIM, LIFTGATE-LOWER			
FD01-68-960C	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-962		TRIM, LIFTGATE-UPPER			
FD01-68-930A	1				
02	INT-	FE5 FE6 FE7 BLACK			


6300 WINDOW GLASSES

6300 -1 * WINDOW GLASSES




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-891A EA01-50-891A	2	SPACER, WINDOW WHITE			
63-901 FD31-63-900	1	GLASS, WINDSHIELD			
63-902 FD01-50-894	1	DAM, FRT. WSHLD GLASS L=3120MM (ILLUST. NO.1)			
63-902 8545-63-902	1	L=3850MM (ILLUST. NO.2)			
63-931 FD15-63-930	1	GLASS, BACK WINDOW			
63-959 FB01-63-959	3	TERMINAL, BACK WIND. GLASS			
69-240A BC1C-69-240	1	BASE, INTERIOR MIRROR			

(W/O SUN-RF)
(STEEL SUN-RF)




AUFA06

(GLASS SUN-RF)



AUFA06


(W/O SUN-RF)
(STEEL SUN-RF)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-971K		GROMMET			
0222-66-971	4	(W/O SUN ROOF)			
67-051M		CLIP			
B455-67-C31	2	(ILLUST. NO.1)			
GA2A-67-C33	1	(ILLUST. NO.2)			
67-054F		CLIP			
G030-67-052	2				
67-740P		RELAY, SLIDE ROOF			
EA05-69-873	1				
68-911		WELT, SEAMING			
FD01-69-981A	1				
02	INT-	FE5 FE6 FE7 BLACK			
69-810A		PANEL, SLIDING ROOF			
FD01-69-810B	1	(W/STEEL SUN ROOF)			
F114-69-810B	1	(W/GLASS SUN ROOF)			
69-832		RAIL(R), GUIDE			
FD01-69-851	1				
69-832Z		RAIL(L), GUIDE			
FD01-69-852	1				
69-840A		FRAME, SLIDING ROOF			
FD01-69-840	1				
69-842		GUIDE(R), REAR			
FD01-69-864	1				
69-842Z		GUIDE(L), REAR			
FD01-69-865	1				
69-844		UNIT, DRIVE			
FD01-69-861	1				
69-845B		TAPE, SEAL-SLDG ROOF FRAME			

3-D 5


(W/O SUN-RF)
(STEEL SUN-RF)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
69-882A		PLATE(L),GUIDE			
FD01-69-9H4	1				
69-891A		HOSE,DRAIN-SUN ROOF FRONT			
FD04-69-920	2	(ILLUST. NO.1)			
FD01-69-921	2	(ILLUST. NO.2)			
69-895		WEATHERSTRIP,S/ROOF			
FD01-69-825A	1	(W/STEEL SUN ROOF)			
F114-69-825	1	(W/GLASS SUN ROOF)			
69-896C		SHIM,LOWER PANEL FRO NT			
FB03-69-896A	4				
69-897A		CLIP			
G034-69-897	2				
69-897B		FASTENER,TRIM-SLIDE ROOF			
GA2B-69-897	7	(W/STEEL SUN ROOF)			
69-911		SHADE,SUN			
F114-69-890A	1	(W/GLASS SUN ROOF)			
69-923		CLIP,DRAIN HOSE-SUN ROOF			
FD01-69-929	2				
69-923A		CLIP,DRAIN HOSE-REAR			
FD01-69-923	6				
69-926		JOINT,DRAIN HOSE-REA R			
F100-69-926A	2	(ILLUST. NO.1)			
KA02-69-926	2	(ILLUST. NO.2)			
69-927		NUT,ADJUST-S/ROOF FR AME			
GA2B-69-927	4				
69-95YA		BRACKET,SUN ROOF-FRO NT			
FD01-69-842	4				
74-030L		HOSE,DRAIN-REAR			

THE D-CODE OF **69-840A** CONSISTS OF
FIGURE NUMBERS **①** THROUGH **⑦**.


CMT, AUFA06-04







PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
+-----+ 10-T11 +-----+		RING, 'O'-OIL LEVEL S ENSOR			
N326-10-T11	1				
+-----+ 10-416 +-----+		PLATE, LOCKING			
N3A1-10-416	1				-4C01
+-----+ 10-7301 +-----+		SENSOR, OIL LEVEL			
N3A1-10-470	1				-4C01
A (N3A1-10-470A)					
N3A1-10-470A	1				4C01-
+-----+ 13-356A +-----+		RIVET			
N304-13-356B	1				
+-----+ 14-8201 +-----+		GAUGE UNIT, OIL PRES.			
N3A1-14-820	1				
+-----+ 17-400 +-----+		GEAR SET, DRIVEN-SPEE D			
BV65-17-400	1	(AT)			
+-----+ 17-442J +-----+		RING, 'O'			
1011-17-443	1	(AT)			
+-----+ 17-630 +-----+		SWITCH			
R506-17-640	1	(1ST & 2ND SWITCH) (MT)			
+-----+ 17-640A +-----+		SWITCH, PARK & NEUTRA L			
R507-17-640	1	(MT)			
+-----+ 17-640B +-----+		SWITCH, BACK UP LAMP			
R508-17-640	1	(MT)			
+-----+ 18-T41 +-----+		RING, 'O'-WATER THERM O SW.			
F8B5-18-T41	1	(MT)			
F8B5-18-T41	2	(AT)			
+-----+ 18-211C +-----+		SENSOR, M.A.P.			
N3A1-18-211	1				
+-----+ 18-222A +-----+		PLATE, SENSOR			

4C01 FD333 -400022




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D N3A1-18-222	1				
18-230		SENSOR, CRANKSHAFT PO SI.			
N3A1-18-221	2				
18-270A		RELAY, FUEL PUMP			
NF01-18-821	1				
18-510		UNIT, HEAT GAUGE			
JE15-18-51X	1	PANASONIC			
KL01-18-51X	1	NIHON THERMOSTAT			
18-701		CONTROL UNIT			
N3A1-18-701	1	(ILLUST. NO.1)			
N3DB-18-701	1	(ILLUST. NO.2) (CALIF.) (FED.)			5418-
18-811		RELAY, MAIN			
JE16-18-811	1	DENSO			
18-821		RELAY, FUEL PUMP			
NF02-18-821A	1				
18-831		RESISTOR			
N3A1-18-831	1	(ILLUST. NO.1)			
N3A2-18-831A	1	(ILLUST. NO.2) (AT)			
18-835E		BRACKET, BOOST SENSOR			
N3A1-18-835	2				
18-840C		SENSOR, TEMP. -ENG. COO LANT			
F202-18-840A	1	DENSO (ILLUST. NO.1)			
NF02-18-840	1	(ILLUST. NO.2)			
N370-18-840	1	(ILLUST. NO.3) (AT)			
18-845		SENSOR, IN. AIR TEMP			



5418 FD353 -400030



(1ST&2ND SWITCH)



(MT)




(AT)

AUFA06


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D BV65-21-5H2	1	(AT)			
21-571B		GENERATOR, SPEED PULS E			
BV65-21-5H1	1	(AT)			

CAT. AUFA06-04

1997-01




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-225B		COVER, HOLE			
FD03-55-225	1	(HARD SUSP)			
00		BLACK			
55-280J		BULB			
B456-60-223	1				
66-241		PROTECTOR			
FD01-66-241	1				
66-250		LIGHTER, CIGAR			
P100-66-250	1				
66-251		RING, ILLUMINATION			
UB40-66-251	1				
66-340		SWITCH, MAIN			
FD01-66-340	1	(NOR. SUSP)			
66-600A		SWITCH, RMT. MIRROR			
FD01-66-600A	1				
66-670		SWITCH, RETRACTOR			
FD01-66-670	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
60-253		CAM,CANCEL			
*GB6H-66-126	1				
66-CS0		SPRING,CLOCK			
*FD04-66-CS0	1				
66-110		SWITCH,COMBINATION			
FD01-66-120E	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD04-66-120D	1	(W/GLASS SUN ROOF)			
66-121B		SPRING,CANCEL CAM			
*H384-66-121	1				
66-122		SWITCH,DIMMER			
*FD04-66-136	1				
66-122B		SWITCH,LIGHT & TURN			
*FD04-66-122	1				
66-123C		UNIT,WIPER-COMB. SWITCH			
*FD04-66-135	1				
66-128B		LEVER,WIPER-COMB. SWITCH			
*FD01-66-128	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
*FD04-66-128	1	(W/GLASS SUN ROOF)			

6615 POWER WINDOW SWITCHES

6615 -1 * POWER WINDOW SWITCHES





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-350		SWITCH, POWER WINDOW			
FD14-66-350C	1				
66-370		SWITCH, POWER WINDOW			
FD01-66-370A	1				




5123 FD333 -400026

6630 BODY RELAYS & UNIT







6630 -2 * BODY RELAYS & UNIT


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-7404		RELAY, TRANSFER			
HD22-67-740	2	(RADIO RELAY) (AIR PUMP RELAY)			
H302-67-740	1	20A (STARTER CUT RELAY)			
67-830		UNIT, DOOR LOCK & TIMER			
FC33-67-830	1				
67-9A1A		BRACKET, RELAY			
FD01-67-9B1B	1	(ILLUST. NO.1)			
F100-67-9C1A	1	(ILLUST. NO.2)			
67-990G		BRACKET, A.B.S.			
FD31-67-B5XA	1	(ILLUST. NO.1)			
FD31-67-B5Y	1	(ILLUST. NO.2)			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-546	2	SCREW, DOOR SWITCH			
LA01-66-546					
66-780A	1	HORN, HIGH TONE			-4A01
F100-66-780A A (F100-66-780B)					
F100-66-780B	1				4A01-
66-790	1	HORN, LOW TONE			-4A01
FD01-66-790A A (FD01-66-790B)					
FD01-66-790B	1				4A01-
66-820	2	SWITCH, DOOR			
B455-66-540					
4A01 FD333 -400C14					














PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-231		ORNAMENT, STEREO			
FD01-66-9MOD	1	(W/O C.D. PLAYER)			
66-AC5		SPRING, AUDIO			
E016-66-AC5	2	(W/O C.D. PLAYER)			
66-AC9		RUBBER, REAR-ET/ED COMBI.			
FD01-66-AC9	1				
66-AG0		PLAYER, COMPACT DISC			
FD04-66-9G0B	1	(W/C.D. PLAYER)			
66-BC2		KNOB, VOLUME-TUNER & DECK			
FD01-66-BC1	1				
66-BC2A		KNOB, BASS/TREBLE			
FD01-66-BC2	2				
66-DS0		CD SOFT			
F105-66-DS0	1	(W/C.D. PLAYER)			
66-870J		AUDIO SET			
FD01-66-9C0B	1	(ILLUST. NO.1) (W/O C.D. PLAYER)			
FD04-66-9C0B	1	(ILLUST. NO.2) (W/C.D. PLAYER)			
66-903		BRACKET, TUNER			
FD04-66-AW1	2	PANASONIC (W/C.D. PLAYER)			
66-904		BRACKET, REAR			
FD04-66-AW6	1	(W/C.D. PLAYER)			
66-911B		COVER, HOLE			
FD01-66-BC4	2	(ILLUST. NO.1)			
FD04-66-BC4	2	(ILLUST. NO.2) (W/C.D. PLAYER)			
66-920E		AMP, POWER-FRONT			
FD01-66-920A	1	(W/O C.D. PLAYER)			
FD04-66-920A	1	(W/C.D. PLAYER)			





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-981A		CONNECTOR, SHORT			
FD01-66-BC9	1				
66-997C		CORD, EARTH-RADIO			
FD02-66-997A	1				



66-930









6682 -1 AUDIO SYSTEMS (ANTENNA & SPEAKER)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-034		CAP			
H380-51-013	5	(W/C.D. PLAYER)			
H380-51-013	8	(W/O C.D. PLAYER)			
66-A3Y		PLATE, EARTH-MOTOR AN			
FD01-66-A3Z	1	TENNA			
66-A30		NUT, MOUNTING-ANTENNA			
FD01-66-A9Y	1	(ILLUST. NO.2)			-5206
M001-66-A31	1	(ILLUST. NO.1)			5206-
FD02-66-A9Y	1	(ILLUST. NO.2)			5206-
66-A32		RING, 'O'-MOUNTING AN			
FD02-66-A3Z	1	TENNA			5206-
66-A64		BRKT, JOINT-SPEAKER D			
FD10-66-A64A	1	UCT (W/C.D. PLAYER)			
66-A66		WASHER, SPEAKER			
FD09-66-A66	1	(W/C.D. PLAYER)			
66-A66A		BRACKET, DUCT SPEAKER			
FD10-66-A66	1	(W/C.D. PLAYER)			
66-A9Z		INSULATOR, ROD-ANTENN			
FD01-66-A9Z	1	A			
66-A94		PIPE, DRAIN-ANTENNA			
FD01-66-A90	1				
66-E6X		DUCT 'A', REAR SPEAKER			
FD10-66-E6XC	1	(W/C.D. PLAYER)			
66-E6Y		DUCT 'B', RR SPEAKER			
FD10-66-E6ZC	1	(W/C.D. PLAYER)			
66-E6YA		DUCT 'C', RR SPEAKER			
FD10-66-E6YC	1	(W/C.D. PLAYER)			
66-E60		SPEAKER, REAR			

5206 FD333 -400026





PART NO.	QTY	MODEL/RESTRICTION	MODFL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
FD10-66-960B	1	(W/C.D. PLAYER)			
66-080		CORD			
FD01-66-D10	1				
66-930		ANTENNA, RADIO			
FD01-66-930B	1				
66-935		FEEDER-ANTENNA			
FD01-66-940B	1	(ILLUST. NO.1)			
FD02-66-940C	1	(ILLUST. NO.2)			-5C26
A (FD02-66-940D)					
*FD02-66-940D	1	(ILLUST. NO.2)			5C26-
66-936A		BRKT, MOTOR-ANTENNA			
FD01-66-A9X	1				
66-941		POLE, ANTENNA			
FD01-66-A3X	1				
66-950A		BRACKET(L), SPEAKER			
FD10-66-A65A	1	(W/C.D. PLAYER)			
66-960C		SPEAKER, FRONT			
FD01-66-960A	1	(W/O C.D. PLAYER)			
FD04-66-960A	1	(W/C.D. PLAYER)			
66-960H		SPEAKER(R), LOUD-DOOR			
FD09-66-960C	1	(ILLUST. NO.2) (W/C.D. PLAYER)			-5501
FD15-66-96X	1	(ILLUST. NO.1) (W/O C.D. PLAYER)			5501-
AN(FD02-66-96XF)					
FD02-66-96XF	1	(ILLUST. NO.1) (W/O C.D. PLAYER)			
66-960J		SPEAKER(L), LOUD-DOOR			
FD08-66-960C	1	(ILLUST. NO.2) (W/C.D. PLAYER)			-5501
FD15-66-96Y	1	(ILLUST. NO.1) (W/O C.D. PLAYER)			5501-
FD02-66-96YF	1	(ILLUST. NO.1) (W/O C.D. PLAYER)			
5501 FD333	-400229				
5C26 FD333	-400531				



6682 -3 * AUDIO SYSTEMS (ANTENNA & SPEAKER)


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-960K		SPEAKER(R), LOUD-RR			
FD17-66-96X	1	(W/O C.D. PLAYER)			-5616
FD06-66-96XA	1	(W/O C.D. PLAYER)			5616-
66-960N		SPEAKER(L), REAR			
FD17-66-96Y	1	(W/O C.D. PLAYER)			-5616
FD06-66-96YA	1	(W/O C.D. PLAYER)			5616-
66-970F		CORD, EARTH			
FD01-66-997A	1				
67-051G		CLIP			
B093-67-051	1				
67-191A		CLIP			
B467-67-CE1	2				
68-615B		NUT, FLANGE-CAP			
B100-68-615	1				
76-809		FELT			
FD08-66-EG5A	1	(W/C.D. PLAYER)			
87-137		FELT			
FD11-66-EG5	2	(W/C.D. PLAYER)			

5616 FD333 -400230




6700 FRONT & REAR WIRING HARNESSSES

(1/2)



6700 -1 FRONT & REAR WIRING HARNESSSES

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
14-770		BRACKET,OIL COOLER			
N3A2-14-770B	1	((MT))>(NOR. SUSP))			
50-039A		CLIP,PROTECTOR			
F100-67-CH1	2				
56-240		COVER			
FD01-56-06XA	1				
56-871A		RUBBER,SEAL			
FD01-56-062	1				
66-136		FUSE (30A)			
H115-67-099	1				
66-136A		FUSE (40A)			
H116-67-099	1				
66-496		FUSE (15A)			
99705-1115	1				
66-497		FUSE (20A)			
99705-1120	1				
66-497B		FUSE (30A)			
99705-1130	1				
66-755		CASE,RELAY BOX			
FD01-66-755C	1				
66-756		COVER,UNDER-RELAY BOX			
FD01-66-756	1				
66-760		BLOCK,MAIN FUSE			
FD31-66-760	1				
66-761		COVER,MAIN FUSE BLOCK			
FD31-66-761	1				
66-767		COVER,UNDER MAIN FUSE BLK			
FD01-66-767	2				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-B22		BRACKET, HARNESS			
FD01-67-B12	1				
67-B7X		BRACKET, HARNESS			
FD05-67-B7XE	1				
67-ED0		WIRE, EARTH-REAR DEFF OGER			
FD01-67-ED0A	1				
67-SH1		CORD, SHORT			
F100-67-SH0D	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			
67-010A		HARNESS, FRONT			
FD31-67-010B A (FD31-67-010D)	1	(MT)			-5418
FD33-67-010B A (FD33-67-010D)	1	(AT)			-5418
FD31-67-010D	1	(MT)			5418-
FD33-67-010D	1	(AT)			5418-
67-014F		PROTECTOR, HARNESS			
F100-67-PS1	1				
67-050		HARNESS, REAR			
FD31-67-050A	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD34-67-050A	1	(W/GLASS SUN ROOF)			
67-06Y		HARNESS NO.3, REAR			
FD01-67-06YE	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD04-67-06YF	1	(W/GLASS SUN ROOF)			
67-060		HARNESS NO.2, REAR			
FD01-67-060E	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD04-67-060D	1	(W/GLASS SUN ROOF)			
67-061J		PAD, PROTECTOR-HARNES			
F100-67-PP1	2				

5418 FD333 -400030


6700 FRONT & REAR WIRING HARNESSSES

(1/2)




6700 -3 * FRONT & REAR WIRING HARNESSSES


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-071A		CORD			
F100-67-071F	1	(ILLUST. NO.1)			
F100-67-270A	1	(ILLUST. NO.2)			
67-099D		FUSE (60A)			
FB01-67-099	3	60A			
67-100		HARNESS, ROOM LAMP			
FD01-67-100D	1	(W/O SUN ROOF)			
FD04-67-100D	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			
67-9C0		BOX, RELAY-FRONT HARNESS			
FD15-66-750	1				
67-9C2		COVER, RELAY BOX-FRONT HARNESS			
FD15-66-752	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-0FXA		BRACKET, ENGINE HARNESS			
N3A1-18-0FXA	1	(ILLUST. NO.1)			
N3A2-18-0FXA	1	(ILLUST. NO.2)			
18-050		WIRING, ENGINE			
N3A3-18-05Z	1	(ILLUST. NO.2)			
N3A1-18-05ZF A (N3A1-18-05ZG)	1	(ILLUST. NO.1) (MT)			-5418
N3A2-18-05ZH A (N3A2-18-05ZJ)	1	(ILLUST. NO.1) (AT)			-5418
N3A1-18-05ZG	1	(ILLUST. NO.1) (MT)			5418-
N3A2-18-05ZJ	1	(ILLUST. NO.1) (AT)			5418-
18-054		BRACKET, HOLE-ENG. WIRING			
N3A1-18-0FY	1				
18-058		BRACKET, ENGINE HARNESS			
N3A2-18-054	1				
66-136		FUSE (30A)			
H115-67-099	1				
66-136A		FUSE (40A)			
H116-67-099	1				
66-760		BLOCK, MAIN FUSE			
FD02-66-760C	1				
66-761		COVER, MAIN FUSE BLOCK			
FD02-66-762A	1				
66-872		TAB, EARTH			
FD01-67-TE1C	1				
67-B7X		BRACKET, HARNESS			
FD03-67-B7XD	1				
67-B71		BRACKET, HARNESS			
FD01-67-B71B	1	(MT)			
5418 FD333 -400030					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D FD02-67-B71A	1	(AT)			
67-070		HARNESS, ENGINE			
FD01-67-070L	1	(MT)			
FD02-67-070C	1	(AT)			
67-071C		WIRE, EARTH			
FD01-67-E70A	1				
67-099T		FUSE (120A)			
J001-67-099	1				





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-495		FUSE (10A)			
99705-1110	5				
66-496		FUSE (15A)			
99705-1115	7				
66-497		FUSE (20A)			
99705-1120	4				
66-497B		FUSE (30A)			
99705-1130	1				
66-730		BLOCK, FUSE			
FD01-66-730A	1				
66-732D		COVER, FUSE BLOCK			
FD01-66-731A	1				
66-733A		BREAKER			
H001-66-733	1				
67-020D		HARNESS, INST.			
FD01-67-032A	1				
67-030		HARNESS, INSTRUMENT			
FD15-67-030C	1	((W/O SUN ROOF))>(MT)			
FD17-67-030C	1	((W/O SUN ROOF))>(AT)			
FD18-67-030C	1	((W/GLASS SUN ROOF))>(MT)			
FD19-67-030C	1	((W/GLASS SUN ROOF))>(AT)			
FD36-67-030	1	(W/STEEL SUN ROOF)			
67-040		HARNESS, DASHBOARD			
FD15-67-040B	1	((W/O SUN ROOF))>(MT)			
		(W/STEEL SUN ROOF)			
FD17-67-040B	1	((W/O SUN ROOF))>(AT)			
FD18-67-040B	1	((W/GLASS SUN ROOF))>(MT)			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D FD19-67-040B	1	((W/GLASS SUN ROOF))> (AT))			
67-240G FD01-67-240E	1	HARNESS, LOGICAL CONT ROL			


6703 DOOR, FLOOR & CEILING WIRING HARNESSSES



6703 -1 * DOOR, FLOOR & CEILING WIRING HARNESSSES


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-180F FD31-67-180A	1	WIRING,FLOOR			
67-190J FD15-67-190C	1	HARNESS,DOOR-DRIVER SIDE			
67-200D FD15-67-200C	1	HARNESS,DOOR-PASSENGER SIDE			

6704 WIRING HARNESS CLAMPS




① 45-961B	② 66-941A	③ 67-CC1	④ 67-CC1	⑨ 20-451
⑤ 67-CT1	⑥ 67-013A	⑦ 67-013D	⑧ 67-191A	


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
20-451		CLIP			
B612-20-468	1	(MT)			4A03-
45-961B		CAP			
H002-45-961	1				
66-941A		CLIP			
FB01-66-945	1	(MT)			-4A03
67-CC1		CLIP, HARNESS			
FD01-67-CC1	6	(ILLUST. NO.1)			
F100-67-C41	1	(ILLUST. NO.2)			
67-CT1		CLIP, HARNESS			
FD01-67-CD1	2				
67-013A		CLIP			
UB42-67-013	1	(AT)			
67-013D		PROTECTOR, HARNESS			
FD01-67-P13	2				
67-191A		CLIP			
B467-67-CE1	2				
4A03 FD333 -400014					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-775A		CLIP, WASHER HOSE			
D061-67-505	1	(ILLUST. NO.1)			
M020-67-505	2	(ILLUST. NO.2)			
67-013A		CLIP			
H045-67-013	1				
67-480		TANK, WASHER-FRONT			
FD01-67-480B	1				
67-500C		PIPE, SCREEN WASHER			
FD05-67-501	1				
67-500J		PIPE, SCREEN WASHER			
FD03-67-501	1	(ILLUST. NO.1)			
FD04-67-501A	1	(ILLUST. NO.2)			
67-501D		PIPE, WASHER-FRONT WI PER			
FD01-67-501	1	(ILLUST. NO.1)			
FD02-67-501	1	(ILLUST. NO.2)			
67-502A		JOINT, HOSE			
FD01-67-502	2				
67-508		VALVE, CHECK			
FD01-67-508	2				
67-509B		TUBE, CORRUGATE			
FD01-67-509	1	(ILLUST. NO.1)			
FD02-67-509	1	(ILLUST. NO.2)			
67-510C		NOZZLE(R), WASHER			
FD02-67-510	1				
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
03	EXT-	M8 N6 PX PZ 2A 3L 4G BLACK			
67-510D		NOZZLE(L), WASHER			
FD01-67-510	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
03	EXT-	MB N6 PX PZ 2A 3L 4G BLACK			
76-671A		TANK, WASHER-RR WIPER			
FD01-67-481A	1				
76-672A		CAP, TANK			
FD01-67-483	1				
76-672B		PUMP, WASHER			
FD01-67-482	1				
76-677A		GROMMET, WASHER TANK			
S084-76-677	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-306		NUT, WIPER LINK			
GJ21-67-306	5				
67-321C		ARM, WIPER-DRIVER SIDE			
FD01-67-321	1				
67-321D		ARM, WIPER-CO DRIVER SIDE			
FD02-67-321	1				
67-330		BLADE, WIPER-FRONT			-5201
TA02-67-330 AN(TA02-67-330A)	1				5201-
TA02-67-330A	1				
67-330D		BLADE(L), WIPER-FRONT			-5201
FD01-67-330A AN(FD01-67-330B)	1				5201-
FD01-67-330B	1				
67-331		RUBBER, BLADE-FRONT			-5201
F100-67-331 AN(H272-67-331B)	1				5201-
H272-67-331B	1				
67-331Z		RUBBER, BLADE-FRONT			-5201
D061-67-331 AN(D061-67-331A)	1				5201-
D061-67-331A	1				
67-350		MOTOR, WIPER			
FD01-67-340	1	(EXC. COLD SPEC)			
FD02-67-340	1	(COLD SPEC)			
76-601		LINK, WIPER			
FD01-67-360	1	(EXC. COLD SPEC)			
FD02-67-360	1	(COLD SPEC)			
76-641		COVER, WIPER ARM-FRONT			
LA01-67-395A	2				
76-657		SHAFT, DRIVE NO.1			

5201 FD333 -400026




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
FD01-67-363	1	(EXC.COLD SPEC)			
FD02-67-363	1	(COLD SPEC)			
76-658		SHAFT,DRIVE NO.2			
FD01-67-364	1	(EXC.COLD SPEC)			
FD02-67-364	1	(COLD SPEC)			
76-659		ARM NO.1,LINK			
FD01-67-361	1				
76-659A		ARM NO.2,LINK			
FD01-67-362	1				

6740 WIPER MOTOR COMPONENTS (FRONT)
 COMPONENTS OF FD01-67-340
 FD02-67-340



6740 -1 * WIPER MOTOR COMPONENTS (FRONT)


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
76-612		PLATE, HOLDER-BRUSH			
FD01-67-351	1	(EXC. COLD SPEC)			
FD02-67-351	1	(COLD SPEC)			
76-619		PARTS SET			
H043-76-619A	1				
76-661		GEAR, SHAFT			
FD01-67-354	1				
76-662		WASHER			
B094-76-662	1				
76-663		WASHER, TOOTHED			
B094-76-663	1				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-241		PLUG, DRAIN			
0118-56-241	1	BASE, R2, R3, (W/O RR WASHER TANK)			
56-775A		CLIP, WASHER HOSE			
LA01-67-505B	1	TOURING, (W/RR WASHER TANK)			
66-371		CAP, SEAL			
FD01-67-366	1				
66-372B		NUT			
B093-76-605	1				
66-941A		CLIP			
GB08-66-941	4	TOURING, (W/RR WASHER TANK)			
66-971K		GROMMET			
0222-66-971	1	BASE, R2, R3, (W/O RR WASHER TANK)			
67-330F		BLADE, WIPER			-5201
FD03-67-330 AN(FD03-67-330A)	1				5201-
FD03-67-330A	1				
67-331		RUBBER, BLADE-FRONT			-5201
B461-67-331 AN(B461-67-331A)	1				5201-
B461-67-331A	1				
67-421A		ARM, WIPER			
FD01-67-421	1				
67-450A		MOTOR			-5201
FD01-67-450A AN(FD01-67-450B)	1				5201-
FD01-67-450B	1				
67-480A		TANK, WASHER-REAR			
FD02-67-480	1	TOURING,			

5201 FD333 -400026



6750 WINDOW WIPER & WASHER (REAR)



6750 3 * WINDOW WIPER & WASHER (REAR)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
76-674B	1	FANNEL			
FD02-67-484	1	TOURING, (W/RR WASHER TANK)			
93-2804	1	PIPE,VINYL			
99328-04010	1	1.10M CUT IT TO USE			


6760 WINDOW WIPER MOTOR COMPONENTS (REAR)
COMPONENTS OF FD01-67-450B




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
76-607A		BUSH, INNER			
FD01-67-402 A (FD01-67-402A)	1				-5201
FD01-67-402A	1				5201-
76-612A		PLATE, HOLDER-BRUSH			
FD01-67-451	1				
76-619A		PARTS SET			
B002-76-619A	1				

5201 FD333 -400026

6800 CEILING TRIMS

(STEEL SUN-RF)
(GLASS SUN-RF)

(W/O SUN-RF)



a	b	c	d
68-D21	68-0C0	68-865S	68-865U



AUFA06


6800 -1 * CEILING TRIMS

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-D21		CLIP, TRIM			
GA2A-68-D21	1				
68-0C0		CLIP, TOP CEILING			
M001-68-0C0A	2				
68-021A		INSULATOR, ROOF			
FD01-68-021A	1	(W/O SUN ROOF)			
68-022B		PAD, ROOF			
FD15-68-016	1	(W/O SUN ROOF)			
68-030		CEILING, TOP			
FD01-68-030C	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			-4A01
02	INT-	FE5 FE6 FE7 BLACK			
FD03-68-030C	1	(W/O SUN ROOF)			-4A01
02	INT-	FE5 FE6 FE7 BLACK			
FD03-68-030D	1	(W/O SUN ROOF)			4A01-
02	INT-	FE5 FE6 FE7 BLACK			
FD01-68-030D	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			4A01-5C26
02	INT-	FE5 FE6 FE7 BLACK			
*FD01-68-030E	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			5C26-
* 02	INT-	FE5 FE6 FE7 BLACK			
68-865Q		FASTENER			
GJ21-68-885B	4				
00	INT-	FE5 FE6 FE7 BLACK			
68-865S		CLIP, TRIM			
GJ12-68-865	4				
68-865U		CLIP, TRIM			
GJ21-68-865	2				
69-980A		BRACKET, OVERHEAD CON SOLE			
FD01-69-98X	1				



4A01 FD333 -400014
5C26 FD333 -400531

CAT. AUFA06-04

1997-01




68-160
68-160Z



PART NO	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-D21		CLIP,TRIM			
FD01-68-D21	2				
68-160		TRIM(R),'A'PILLAR			
FD01-68-160F	1				-5C26
02	INT-	FE5 FE6 FE7 BLACK			5C26-
*FD01-68-160G	1				
* 02	INT-	FE5 FE6 FE7 BLACK			
68-160Z		TRIM(L),'A'PILLAR			
FD01-68-170F	1				-5C26
02	INT-	FE5 FE6 FE7 BLACK			5C26-
*FD01-68-170G	1				
* 02	INT-	FE5 FE6 FE7 BLACK			
68-218B		SPRING,TRIM			
FD01-68-165	2				
68-865S		CLIP,TRIM			
GJ12-68-865	2				
5C26 FD333 -400531					


6840 TRIMS & SCUFF PLATES



(a)	(b)	(c)	(d)	(e)	(f)
64-345C	68-AB1	68-AC3	68-AD3	68-AD4	68-D21
(g)	(h)	(i)	(j)	(k)	
68-172H	68-353	68-712D	68-865Q	68-865S	


6840 -1 TRIMS & SCUFF PLATES

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
64-345C		SPRING, UPPER PLATE			
H260-64-345	6				
68-AB1		FASTENER			
FD01-68-AB1B	2				
68-AC3		FASTENER			
B467-68-AC3	10				
02	INT-	FE5 FE6 FE7 BLACK			
68-AD3		CLIP, SCUFF PLATE			
H380-68-AD3	2				
68-AD4		GROMMET, SCUFF PLATE			
FD01-68-AD4C	2				
68-D21		CLIP, TRIM			
LA10-68-D21	1				
68-172H		FASTENER, CTR. P/UPP.			
B100-68-215A	1				
68-315		STRAP			
EA01-68-315	2				
68-320		TRAY, REAR PACKAGE			
FD01-68-310B	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
FD05-68-310C	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-351		BRKT, FRT SIDE TRIM			
FD01-68-351	1	(FOR RIGHT)			
68-351Y		BRACKET(L), UPPER-F.S			
FD01-68-356	1	IDE			
68-352		BRACKET(R), LOWER-F.S			
FD01-68-352	1	IDE			





(a)	(b)	(c)	(d)	(e)	(f)
64-345C	68-AB1	68-AC3	68-AD3	68-AD4	68-D21
(g)	(h)	(i)	(j)	(k)	
68-172H	68-353	68-712D	68-865Q	68-865S	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
+-----+ 68-352Z +-----+		BRACKET(L), LOWER-F.S IDE			
FD01-68-357	1				
+-----+ 68-353 +-----+		PIN, GUIDE-F.SIDE TRI M			
FD01-68-353	1				-5C19
A (FD01-68-353A)					
*FD01-68-353A	1				5C19-
+-----+ 68-371 +-----+		TRIM(R), FRONT SIDE			
FD01-68-371A	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-371Z +-----+		TRIM(L), FRONT SIDE			
FD01-68-391A	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-711 +-----+		PLATE(R), FRONT SCUFF			
FD01-68-710A	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-711Z +-----+		PLATE(L), FRONT SCUFF			
FD01-68-720A	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-712D +-----+		CLIP			
B456-68-712	4				
+-----+ 68-8T0 +-----+		LID(R), TRUNK SIDE			
FD01-68-8T0B	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-8T0Z +-----+		LID(L), TRUNK SIDE			
FD01-68-8V0B	1				
02	INT-	FE5 FE6 FE7 BLACK			
+-----+ 68-830B +-----+		BRACKET(R), TRUNK SID E			
FD01-68-8H2	1				
+-----+ 68-830X +-----+		BRACKET(L), TRUNK SID E			
FD01-68-8H7	1				
5C19 FD333 -400483					




a	b	c	d	e	f
64-345C	68-AB1	68-AC3	68-AD3	68-AD4	68-D21
g	h	i	j	k	
68-172H	68-353	68-712D	68-865Q	68-865S	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-847		CAP(R),HOLE-TRUNK TRIM			
FD01-68-J30A	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-847Z		CAP(L),HOLE-TRUNK TRIM			
FD01-68-J40A	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-860		TRIM(R),TRUNK SIDE			
FD01-68-850E	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-860Z		TRIM(L),TRUNK SIDE			
FD01-68-870F	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-863B		COVER(R),TRUNK SIDE			
FD01-68-857	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-863X		COVER(L),TRUNK SIDE			
FD01-68-877	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-864C		GRILLE,EXTRACT.-T.S. TRIM			
FD09-68-J5Y	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-865Q		FASTENER			
GJ21-68-885B	4				
00	INT-	FE5 FE6 FE7 BLACK			
68-865S		CLIP,TRIM			
GJ12-68-865	4				
68-890		TRIM,TRUNK END			
FD01-68-89X	1				
02	INT-	FE5 FE6 FE7 BLACK			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
58-612	18	CUSHION, RUBBER			
0259-58-612					
69-760A	1	BOX, STORAGE			
FD01-69-760C					
02	INT-	FE5 FE6 FE7 BLACK			
69-762	1	PLATE, LOCK			
FD01-69-768A					
02	INT-	FE5 FE6 FE7 BLACK			
69-771A	1	LID(R), OUTER-STRAGE BOX			
FD01-69-771A					
02	INT-	FE5 FE6 FE7 BLACK			
69-771Y	1	LID(L), OUTER-STRAGE BOX			
FD01-69-781					
02	INT-	FE5 FE6 FE7 BLACK			




a	b	c	d	e	f
68-615B	68-675	68-865 (NO. 2)	68-865 (NO. 1)	69-885C	99868-0410B

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-6C5		PAD(R),TIRE HOUSE			
FD01-68-644A	1				
68-6C5Z		PAD(L),TIRE HOUSE			
FD01-68-649A	1				
68-6F1		BEZZEL,OPENER LEVER			
FD01-68-6F6A	1				
02	INT-	FE5 BLACK			
17	INT-	FE7 RED			
33	INT-	FE6 TAN			
68-6L1		COVER 'A',HOLE			
FD01-68-6L1A	2				
68-6L2		COVER 'B',HOLE			
FD01-68-6L2A	2				
68-6L3		COVER 'C',HOLE			
FD01-68-6L3A	2				
68-615B		NUT,FLANGE-CAP			
B100-68-615	8				
68-630A		INSULATOR,DASHBOARD			
FD01-68-63XE	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD05-68-63XE	1	(W/GLASS SUN ROOF)			
68-648		PAD,REAR SEAT			
FD01-68-648	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
FD05-68-648	1	(W/GLASS SUN ROOF)			
68-652D		INSULATOR(R),F.FLOOR			
FD01-68-6N6	1				
68-654B		INSULATOR(R),COWL SIDE			
FD01-68-6A1	1				




(a)	(b)	(c)	(d)	(e)	(f)
68-615B	68-675	68-865 (NO. 2)	68-865 (NO. 1)	69-885C	99868-0410B

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-654D		INSULATOR(L), F.FLOOR			
FD01-68-6N7	1				
68-654X		INSULATOR(L), COWL SIDE			
FD01-68-6A2	1				
68-671A		MAT, FLOOR			
FD01-68-670G A (FD01-68-670H)	1	BASE, R2, R3, (W/FRT WIND.WASHER)			-5228
02	INT-	FE5 BLACK			
33	INT-	FE6 TAN			
FD05-68-670G A (FD05-68-670H)	1	TOURING (W/FRT & RR WIND.WASHER)			-5228
02	INT-	FE5 BLACK			
33	INT-	FE6 TAN			
FD01-68-670H	1	BASE, R2, R3, (W/FRT WIND.WASHER)			5228-5C26
02	INT-	FE5 BLACK			
33	INT-	FE6 TAN			
FD05-68-670H	1	TOURING (W/FRT & RR WIND.WASHER)			5228-5C26
02	INT-	FE5 BLACK			
33	INT-	FE6 TAN			
*FD01-68-670J	1	BASE, R2, R3, (W/FRT WIND.WASHER)			5C26-
* 02	INT-	FE5 BLACK			
* 33	INT-	FE6 TAN			
*FD05-68-670J	1	TOURING (W/FRT & RR WIND.WASHER)			5C26-
* 02	INT-	FE5 BLACK			
* 33	INT-	FE6 TAN			
68-675		FASTENER			
B100-68-675	2				
68-695		MAT, TRUNK ROOM			
FD01-68-81X	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
5228 FD333 -400026 5C26 FD333 -400531					




(a)	(b)	(c)	(d)	(e)	(f)
68-615B	68-675	68-865 (NO. 2)	68-865 (NO. 1)	69-885C	99868-0410B


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
02	INT-	FE5 FE6 FE7 BLACK			-5401
04	INT-	FE5 FE6 FE7 BLACK			5401-
FD05-68-81X	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			-5401
04	INT-	FE5 FE6 FE7 BLACK			5401-
68-811		BOARD, PARTITION			
FD01-68-82X	1				
02	INT-	FE5 FE6 FE7 BLACK			
68-865		FASTENER			
BF70-68-865	2	(ILLUST. NO.1)			
00	INT-	FE5 BLACK			
17	INT-	FE7 WINE			
33	INT-	FE6 TAN			
G032-68-865A	5	(ILLUST. NO.2)			
00	INT-	FE5 FE6 FE7 BLACK			
69-885C		FASTENER			
UB54-68-885	1				
00	INT-	FE5 BLACK			
18	INT-	FE7 RED			
82	INT-	FE6 BEIGE			
76-071		SILENCER, FLOOR			
0208-76-071	1	30CMX30CM			
5401 FD333 -400028					




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-961D		BOLT			
FD01-56-961	1				
68-AC3		FASTENER			
FD01-68-AC3	1				
68-070		WRENCH, HUB NUT			
NA01-68-070	1				
68-230		STOPPER, WHEEL			
0208-68-230	1				
68-615B		NUT, FLANGE-CAP			
B100-68-615	1				
69-661A		BOX, TOOL			
FD01-69-67YA	1				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-742C		CLIP			
6043-50-742	6				
51-820		GARNISH(R)			
FD01-50-8R0B	1				
51-820Z		GARNISH(L)			
FD01-50-8S0B	1				
69-110A		MIRROR(R), DOOR			
FD01-76-120	1				
MB	EXT-	MB 2A MONTEGO BLUE M			
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
PZ	EXT-	DX PZ PX BRILLIANT BLACK			
3L	EXT-	3L 4G SILVER STONE METALLIC			
69-110Y		MIRROR(L), DOOR			
FD01-76-180	1				
MB	EXT-	MB 2A MONTEGO BLUE M			
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
PZ	EXT-	PX PZ BRILLIANT BLACK			
3L	EXT-	3L 4G SILVER STONE METALLIC			
69-116		BASE(R), MIRROR			
FD01-69-240	1				
MB	EXT-	MB 2A MONTEGO BLUE M			
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
PZ	EXT-	PX PZ BRILLIANT BLACK			
3L	EXT-	3L 4G SILVER STONE METALLIC			
69-116Z		BASE(L), MIRROR			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
FD01-69-242	1				
M8	EXT-	M8 2A MONTEGO BLUE M			
NU	EXT-	NT NU VINTAGE RED			
PT	EXT-	PT VX CHAST WHITE			
PZ	EXT-	PX PZ BRILLIANT BLACK			
3L	EXT-	3L 4G SILVER STONE METALLIC			
69-140A		GLASS(R),MIRROR			
FD01-69-123	1				
69-140Y		GLASS(L),MIRROR			
FD01-69-183	1				
69-170		MIRROR,INTERIOR			
BC1C-69-220	1				
69-210		SUN VISOR(R)			
FD31-69-270A	1	(W/O SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
FD34-69-270A	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
69-210Z		SUN VISOR(L)			
FD31-69-320A	1	(W/O SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
FD34-69-320A	1	(W/STEEL SUN ROOF) (W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
69-261		ADAPTER,SUN VISOR			
GA5R-69-261	2				
02	INT-	FE5 FE6 FE7 BLACK			
69-263		COVER,CENTER ADAPTER			
GA5R-69-263	2				
02	INT-	FE5 FE6 FE7 BLACK			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
69-277		COVER, SUN VISOR			
GA5R-69-277	2				
02	INT-	FE5 FE6 FE7 BLACK			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
57-K91	1	LABEL 'A', CAUTION-A/B			
KA78-57-K91	1				
61-829	1	LABEL, CAUTION			
FD15-61-439	1	(ILLUST. NO.1) (W/AIR CON.)			
FD16-61-439B	1	(A) (ILLUST. NO.2)			
66-201A	1	LABEL, BURGLAR ALARM			
FB01-66-201	1				
66-201B	1	LABEL, ANTI THEFT-AUD IO			
NA01-66-201	1				
69-C61	1	LABEL, UNLEADED FUEL			
UB40-69-C61	1				
69-D51	1	LABEL, VEHICLE INFORM ATION VIN NO. IS REQUIRED			
B001-69-D51	1				
69-D61	1	LABEL, FUEL WARNING			
KA10-69-D61A	1				
69-014	1	LABEL, TIRE			
FD01-69-014 A (FD01-69-014B)	1				
FD01-69-014B	1				
69-014A	1	LABEL, TEMPORARY TIRE			
FD03-69-074A	1	ENGLISH			
FD04-69-074	1	FRENCH			
69-021A	1	PLATE, CAUTION			
NA01-69-068A	1				
69-037	1	LABEL, FUEL ECONOMY (W/FUEL CONSUMPTION LABEL) (MT)			
N3E3-69-042	1				
4A01 FD333 -400014					




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
69-038A	1	LABEL, GASOLINE			
HG30-69-065	1				
69-041	1	LABEL, EMISSION			
N3DB-69-036A	1	(FED.) (MT)			
N3D9-69-036A	1	(FED.) (AT)			
N3E1-69-036A	1	(CALIF.) (MT)			
N3E2-69-036A	1	(CALIF.) (AT)			
69-044A	1	LABEL, VAC. DIAPHRAGM			
N3DB-69-044	1				
69-055A	1	LABEL, SAFETY PANEL			
FA11-69-C31	1	(W/SAFETY LABEL)			
69-064	1	LABEL, BATTERY			
FA03-69-C72A	1	(ILLUST. NO.1) (W/BATTERY LABEL)			
FA01-69-064A	1	(ILLUST. NO.2) (W/BATTERY LABEL)			




(a)	(b)	(c)			
55-216B	68-AC3	68-865S			

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-216B		SPRING,CENTER PANEL			
B092-55-257	4				
68-AC3		FASTENER			
B467-68-AC3	6				
02	INT-	FE5 FE6 FE7 BLACK			
68-5H0		GRILLE(R),SPEAKER			
FD01-68-5H0B	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-5T0		GRILLE(L),SPEAKER			
FD01-68-5W0B	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-50X		BRACKET(R),QUARTER T RIM			
FD01-68-505	1				
68-50XZ		BRACKET(L),QUARTER T RIM			
FD01-68-509	1				
68-52X		POCKET(R),QTR. TRIM			
FD05-68-5C1	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-52XZ		POCKET(L),QTR. TRIM			
FD05-68-5N1	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-520A		TRIM(R),QUARTER			
FD01-68-520H	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
FD05-68-520F	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
68-520Y		TRIM(L),QUARTER			
FD01-68-550H	1	(W/O SUN ROOF) (W/STEEL SUN ROOF)			




(a)	(b)	(c)			
55-216B	68-AC3	68-865S			
					

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
02	INT-	FE5 FE6 FE7 BLACK			
FD05-60-550F	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
+-----+					
68-540B		COVER(R),QTR. TRIM			
+-----+					
FD05-68-5CX	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
+-----+					
68-540X		COVER(L),QTR. TRIM			
+-----+					
FD05-68-5NX	1	(W/GLASS SUN ROOF)			
02	INT-	FE5 FE6 FE7 BLACK			
+-----+					
68-865S		CLIP,TRIM			
+-----+					
GJ12-68-865	18				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-015C		BOLT			
BR70-50-022	10				
50-121		DAM,AIR-SKIRT			
FD03-51-9H0	1	(HARD SUSP)			
50-335		NUT,CLIP			
FB01-50-133C	10				
50-753A		FASTENER			
G043-50-753	2				
50-841G		GROMMET,SCREW			
F044-51-912	4				
51-PS2		SCREW,GROMMET			
FC17-51-PS2A	4				
51-9B0		SPOILER(R),SIDE			
FD01-51-9B0B	1				
51-9C0		SPOILER(L),SIDE			
FD01-51-9C0B	1				
51-9G6		GASKET(R),SPOILER			
FD03-51-9G6	1	(HARD SUSP)			
51-9G7		GASKET(L),SPOILER			
FD03-51-9G7	1	(HARD SUSP)			
51-9K0		SKIRT(R),FRONT AIR D			
FD03-51-9H1A	1	(ILLUST. NO.1)			
FD01-51-9K1	1	(ILLUST. NO.2)			
51-9L0		SKIRT(L),FRONT AIR D			
FD03-51-9H2A	1	(ILLUST. NO.1)			
FD01-51-9L1	1	(ILLUST. NO.2)			
51-95X		SCREW SET			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D BWIN-51-95X	4	(HARD SUSP)			
51-950		SPOILER, REAR			
FD03-51-960C	1	(HARD SUSP)			
M8	EXT	M8 2A MONIEGO BLUE M			
NU	EXT	NT NU VINTAGE RED			
PT	EXT	PT VX CHAST WHITE			
PZ	EXT	PX PZ BRILLIANT BLACK			
3L	EXT	3L 4G SILVER STONE METALLIC			
51-956		BRACKET(R), SPOILER			
FD03-51-965	1	(HARD SUSP)			
51-956A		BRACKET(L), SPOILER			
FD03-51-966	1	(HARD SUSP)			
51-958		CLIP, SPOILER			
B459-51-958	2	(HARD SUSP)			
51-965D		GASKET(C), SPOILER			
FD03-51-968A	1	(HARD SUSP)			
51-966B		GASKET, SPOILER			
FD03-51-969A	1	(HARD SUSP)			
51-994		GASKET, RR SPOILER			
FD03-51-994	1	(HARD SUSP)			
68-675		FASTENER			
B100-68-675	2				
00	EXT	M8 NT NU N6 PT PX PZ VX 2A 3L 4G BLACK			

PART NUMBER INDEX

This index is listed in the following sequence,

INDEX DES NOMBRES DE PIÈCES

Cet index a été composé selon la séquence suivante.

NUMERO INDICE DE PIEZA

Este indice se ordena en la siguiente secuencia.

TEILENUMMERN

Die Teilenummern setzen sich wie folgt zusammen.

GENERAL PARTS

EXAMPLE

- ① Model/Type
Third, in the sequence of model/types (1st-4th digits)
- ② Group
First, in the sequence of group (5th & 6th digits)
- ③ Part
Second, in the sequence of part (7th-9th digits)

PIÈCES GÉNÉRALES

EXEMPLE

- ① Modèle/type
Troisièmement, séquence du modèle/type (1er à 4ème chiffres)
- ② Groupe
Premièrement, séquence du groupe (5ème et 6ème chiffres)
- ③ Pièce
Deuxièmement, séquence de la pièce (7ème à 9ème chiffres)

PIEZAS GENERALES

EJEMPLO

- ① Tipo de modelo
Tercero, en la secuencia de tipo de modelo (entre las cifras 1ro-4to lugar)
- ② Grupo
Primero, en la secuencia de grupo (las cifras en 5to y 6to lugar)
- ③ Pieza
Segundo, en la secuencia de pieza (entre las cifras 7mo-9no lugar)

ALLGEMEINE TEILE

BEISPIEL

- ① Modell/Typ
Angabe des Modells bzw. Typs (1. bis 4. Ziffer)
- ② Baugruppe
Angabe der Baugruppe (5. und 6. Ziffer)
- ③ Teil
Angabe des Teils (7. bis 9. Ziffer)

①
②
③
B A O 1
6 0
3 5 0

STANDARD PARTS

Standard Parts are listed in numerical sequence after General Parts.
(Note: Those parts which do not have D-Code are not listed in the index.)

PIÈCES STANDARD

Les pièces standard sont énumérées selon une séquence numérique, après les pièces générales.
(Remarque: Les pièces qui ne possèdent pas de code D ne sont pas mentionnées dans cet index.)

PIEZAS NORMALES

Las piezas normales se numeran secuencialmente después de las Piezas generales.
(Nota: Las piezas que no tienen un código D no están en el índice.)

STANDARDTEILE

Die Standardteile sind nach den allgemeinen Teilen mit fortlaufender Numerierung aufgeführt.
(Hinweis: Teile ohne D-Code sind nicht aufgeführt.)

*****	N318-10-441	1-D3	N3A1-13-C60	1-L4	N3A2-13-247	1-G4	NF01-13-735	1-F5	N3A1-14-310A	1-E6	N3A1-15-355	1-M6	
*****	N3A1-10-450A	1-E3	N3A2-13-C61	1-L4	N3A3-13-247	1-M4	N3A1-13-735	1-G4	N3A2-14-600	1-E6	N3A1-15-359	1-M6	
* 02-000 *	N3A1-10-470	3-H5	N3A1-13-C80B	1-E4	N3A1-13-249	1-M4	N3A1-13-735	1-M4	N390-14-602	1-E6	N3A1-15-380C	1-L6	
*****	N3A1-10-470A	3-H5	N3A2-13-C80C	1-E4	N3A1-13-250	1-K4	N3A1-13-735	1-M4	N326-14-603B	1-E6	F201-15-382	1-M6	
*****	2306-10-481	1-J5	N3C2-13-C80	1-E4	N3A2-13-250	1-K4	N3C7-13-751	1-M4	N3A1-14-604	1-I6	N3A1-15-383	1-M6	
*****	N3A1-10-498	1-H3	N3C1-13-C8Y	1-M4	N236-13-253A	1-J5	N3A3-13-753	1-F5	N350-14-604	1-E6	F201-15-388A	1-M6	
*****	N3A1-10-500	1-H3	N3A1-13-W6X	1-D5	8574-13-253	1-L4	N3A3-13-754A	1-F5	N350-14-620	1-E6	KF17-15-543	1-M6	
N3A1-02-200	1-C3	N3A1-10-500B	1-H3	N3A2-13-W6X	1-D5	NF01-13-257A	1-L4	N3A1-13-761A	1-K5	N3A1-14-622	1-I6	N3A1-15-610A	1-M6
N3A2-02-200	1-C3	N3A1-10-502	1-H3	N3A1-13-W60	1-D5	N3A1-13-257	1-L4	N3A1-13-765	1-G4	0813-14-623	1-E6	8553-15-611	1-M6
*****	N3A1-10-507	1-H3	N3A2-13-W60	1-D5	N3A1-13-280	1-L4	N3A1-13-766	1-N4	N3A1-14-625A	1-E6	N326-15-812	1-N6	
*****	0813-10-555A	1-F3	N3A1-13-W64	1-D5	N253-13-282	1-L4	N3A1-13-767	1-N4	N318-14-631	1-E6	N3A1-15-907	1-N6	
* 09-000 *	1668-10-556A	1-F3	N3A2-13-W64	1-D5	N3A1-13-300A	1-J5	N3A2-13-768	1-N4	N326-14-633	1-D3	N3A1-15-908	1-N6	
*****	N3A1-10-560B	1-H3	N3A1-11-W68	1-D5	F201-13-302A	1-M4	N3A1-13-785	1-I4	N3A1-14-660A	1-E6	N3A1-15-910A	1-N6	
*****	N3A1-10-566	1-H3	N390-13-W69	1-D5	N3A1-13-320	1-M4	N390-13-785	1-N4	N3A1-14-667A	1-I6	NF01-15-932	1-F8	
*****	*****	*****	N3A1-13-W7X	1-D5	FE51-13-329	1-G4	N3A3-13-786	1-N4	N3A1-14-668A	1-I6	N3A1-15-932A	1-N6	
FD15-09-010C	2-C10	*****	N3A1-13-W70	1-D5	N3A1-13-33X	1-D4	N3A3-13-810	1-F5	N3A1-14-670A	1-E6	N3A1-15-933A	1-N6	
FD15-09-010D	2-C10	* 11-000 *	N3A1-13-W76	1-D5	N3C1-13-330	1-J5	N3A3-13-810	1-F5	N3A1-14-700	1-I6	N3A1-15-94Y	1-N6	
FD15-09-010E	2-C10	*****	N3A1-13-W8Y	1-D5	N3A1-13-35Z	2-K6	N3A3-13-810	1-F5	N3A3-14-700	1-I6	N3A1-15-966	1-N6	
FD17-09-010C	2-C10	*****	N3A1-13-W80	1-D5	N390-13-350	2-K6	N3A1-13-812	1-F5	N3A1-14-702	1-D9	N390-15-966	1-F8	
*****	*****	*****	N3A1-13-W86	1-D5	N304-13-356B	3-H5	N3A1-13-815A	2-D6	*****	*****	*****	*****	
FD17-09-010D	2-C10	N3YA-11-B10	1-M3	N3A1-13-W87	1-D5	N3C1-13-36Y	1-H4	N3A7-13-815	2-D6	N3A1-14-708	1-I6	* 16-000 *	
FD17-09-010E	2-C10	N3A1-11-B11	1-L3	N3A1-13-W89	1-D5	FE51-13-363	1-G4	N3A1-13-816A	2-D6	N3A2-14-708	1-D9	*****	
*****	*****	N3A2-11-B11	1-L3	JE17-13-ZE1	2-K6	NF01-13-363	1-D4	N3A3-13-820A	1-F5	N3B2-14-708	1-I6	*****	
* 10-000 *	*****	N3A3-11-B11	1-L3	FEH2-13-ZE4	2-K6	*****	1-D9	N3A2-13-840	2-D6	N3A1-14-710B	1-J6	*****	
*****	*****	N351-11-C00	1-L3	BP02-13-ZE5	2-K6	0222-13-363	1-I6	N3A1-13-885	1-F4	N3A2-14-710B	1-J6	N315-16-111	1-C7
*****	*****	N351-11-C00B	1-L3	JE48-13-ZG1	1-K4	NF01-13-364	1-D9	N3A3-13-885	1-K5	N3A1-14-720B	1-J6	N315-16-117	1-C7
*****	*****	N326-11-C02A	1-L3	J503-13-ZG1	1-K4	*****	1-I6	N3A1-13-887	1-F4	N3A1-14-770B	1-J6	N315-16-142	1-C7
*****	*****	N326-11-C03A	1-L3	N390-13-ZG1	1-K4	NF02-13-364	1-G4	N3A3-13-888	1-I4	N3A2-14-770B	1-D9	N315-16-150	1-C7
N326-10-B06	1-D3	N326-11-C03C	1-L3	NF01-13-ZG3	1-K4	NF01-13-366	1-N3	N3A2-13-889A	2-C8	*****	1-J6	N315-16-210B	1-C7
N3A1-10-B10	1-D3	N326-11-C04A	1-L3	N3A1-13-ZG3	1-L4	N3A1-13-380	1-E4	NF01-13-890	1-K5	N3A1-14-780B	1-J6	N315-16-221	1-C7
N3A1-10-B50	1-D3	N326-11-C06A	1-L3	NF01-13-ZG4	1-K4	N3A1-13-385A	1-E4	N3A3-13-97X	1-I4	N3A2-14-780B	1-D9	N315-16-410B	1-C7
N326-10-B71A	1-D3	N326-11-C06C	1-L3	J503-13-ZG7	1-K4	N3C2-13-385	1-E4	N3A1-13-970	1-I4	*****	1-J6	N315-16-415	1-C7
N326-10-B72	1-D3	N3Y1-11-C11	1-M3	N3A3-13-ZG7	1-K4	N3A1-13-390B	1-C4	N3A2-13-971A	2-C8	N3A1-14-820	3-H5	N315-16-416	1-C7
N3A1-10-B73	1-D3	NF01-11-C17	1-L3	N3A1-13-ZLY	1-E4	N3C2-13-390	1-C4	N3A1-13-972	1-I4	N3A1-14-830A	1-J6	N315-16-460C	1-C7
N3A1-10-C00D	1-G3	N326-11-C20A	1-L3	N3A1-13-ZL7	1-E4	N3A1-13-396A	1-C4	N3A1-13-978	1-K5	N3A3-14-830A	1-J6	N315-16-510	1-C7
N3A1-10-C08	1-G3	N326-11-C22A	1-L3	N3A1-13-Z01	1-N4	N3A1-13-397A	1-E4	NF01-13-988A	1-K5	N3A1-14-850	1-J6	N315-16-515	1-C7
N326-10-C15	1-D3	NF01-11-C24	1-L3	SL50-13-Z11	1-D4	N3A1-13-410	2-C8	N3A3-13-990	1-F5	*****	*****	N315-16-520B	1-C7
N3YA-10-C50D	1-G3	N3A1-11-D00	1-I3	N3A1-13-Z40	1-N4	N3D8-13-415	1-I4	N3A4-13-990	1-F5	* 15-000 *	*****	N315-16-522	1-C7
N3YB-10-C50D	1-G3	N326-11-D03	1-I3	N3B7-13-100B	1-N3	N3D8-13-420	1-I4	N3A1-13-991	1-F5	*****	*****	N315-16-921	2-I6
*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****
N350-10-C85	1-G3	N326-11-D11	1-I3	E303-13-104	1-J5	N3A1-13-421	2-C8	HE41-13-995	1-K5	* 15-000 *	*****	*****	*****
NF01-10-C86	1-G3	N326-11-D15	1-I3	1010-13-104	1-J5	N3A2-13-421	2-C8	N3A1-13-995	1-K5	*****	*****	*****	*****
N3A1-10-D30	1-D3	N326-11-D17	1-I3	*****	1-M3	N3D8-13-421	2-C8	N390-13-995A	1-K5	*****	*****	*****	*****
N3A1-10-D00A	1-E3	NF01-11-D51	1-J3	N3A1-13-111A	1-N3	N3B7-13-428A	1-I4	N3A3-13-996	1-F5	*****	*****	*****	*****
NF01-10-D10	1-E3	N390-11-D52	1-J3	N3A1-13-112	1-N3	N326-13-428A	1-I4	N3A4-13-996	1-F5	B595-15-T59	1-J6	*****	*****
N3A1-10-D10	1-E3	NF01-11-D53	1-J3	N3A1-13-150	1-K4	N3A7-13-450A	1-C4	*****	*****	N3C1-15-010D	1-J6	*****	*****
N3A1-10-E0YB	1-E3	NF01-11-D54	1-J3	N3A2-13-150	1-K4	N3A7-13-450B	1-C4	*****	*****	N3C2-15-010D	1-J6	*****	*****
NF01-10-E04	1-E3	NF01-11-D55	1-J3	N3B7-13-150	1-K4	N390-13-453A	1-E4	* 14-000 *	*****	8AF4-15-100A	1-J6	*****	*****
NF01-10-E05	1-E3	NF01-11-D56	1-J3	N3D8-13-150	1-K4	N391-13-456	1-C4	*****	*****	N3A1-15-109	1-L6	*****	*****
NF01-10-E06	1-E3	NF01-11-D57	1-J3	N3B7-13-153	1-K4	E5B4-13-461B	1-E4	*****	*****	N3A1-15-116	1-J6	*****	*****
NF01-10-E07	1-E3	NF01-11-D58	1-J3	B6B1-13-157	1-I4	N3A1-13-461	1-C4	*****	*****	N3C1-15-120	1-J6	*****	*****
NF01-10-E08	1-E3	NF01-11-D59	1-J3	N3D8-13-157	1-I4	N3C1-13-468	1-C4	*****	*****	N3A1-15-131	1-K6	*****	*****
NF01-10-E09	1-D3	N3A7-11-D61	1-J3	8574-13-157	1-I4	N236-13-483	1-L4	NF01-14-100	1-D6	N3A1-15-140	1-K6	*****	*****
N3A1-10-E1YC	1-E3	N3A8-11-D61	1-J3	*****	2-C8	N3A1-13-491	2-D6	0810-14-113	1-D6	N3A2-15-140	1-K6	*****	*****
NF01-10-E22	1-E3	N3C1-11-D71	1-I3	N326-13-158	1-K4	N3A1-13-496	1-I4	0221-14-115	1-D6	N3A1-15-150	1-L6	*****	*****
NF01-10-E23	1-E3	N326-11-D75	1-J3	E580-13-161	2-K6	N3A1-13-53X	1-E4	0839-14-115	1-H3	N386-15-162	1-K6	*****	*****
NF01-10-E24	1-E3	0820-11-341	1-L3	N3A1-13-162	1-G4	N3C1-13-530	1-E4	N326-14-117	1-D6	N3A1-15-168	1-K6	*****	*****
NF01-10-E25	1-E3	8341-11-343	1-M3	N350-13-164	1-C4	N386-13-535	2-D6	0839-14-119B	1-D6	N3A1-15-170	1-K6	*****	*****
NF01-10-E26	1-E3	N225-11-351	1-M3	N3A3-13-170	1-G4	N3A1-13-54X	1-E4	8553-14-125	1-D6	N3A2-15-170	1-K6	*****	*****
N350-10-E50A	1-H3	1011-11-353A	1-M3	*****	1-N3	N3A1-13-540A	1-E4	N326-14-131	1-D6	8AF6-15-171	1-K6	*****	*****
*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	N3C1-15-173	1-K6	*****	*****
N350-10-E56	1-G3	N225-11-361	1-M3	N3A1-13-200	1-M4	N3A1-13-550	1-D4	NF01-14-135	1-D6	N326-15-174	1-K6	*****	*****
N350-10-E61A	1-H3	1011-11-363A	1-M3	N3A1-13-203	1-M4	N3A1-13-56X	1-D4	N318-14-140	1-D6	N3C1-15-175	1-K6	*****	*****
N3A1-10-S60	1-C3	N3C1-11-400	1-I3	N3A1-13-220	1-M4	N3A1-13-56YB	1-D4	N326-14-143	1-D6	N3A1-15-182A	1-K6	*****	*****
N326-10-T11	3-H5	1881-11-404	1-I3	N3A1-13-221A	1-M4	N3A1-13-640	1-E5	N326-14-151	1-D6	N3A1-15-183A	1-K6	*****	*****
1757-10-111	1-D3	N3C1-11-406	1-I3	N3D8-13-221	1-M4	N3A2-13-640	1-E5	N3A1-14-230	1-D6	N3A1-15-184A	1-K6	*****	*****
N231-10-174	1-G3	N3C1-11-408	1-I3	N3D8-13-222	1-M4	N3A1-13-655	1-J5	N3A1-14-240A	1-D6	N3A1-15-185A	1-L6	*****	*****
0839-10-203	1-G3	0839-11-412	1-I3	N3A1-13-23XB	1-N3	N3A1-13-661	1-N3	N386-14-248	1-D6	N3A1-15-185B	1-L6	*****	*****
8562-10-205	1-G3	N3A1-11-500	1-I3	N3A1-13-23XC	1-N3	N3A1-13-681A	1-J5	N3A1-14-260	1-F4	N3A1-15-186A	1-L6	*****	*****
1757-10-207A	1-G3	N318-11-502A	1-J3	N3A1-13-231	1-G4	N3A1-13-691A	1-K5	N3A1-14-270A	1-F4	N3A1-15-186B	1-L6	*****	*****
N249-10-219	1-G3	N351-11-521	1-J3	N3A1-13-232	1-G4	N3A1-13-692A	1-K5	N3A1-14-273A	1-H3	N3A1-15-200A	1-L6	*****	*****
0453-10-250A	1-D3	0820-11-705	1-J3	N3D8-13-232	1-G4	N3A1-13-70Y	1-C4	0839-14-274	1-H3	N3A2-15-200A	1-L6	*****	*****
0324-10-252	1-D3	0810-11-711	1-J3	N3A1-13-24XA	1-G4	N3C1-13-700	1-E4	N3A1-14-280A	1-F4	JE48-15-202	1-L6	*****	*****
8AFH-10-271	1-C3	*****	*****	N3A1-13-240A	1-G4	NF01-13-708A	1-C4	N3A1-14-290A	1-F4	NF01-15-203	1-L6	*****	*****
1757-10-309	1-G3	*****	*****	1480-13-240A	1-J5	N3A1-13-710	1-F4	N3A2-14-290A	1-F4	KF01-15-205	1-L6	*****	*****
N3A1-10-400A	1-G3	* 13-000 *	*****	1481-13-240A	1-J5	N3A2-13-710	1-F4	N3D8-14-290	1-F4	N3A1-15-205A	1-L6	*****	*****
HE03-10-404	1-G3	*****	*****	1482-13-240A	1-J5	N3A1-13-712	1-G4	N3D9-14-290	1-F4	N3A2-15-211B	1-L6	*****	*****
N3A1-10-416	3-H5	*****	*****	N3C1-13-245	1-D4	N3A1-13-720	1-K5	N3A1-14-293	1-F4	N3A2-15-211C	1-L6	*****	*****
N3A1-10-420B	1-E3	*****	*****	N3A1-13-246A	1-D4	N3A1-13-721	1-K5	N3A2-14-293	1-F4	2667-15-303A	2-G4	*****	*****
N3A1-10-424A	1-E3	*****	*****	N3A1-13-247	1-M4	N3A1-13-726	1-K5	B6Y1-14-302	1-E6	N3A1-15-35XB	1-L6	*****	*****
N3YA-10-427	1-H3	N350-13-B96	1-K5	N3A2-13-247	1-D4	1480-13-730	1-F5	B6Y1-14-302A	1-F6	N3A1-15-350B	1-M6	*****	*****

F123-34-700A 2-E5	FD01-41-30XA 2-D7	D001-43-152 2-F7	W01C-43-954 2-H7	FD01-50-650D 2-K10	FD01-51-06XB 2-E11
FD01-34-701B 2-D5	H266-41-341 2-G6	FB02-43-152A 2-F8	FD01-43-980B 2-J7	FD01-50-654A 2-K10	FD01-51-060D 2-E11
2-F3	FD01-41-360A 2-I6	FD01-43-221A 2-G7	*****	FD01-50-7P0 2-F12	FD01-51-061 2-E11
FD01-34-710A 2-E5	FD03-41-370 2-I6	FD31-43-250B 2-I7	*****	FB01-50-733 2-H10	FD01-51-064A 2-E11
F123-34-710A 2-E5	F100-41-370 2-I6	FD31-43-260C 2-I7	* 44-000 *	FD01-50-741C 2-N10	B481-51-069 2-I11
FD01-34-711A 2-E5	G091-41-412 2-G6	FD31-43-270C 2-L7	*****	G043-50-742 3-G9	NA01-51-069 2-E11
FD01-34-800H 2-F5	FD01-41-419 2-G6	FD31-43-280B 2-L7	*****	FD01-50-751C 2-N10	FD01-51-07XB 2-E11
FD16-34-900A 2-E5	F100-41-421 2-G6	FD01-43-30XA 2-D7	*****	FD01-50-753 2-J13	FD01-51-070D 2-E11
F123-34-900A 2-E5	0813-41-422D 2-G6	FD01-43-30XB 2-D7	*****	G043-50-753 3-N9	FD01-51-071 2-E11
*****	H005-41-424 2-G6	FD02-43-30XA 2-F7	FD01-44-010G 2-N7	FD01-50-783 2-F12	FD01-51-1E6 2-E11
* 37-000 *	H001-41-443 2-D7	FD02-43-30XB 2-F7	FD01-44-010H 2-N7	FD01-50-790A 2-F12	FD01-51-143 2-J11
*****	B312-41-470 2-G6	FD31-43-310 2-L7	FD01-44-035 2-N7	B482-50-792 2-F12	FD01-51-144 2-J11
* 37-000 *	B312-41-52Z 2-H6	FD31-43-320A 2-L7	FD01-44-036 2-N7	FD02-50-792 2-I11	EA02-51-146A 2-J11
*****	B312-41-53Z 2-H6	FD04-43-360B 2-I7	FD01-44-150 2-N7	FD03-50-792 2-I11	EA04-51-146A 2-J11
B002-37-160 2-G5	FD01-41-600B 2-J6	FD04-43-370B 2-I7	GA2B-44-375A 2-N7	FD01-50-793 2-F12	8BFH-51-150 2-J11
FD01-37-191B 2-G5	FD01-41-660B 2-J6	FD04-43-40Z 2-H7	0118-44-375 2-N7	FD01-50-794A 2-F12	FD01-51-151 2-J11
FD01-37-790A 2-H5	FD01-41-661B 1-N3	TA04-43-403A 2-G7	FD01-44-410A 2-N7	FD01-50-795 2-F12	FD01-51-152 2-K11
FD01-37-810 2-H5	FD01-41-662B 1-N5	B6Y4-43-41Z 2-H7	FD01-44-420B 2-N7	GA7B-50-795 2-F12	FD01-51-153B 2-J11
*****	FD01-41-920 2-G6	B6Y4-43-41ZA 2-H7	*****	UB39-50-795 2-C11	FD01-51-155B 2-J11
* 39-000 *	F100-41-190B 2-G6	FD01-43-443A 2-G7	* 45-000 *	E016-50-796 2-F12	FD02-51-159 2-K11
*****	*****	H001-43-443 2-G7	*****	FD01-50-798 2-F12	8BFH-51-160 2-J11
* 39-000 *	*****	B603-43-45XA 2-G7	*****	FD02-50-798 2-F12	FD01-51-161 2-J11
*****	* 42-000 *	EA03-43-504B 2-L7	*****	FD01-50-799 2-H10	FD01-51-162 2-K11
B001-39-037B 2-C4	*****	W023-43-504 2-G6	FD01-45-111 2-C8	FD01-50-800B 3-G9	FD01-51-163B 2-J11
2-E4	B536-42-045 2-K6	*****	FD01-45-112 2-C8	FD01-50-803 2-H10	FD02-51-169 2-K11
2-E5	0866-42-046 2-K6	HG83-43-505 2-L7	FD01-45-115B 2-C8	FD01-50-803 2-F10	FD01-51-17XE 2-J11
2-F5	FD17-42-11X 2-L6	W023-43-505 2-G6	FD31-45-280A 2-J7	FD01-50-803 2-F10	FD01-51-170B 2-J11
FD01-39-040C 2-C6	FD31-42-110 2-K6	*****	FD31-45-320A 2-J7	FD01-50-850C 2-I11	FD01-51-173 2-K11
FD01-39-040D 2-C6	FD33-42-110 2-K6	HG83-43-506 2-L7	FD01-45-33XC 2-J7	FD01-50-850C 2-I11	FD01-51-18XE 2-K11
FD01-39-050A 2-C6	HG31-42-114 2-K6	NA23-43-515 2-H7	FD01-45-36XA 2-J7	EA01-50-891A 3-M4	FD01-51-180B 2-J11
FD31-39-050 2-C6	FD01-42-210A 2-K6	FDY1-43-55X 2-G7	FD01-45-36ZA 2-J7	FD01-50-894 3-M4	FD01-51-183 2-K11
FD01-39-050A 2-C6	FD01-42-231A 2-L6	G309-43-607 2-H12	FD01-45-360B 2-J7	FDY2-50-91XB 2-F12	FD01-51-24XA 2-K11
FD01-39-065 2-C6	FD01-42-232 2-L6	B533-43-62Z 2-H7	D001-45-367 2-J7	FD01-50-912 2-G12	FD01-51-240B 2-K11
FD01-39-066 2-C6	FD01-42-237 2-K6	NA23-43-625 2-H7	FD01-45-510D 2-I6	FD01-50-913 2-G12	FD01-51-241B 2-K11
FD01-39-710C 2-C6	FD01-42-242 2-L6	FD01-43-63XF 2-I7	HE01-45-540 2-I6	FDY2-50-92XB 2-G12	FD01-51-244 2-K11
FD01-39-710D 2-C6	GE60-42-243 2-L6	FD03-43-63XF 2-I7	FD01-45-611A 2-C8	*****	FD01-51-246 2-K11
FD01-39-723 2-C6	*****	B604-43-63Z 2-H7	FD01-45-612 2-C8	* 51-000 *	FD01-51-249 2-L11
FD01-39-730A 2-F4	FD01-42-244 2-L6	W023-43-635 2-I7	FD01-45-711 2-C8	*****	FD01-51-25XA 2-K11
*****	H260-42-245A 2-L6	W023-43-635A 2-I7	FD01-45-712A 2-D8	FD01-50-180A 2-F10	FD01-51-250B 2-L11
* 40-000 *	UE54-42-250 2-L6	0136-43-635 2-I6	FD01-45-713 2-D8	FD01-50-1C0A 2-F10	FD01-51-251B 2-K11
*****	D061-42-270 2-L6	FD01-43-64XE 2-I7	FD01-45-910A 2-D8	FD01-50-1D0 2-F10	BF67-51-261 2-J13
N3A1-40-D20F 2-D6	FD01-42-289 2-L6	FD03-43-64XE 2-I7	FD01-45-911 2-D8	FD01-50-1E0 2-F10	FD01-51-261A 2-N11
FE20-40-061 2-E6	FD01-42-298 2-L6	FD01-43-640B 2-G7	FB01-45-914 2-N6	FD01-50-1F1 2-F10	BR70-51-264 2-J13
N3A1-40-061D 2-E6	FD01-42-41X 2-C7	FD01-43-670B 2-I7	B455-45-916 2-K7	FD01-50-1G1 2-F10	FD01-51-270C 2-N11
N3A1-40-061E 2-E6	FD31-42-511A 2-M6	H381-43-676 2-G7	B001-45-919B 2-K7	FD01-50-1J1 2-H10	G225-51-273 2-N11
N3A2-40-061A 2-E6	FD01-42-545 2-M6	FD01-43-680B 2-I7	F100-45-92X 2-K7	NA01-50-101A 2-F10	G225-51-274B 2-N11
N3A1-40-080A 2-E6	HG30-42-561 2-M6	B001-43-694A 2-I7	FD01-45-920 2-D8	FB01-50-133C 2-F10	FD01-51-293 2-N11
N3A2-40-080 2-E6	FD01-42-710 2-M6	FD31-43-7A0A 2-L7	NA20-45-920B 2-K7	FD01-50-144 2-F10	FD01-51-305 2-E10
N3C1-40-100A 2-E6	J001-42-715 2-L6	FD31-43-7A0B 2-L7	FD01-45-930 2-D8	3597-50-152 2-F12	LA01-51-440 2-C12
N3A1-40-190 2-E6	FD01-42-720 2-M6	HG82-43-7A2 2-L7	FD01-45-940A 2-D8	FD01-50-170B 2-E10	G225-51-441 2-C12
N3A1-40-290 2-E6	B455-42-761 2-L6	NA23-43-7A3 2-L7	FD01-45-95X 2-D8	FD01-51-1E1A 2-N10	FD01-51-5E0B 2-E11
RF36-40-305 2-E6	FD01-42-761 2-M6	HG82-43-7A4 2-L7	FD01-45-960 2-D8	FD01-51-SE2A 2-N10	FD01-51-5E1B 2-F11
N378-40-307 2-E6	FD01-42-762 2-L6	NA23-43-7A8 2-L7	H002-45-961 2-C7	FDY2-51-SH1 2-N10	H380-51-5E2 2-F11
N3A1-40-354 2-E6	B529-42-763 2-M6	FD31-43-7A9 2-M7	*****	FDY2-51-SH2 2-C11	FD01-51-5F0B 2-E11
JE10-40-355 1-F4	FD01-42-767 2-M6	FD05-43-70XB 2-M7	F048-45-964B 2-K7	FD01-51-SL1A 2-N10	FD01-51-5F1B 2-F11
2-E6	FD01-42-768 2-M6	F051-43-708A 2-M7	FD01-45-970 2-D8	FD01-51-SL2A 2-N10	FD01-51-5H0D 2-L11
2-E6	FD01-42-790 2-M6	FD04-43-71YC 2-M7	FD01-45-980 2-D8	FD01-51-S08A 2-N10	FD01-51-5H1C 2-L11
2-E6	GA5R-42-910 2-M6	FD01-43-710A 2-I7	FD01-45-990 2-D8	FD01-51-S1Y 2-C11	FD01-51-5H2 2-L11
2-E6	BC1M-42-980 2-M6	FD04-43-72YC 2-M7	*****	FD01-51-0A1 2-L10	FD01-51-5H3 2-L11
2-E6	BC1M-42-980A 2-M6	FD01-43-720A 2-J7	* 46-000 *	FD01-50-3A0 2-H10	FD01-51-5H4 2-L11
2-E6	*****	FD05-43-73XC 2-M7	*****	FD01-50-3B0 2-H10	FD01-51-5J0D 2-L11
2-F6	* 43-000 *	FD01-43-740B 2-G7	*****	FD07-50-31X 2-H10	FD01-51-5J1C 2-L11
2-F6	*****	FD31-43-750 2-M7	FD02-46-AT1 2-F8	FD07-50-31Y 2-H10	FD01-51-5J3 2-L11
2-F6	*****	FD31-43-780C 2-M7	FD02-46-030 2-F8	FD01-50-510E 2-K10	FD01-51-5T0 2-G10
2-F6	*****	FD31-43-780D 2-M7	FC07-46-040A 2-F8	FD01-50-516A 2-K10	FD01-51-5V0 2-G10
2-F6	*****	FD04-43-800B 2-H7	FD02-46-040 2-F8	FD01-50-530E 2-K10	FD01-51-5Z1B 2-L11
*****	H261-43-028 2-F7	FD01-43-810A 2-J7	J001-46-051 2-F8	FD01-50-536A 2-K10	FD01-51-577 2-I11
* 41-000 *	FD01-43-041 2-D7	FD01-43-836B 2-H7	FD02-46-058 2-F8	FD01-50-538A 2-K10	FD01-51-584A 2-L11
*****	HF23-43-090A 2-F7	FD01-43-840B 2-H7	FD02-46-10XE 2-F8	FD01-50-539A 2-K10	FD01-51-585 2-I11
0727-41-023 2-D7	H001-43-095 2-J13	F100-43-85X 2-J7	FD02-46-100C 2-F8	NA01-50-6B1 2-J10	FD01-51-589 2-M11
0727-41-131 2-D7	HF23-43-099 2-F7	B455-43-853 2-J7	0187-46-683 2-D7	FE01-50-6B2 2-J10	FD01-51-59XA 2-I11
0305-41-140 2-D7	HE01-43-140 2-D7	FD01-43-86XB 2-J7	H380-46-684 1-L11	FD01-50-615 2-J10	FD01-51-59XB 2-I11
	D001-43-152 2-D7	FD31-43-86YA 2-M7	H380-46-689 1-L11	FD01-50-619A 2-J10	FD01-51-591 2-I11
		F123-43-900 2-M7		FD01-50-640D 2-K10	FD01-51-591A 2-I11
				FD01-50-644A 2-K10	FD01-51-594 2-I11
				FD01-50-646B 2-K10	FD01-51-6A5 2-F11
				FD01-50-649A 2-K10	FD01-51-6G1A 2-F11
					FD01-51-6G8 2-F11

FD01-68-810B02 3-L8	FD34-69-270A02 3-H9	FDY4-70-24X 2-D13	FD01-76-190A 2-D10	FD05-88-111A18 2-I15	FD05-88-6D0 34 2-M15	99701-6040 2-L11
FD01-68-8V0B02 3-L8	FD01-69-276A 2-N10	FD01-70-242B 2-C13	80YA-76-201 2-D10	FD05-88-111A34 2-I15	FD05-88-6D0A02 2-N15	99701-6049 2-H11
FD01-68-81X 02 3-E9	GA5R-69-277 02 3-I9	FD01-70-252A 2-D13	FD01-76-201 2-D10	FD15-88-112 2-I15	FD05-88-6D0A18 2-N15	99701-6050 2-D12
FD01-68-81X 04 3-E9	FD31-69-320A02 3-H9	FD01-70-272B 2-D13	FD01-76-202 2-D10	FD01-88-124 2-F15	FD05-88-6D0A34 2-N15	2-H11
FD05-68-81X 02 3-E9	FD34-69-320A02 3-H9	FD01-70-274A 2-D13	FD01-76-210B 2-C10	FD15-88-130A02 2-I15	FD01-88-6D2B02 2-N15	2-N11
FD05-68-81X 04 3-E9	B316-69-361 2-N16	FD01-70-311A 2-D13	FD01-76-210C 2-C10	FD15-88-130C02 2-I15	FD01-88-6D2B02 2-N15	99703-8605 2-L10
1011-68-815 2-D16	FD15-69-44X 00 2-M16	FDY1-70-400B 2-F13	FD01-76-210D 2-C10	FD18-88-130 02 2-I15	FD03-88-6D2A02 2-N15	99705-1115 3-C7
FD01-68-82X 02 3-E9	FD01-69-67YA 3-F9	FD01-70-440B 2-D13	FD01-76-220B 2-C10	FD18-88-130 18 2-I15	FD03-88-6D2B02 2-N15	3-H7
FD01-68-850E02 3-M8	FD01-69-760C02 3-N8	FD01-70-490B 2-D13	FD01-76-220C 2-C10	FD18-88-130 34 2-I15	FD03-88-6D2C02 2-N15	99705-1130 3-C7
FD01-68-857 02 3-M8	FD01-69-768A02 3-N8	0187-70-491 2-C7	FD01-76-220D 2-C10	FD18-88-130B02 2-J15	FD05-88-6D2 02 2-N15	3-H7
BF70-68-865 00 3-E9	FD01-69-771A02 3-N8	FD04-70-600B 2-G13	FD15-76-250A 2-D10	FD18-88-130B18 2-J15	FD05-88-6D2 18 2-N15	99963-6930 1-J7
BF70-68-865 17 3-E9	FD01-69-781 02 3-N8	FD01-70-601A 2-G13	FD15-76-250B 2-D10	FD18-88-130B34 2-J15	FD05-88-6D2 34 2-N15	99963-6940 1-J7
BF70-68-865 33 3-E9	FD01-69-810B 3-C5	FD01-70-610A 2-N12	FD01-76-260 2-D10	FD19-88-130A02 2-I15	FD05-88-6D2A02 2-N15	99963-6950 1-J7
BR70-68-865 1-C5	F114-69-810B 3-C5	FD01-70-640 2-G13	FD01-76-260A 2-D10	FD19-88-130B02 2-I15	FD05-88-6D2A18 2-N15	99963-6960 1-J7
1-D4	FD01-69-825A 3-E5	FD01-70-651A 2-C13	FD01-76-260B 2-D10	FD19-88-130D02 2-J15	FD05-88-6D2A34 2-C16	99963-6970 1-J7
B102-68-865 00 2-F15	F114-69-825 3-E5	FD01-70-661 2-G13	FD01-76-290 2-D10	FD15-88-131 02 2-J15	B456-88-815 2-C16	*****
B103-68-865 2-G10	FD01-69-840 3-C5	FD01-70-700B 2-G13	FD01-76-290B 2-D10	FD18-88-131 02 2-J15	B260-88-818 2-C16	* STANDARD PARTS *
GJ12-68-865 3-I8	FD01-69-842 3-E5	FD01-70-750C 2-D13	FD02-76-290B 2-D10	FD18-88-131 18 2-J15	EA01-88-818 2-C16	*****
3-J8	FD01-69-845 3-C5	*****	B093-76-605 3-E8	FD18-88-131 34 2-J15	*****	99381-1400 1-I6
3-K4	FD02-69-846 3-D5	* 71-000 *	B002-76-619A 3-H8	FD18-88-131A02 2-J15	* 90-000 *	99611-1500 2-G6
3-M8	FD01-69-851 3-C5	* ***** *	H043-76-619A 3-D8	FD18-88-131A18 2-J15	*****	
3-M9	FD01-69-852 3-C5	*****	B093-76-641 3-F8	FD18-88-131A34 2-J15	*****	
G032-68-865A00 3-E9	FD01-69-858 3-D5	FD01-71-020B 2-E13	B094-76-662 3-D8	FD19-88-131 02 2-J15	90620-17636 2-G5	
FD01-68-870F02 3-M8	FD01-69-859 3-D5	FD01-71-030D 2-E13	B094-76-663 3-D8	FD19-88-131A02 2-J15	90622-65726 2-G5	
FD01-68-877 02 3-M8	FD01-69-861 3-C5	FD01-71-050 2-E13	S084-76-677 3-M7	FD01-88-152 2-J15	90623-25726 2-G5	
GJ21-68-885B00 3-I8	FD01-69-864 3-C5	FD01-71-1B0A 2-E13	HA14-76-707 3-I4	FD01-88-153 2-J15	90623-35726 2-G5	
3-K4	FD01-69-865 3-C5	FD01-71-1D0 2-E13	H001-76-714 3-I4	FD01-88-155 2-J15	90701-7270 2-E11	
3-M8	EA05-69-871 3-D5	FD01-71-1X1 2-F13	H001-76-717 3-I4	FD01-88-160 02 2-K15	*****	
UB54-68-885 00 3-E9	EA05-69-872 3-D5	FD01-71-11Y 2-E13	B001-76-725 3-D4	FD01-88-160A02 2-K15	* 99-000 *	
UB54-68-885 18 3-E9	EA05-69-873 3-C5	FD15-71-11Z 2-E13	B001-76-734 3-F4	FD03-88-160 02 2-K15	*****	
UB54-68-885 82 3-E9	F114-69-890A 3-E5	FDY1-71-110A 2-E13	*****	FD03-88-160A02 2-K15	* 99-000 *	
FD01-68-89X 02 3-M8	FB03-69-896A 3-E5	FD01-71-119 2-F13	* 88-000 *	FD03-88-160B02 2-K15	*****	
FD01-68-911A02 2-H16	GA2B-69-897 3-E5	FD01-71-12XB 2-E13	*****	FD05-88-160 02 2-K15	99236-0571 1-I3	
FD01-68-912A02 2-H16	G034-69-897 3-E5	FD01-71-120B 2-E13	* 88-000 *	FD05-88-160 18 2-K15	99324-07200 1-M6	
FD01-68-930A02 3-L4	FD01-69-9H1 3-D5	FD01-71-131A 2-D13	*****	FD05-88-160A02 2-K15	99324-07400 1-M6	
FD01-68-940B02 3-K4	FD01-69-9H2 3-D5	FD01-71-15XD 2-F13	*****	FD05-88-160A18 2-K15	99328-04010 3-G8	
FD01-68-950B02 3-L4	FD01-69-9H3 3-D5	FD01-71-150E 2-E13	FD01-88-005 2-G15	FD05-88-160A34 2-K15	99340-05540 1-H9	
FD01-68-960C02 3-L4	FD01-69-9H4 3-E5	FDY1-71-200 2-E13	FD01-88-006 2-G15	FD01-88-161 02 2-K15	99351-04999 1-C6	
*****	FD04-69-920 3-E5	FD01-71-230A 2-E13	FD01-88-062 2-F15	FD03-88-161A02 2-L15	99351-06999 1-C6	
* 69-000 *	FD04-69-922 3-E5	FDY1-71-24X 2-F13	FD01-88-072 2-F15	FD03-88-161B02 2-L15	2-N6	
*****	FD01-69-923 3-E5	FD01-71-242B 2-C13	FD01-88-1G1 02 2-G15	FD05-88-161 02 2-K15	99351-08999 1-J4	
FA11-69-C31 3-K9	F100-69-926A 3-E5	FD01-71-252A 2-F13	FD01-88-1G1 17 2-G15	FD05-88-161 18 2-K15	99359-0814 1-I4	
UB40-69-C61 3-J9	KA02-69-926 3-E5	FD01-71-272B 2-F13	FD01-88-1G1 33 2-G15	FD05-88-161 34 2-K15	1-J4	
FA03-69-C72A 3-K9	GA2B-69-927 3-E5	FD01-71-274A 2-F13	FD01-88-1G5 02 2-G15	FD05-88-161A02 2-L15	99359-0815 2-C8	
B001-69-D51 3-J9	FD01-69-929 3-E5	FD01-71-311A 2-F13	FD01-88-1G5 17 2-G15	FD05-88-161A18 2-L15	99359-0815M 2-E8	
KA10-69-D61A 3-J9	FD01-69-960A02 3-D5	FDY1-71-400B 2-F13	FD01-88-1G5 33 2-G15	FD05-88-161A34 2-L15	99359-0819 2-C8	
FD01-69-014 3-J9	FD03-69-970D02 2-D12	FD01-71-440B 2-F13	FD01-88-1H3 02 2-G15	FD01-88-162 2-L15	99541-00603 2-H7	
FD01-69-014B 3-J9	FD03-69-970E02 2-D12	FD01-71-490B 2-F13	FD01-88-1H3 17 2-G15	FD01-88-174 2-F15	99541-01105 1-K3	
N3D8-69-036A 3-K9	EA01-69-973 2-D12	FD01-71-651A 2-E13	FD01-88-1H3 33 2-G15	FD01-88-180A02 2-L15	99541-01201 1-J9	
N3D9-69-036A 3-K9	EA05-69-973 2-D12	*****	FD01-88-1H5 02 2-G15	FD01-88-180C02 2-L15	99541-01252 1-L4	
N3E1-69-036A 3-K9	FD01-69-98X 3-I8	* 75-000 *	FD01-88-1H5 17 2-G15	FD03-88-180A02 2-L15	99541-01401 2-K4	
N3E2-69-036A 3-K9	FD01-69-981A02 3-C5	*****	FD01-88-101 2-G15	FD03-88-180B02 2-L15	99541-01601 1-E6	
N3E3-69-042 3-J9	F114-69-983 3-D5	*****	FD01-88-102 2-G15	FD03-88-180D02 2-L15	1-M9	
N3D8-69-044 3-K9	F114-69-984 3-D5	3625-75-139 2-G14	FD11-88-103 2-G15	FD05-88-180 02 2-L15	99606-63563 1-J7	
FA01-69-064A 3-K9	*****	* 70-000 *	FD01-88-106 2-H15	FD05-88-180 18 2-L15	99611-1750 1-D10	
HG30-69-065 3-K9	* 70-000 *	*****	FD15-88-110 02 2-H15	FD05-88-180 34 2-L15	99636-04130 2-G5	
NA01-69-068A 3-J9	*****	* 76-000 *	FD15-88-110A02 2-H15	FD05-88-180B02 2-M15	99650-28060 2-H5	
FD03-69-074A 3-J9	FD01-70-020B 2-C13	*****	FD18-88-110 02 2-H15	FD05-88-180B18 2-M15	99650-58060 2-H5	
FD04-69-074 3-J9	FD01-70-030D 2-C13	* 76-000 *	FD18-88-110 18 2-H15	FD05-88-180B34 2-M15	99651-94060 2-G5	
FD01-69-123 3-H9	FD01-70-050 2-C13	*****	FD18-88-110 34 2-H15	FD01-88-181 02 2-M15	99655-90005 2-G5	
FD01-69-183 3-H9	FD01-70-1X1 2-D13	0208-76-071 3-E9	FD18-88-110A02 2-H15	FD01-88-181A02 2-M15	99655-90010 2-G5	
BC1C-69-220 3-H9	FD01-70-11Y 2-C13	FD01-76-120 M8 3-G9	FD18-88-110A18 2-H15	FD03-88-181 02 2-M15	99655-90015 2-G5	
BC1C-69-240 3-M4	FD15-70-11Z 2-C13	FD01-76-120 PT 3-G9	FD110-88-110 02 2-H15	FD05-88-181 02 2-M15	99655-90020 2-G5	
FD01-69-240 M8 3-G9	FDY1-70-110A 2-C13	FD01-76-120 PZ 3-G9	F110-88-110A02 2-H15	FD05-88-181 18 2-M15	99655-90025 2-G5	
FD01-69-240 NU 3-G9	FD01-70-119 2-D13	FD01-76-120 3L 3-G9	FD01-88-111 02 2-H15	FD05-88-181 34 2-M15	99655-90030 2-G5	
FD01-69-240 PZ 3-G9	FD01-70-12XA 2-C13	FD01-76-180 M8 3-G9	FD01-88-111A02 2-I15	FD05-88-181A02 2-M15	99655-90035 2-G5	
FD01-69-240 3L 3-G9	FD01-70-120B 2-C13	FD01-76-180 NU 3-G9	FD03-88-111 02 2-H15	FD05-88-181A18 2-M15	99655-90040 2-G5	
FD01-69-242 M8 3-H9	FD01-70-130A 2-D13	FD01-76-180 PT 3-G9	FD01-88-111A02 2-I15	FD05-88-181A34 2-M15	99655-90045 2-G5	
FD01-69-242 NU 3-H9	FD01-70-15XC 2-D13	FD01-76-180 PZ 3-G9	FD03-88-111B02 2-I15	FD01-88-6D0A02 2-M15	99655-90050 2-H5	
FD01-69-242 PT 3-H9	FD01-70-150D 2-C13	FD01-76-180 3L 3-G9	FD05-88-111 02 2-H15	FD01-88-6D0B02 2-N15	99655-90055 2-H5	
FD01-69-242 PZ 3-H9	FDY1-70-200 2-C13	FD01-76-190 2-D10	FD05-88-111 18 2-I15	FD03-88-6D0A02 2-M15	99655-90060 2-H5	
GA5R-69-261 02 3-H9	FD01-70-230A 2-C13	*****	FD05-88-111 34 2-I15	FD03-88-6D0B02 2-N15	99700-5080 2-C12	
GA5R-69-263 02 3-H9	FDY1-70-24X 2-D13	*****	FD05-88-111A02 2-I15	FD05-88-6D0 02 2-M15	99701-3270 2-J11	
FD31-69-270A02 3-H9	*****	*****	*****	FD05-88-6D0 18 2-M15	99701-4278 2-I11	
					99701-6030 2-E14	

* A *

ACTUATOR, A.C.C.----- 3-F6
ACTUATOR, EXHAUST VALVE--- 1-C4
ACTUATOR, MODE-HEATER UNIT 3-D3
ACTUATOR, RECYCLE & FRESH- 3-F3
ACTUATOR, TEMP----- 3-D3
ADAPTER, SUN VISOR----- 3-H9
ADJUSTER NO. 3----- 2-J15
ADJUSTER NO. 4----- 2-J15
ADJUSTER, NO. 1----- 2-G15
ADJUSTER, NO. 2----- 2-G15
ALTERNATOR----- 1-I8
AMP, POWER-FRONT----- 3-H6
ANTENNA, RADIO----- 3-L6
ANTILOCK BRAKE----- 2-M7
ARM NO. 1, LINK----- 3-C8
ARM NO. 2, LINK----- 3-C8
ARM(L), LOWER----- 2-D5
ARM(L), UPPER----- 2-C5
ARM(R), LOWER----- 2-D5
ARM(R), UPPER----- 2-C5
ARM, LOWER-REAR----- 2-D4
ARM, UPPER-REAR----- 2-D4
ARM, WIPER----- 3-E8
ARM, WIPER-CO DRIVER SIDE- 3-N7
ARM, WIPER-DRIVER SIDE--- 3-N7
ARMATURE----- 1-K8
ARMATURE, MAGNETIC CLUTCH- 3-C4
AUDIO SET----- 3-H6

* B *

BACK(C), FRT SEAT----- 2-M15
BACK(L), FRONT SEAT----- 2-M15
BACK(R), FRONT SEAT----- 2-M15
BAFFLE, COWL----- 2-F12
BAFFLE, OIL----- 2-N12
BALL, PILLOW-RR LOWER ARM- 1-G7
BALL, STEEL----- 1-D10
BAND----- 2-G6
BAND(L), TANK FIX----- 2-M6
BAND(R), TANK FIX----- 2-M6
BAND, BATTERY----- 1-C9
BAND, BRAKE----- 1-L10
BAR, STRUT----- 2-K12
BASE(L), MIRROR----- 3-H9
BASE(R), MIRROR----- 3-G9
BASE, INTERIOR MIRROR----- 3-M4
BATTERY----- 1-C9
BEARING----- 2-G3
BEARING & HUB----- 2-K3
BEARING, BALL----- 2-M4
BEARING, BALL-ALT. FRONT-- 1-L7
BEARING, BALL-ALT. REAR-- 1-I8
BEARING, BALL-MAIN DRIVE G 1-J7
BEARING, BALL-MAIN SHAFT-- 1-J7
BEARING, HEAD LAMP----- 2-L10
BEARING, NEEDLE----- 1-E11
BEARING, NEEDLE----- 1-F11
BEARING, NEEDLE----- 1-I3
BEARING, NEEDLE----- 1-I11
BEARING, NEEDLE----- 1-J3
BEARING, NEEDLE----- 1-K7
BEARING, NEEDLE----- 1-L7

BEARING, NEEDLE----- 1-L10
BEARING, PINION----- 1-N7
BEARING, PINION----- 2-J3
BEARING, ROLLER----- 2-K3
BEARING, WHEEL----- 1-J7
BELT, V----- 2-E3
BELT, V----- 1-N6
BELT 'A' (L), FRT SEAT----- 2-D16
BELT 'A' (R), FRT SEAT----- 2-D16
BELT 'B' (L), FRT SEAT----- 2-D16
BELT 'B' (R), FRT SEAT----- 2-D16
BELT 'V'----- 1-G8
BEZEL(L), LAMP----- 1-N6
BEZEL(R), LAMP----- 2-N10
BEZZEL, OPENER LEVER----- 2-N10
BLADE(L), WIPER-FRONT----- 3-C9
BLADE, WIPER----- 3-N7
BLADE, WIPER-FRONT----- 3-E8
BLOCK, FUSE----- 3-N7
BLOCK, MAIN FUSE----- 3-H7
BLOWER UNIT----- 3-C7
BOARD, PARTITION----- 3-F7
BODY & PISTON(L), CALIPER- 3-F3
BODY & PISTON(R), CALIPER- 3-E9
BODY & PISTON(R), CALIPER- 2-G3
BODY & PISTON(R), CALIPER- 2-N4
BODY(L), FRONT DOOR----- 2-G3
BODY(R), FRONT DOOR----- 2-F16
BODY, FILLER CAP----- 2-F16
BODY, LIFT GATE----- 1-K6
BODY, LWR-CONT. VALVE----- 3-J4
BODY, OIL FILTER----- 1-E10
BODY, OIL FILTER----- 1-E6
BODY, THROTTLE----- 1-E5
BODY, UPPER-CONTROL----- 1-H10
BOLT----- 1-D7
BOLT----- 1-D9
BOLT----- 1-D10
BOLT----- 1-E9
BOLT----- 1-E10
BOLT----- 1-F7
BOLT----- 1-G9
BOLT----- 1-H7
BOLT----- 1-H11
BOLT----- 1-J9
BOLT----- 1-K8
BOLT----- 1-K9
BOLT----- 1-K11
BOLT----- 1-L9
BOLT----- 1-N3
BOLT----- 2-C3
BOLT----- 2-C5
BOLT----- 2-C6
BOLT----- 2-C16
BOLT----- 2-D4
BOLT----- 2-D5
BOLT----- 2-E6
BOLT----- 2-E10
BOLT----- 2-F5
BOLT----- 2-F15
BOLT----- 2-H3
BOLT----- 2-H4
BOLT----- 2-J3
BOLT----- 2-K3
BOLT----- 2-L13
BOLT----- 3-F9
BOLT----- 3-N9
BOLT SET----- 1-M7
BOLT SET----- 1-M8
BOLT SET----- 2-G7
BOLT-HEX, HD WASHER----- 2-M4
BOLT, ADJUST----- 3-J5
BOLT, ADJUST----- 1-F8
BOLT, ADJUST----- 1-N6
BOLT, ADJUST----- 2-D5
BOLT, ADJUST----- 2-E4
BOLT, AIR CLEANER----- 1-M4
BOLT, AIR CON----- 3-I3
BOLT, AIR CON----- 3-L3
BOLT, BAFFLE PLATE----- 1-J9
BOLT, BRIDGE-FRT BRAKE--- 2-M4
BOLT, CLAMP----- 1-C9
BOLT, COMPRESSOR----- 3-C4
BOLT, COMPRESSOR----- 3-E4

BOLT, COMPRESSOR-AIR CON.- 3-C4
BOLT, CONNECTOR----- 3-E4
BOLT, CONNECTOR----- 1-E6
BOLT, CONNECTOR----- 1-I6
BOLT, CONNECTOR----- 1-K4
BOLT, CONNECTOR----- 2-G6
BOLT, CONNECTOR----- 2-G7
BOLT, CONNECTOR----- 2-I7
BOLT, CONNECTOR----- 2-L7
BOLT, CONTROL VALVE----- 1-E10
BOLT, CONTROL VALVE----- 1-M9
BOLT, DAMPER-REAR----- 2-M4
BOLT, DUST COVER----- 2-L6
BOLT, FLANGE----- 1-G8
BOLT, FLANGE-ST. KNUCKLE-- 2-F5
BOLT, FUEL DISTRIBUTOR----- 1-C4
BOLT, HUB----- 2-F3
BOLT, HUB----- 2-M4
BOLT, INST. PANEL----- 2-C14
BOLT, INSULATOR----- 3-C6
BOLT, INSULATOR----- 1-E4
BOLT, INSULATOR, FRT HEAT- 2-L13
BOLT, JOINT----- 2-G6
BOLT, LINK----- 2-E15
BOLT, LOCK----- 1-D6
BOLT, LOCK----- 3-D4
BOLT, MAGNET CLUTCH----- 3-F4
BOLT, MOTOR-RETRACT H/LAMP 2-C11
BOLT, MOUNT-MEMBER----- 2-H13
BOLT, MOUNT-MEMBER----- 2-K12
BOLT, OIL PAN----- 1-M9
BOLT, PULLEY----- 1-I3
BOLT, REAR BRAKE----- 2-E3
BOLT, REAR SENSOR----- 2-M7
BOLT, RING GEAR----- 2-K3
BOLT, SET----- 1-D6
BOLT, SET----- 2-C10
BOLT, SET----- 2-F16
BOLT, SETTING----- 2-F16
BOLT, SETTING-HINGE LOWER- 2-F16
BOLT, SHAFT----- 2-H4
BOLT, SPECIAL----- 2-F11
BOLT, STRUT BAR----- 2-M12
BOLT, TENSION----- 1-H3
BOLT, TIE DOWN HOOK-FRONT- 2-L12
BOLT, TURBINE-T. CHARGER--- 1-E4
BOLT, VANE PUMP----- 2-K4
BOLT 'A', LINK----- 2-D4
BONNET----- 2-H12
BOOT----- 2-N7
BOOT SET, INNER JOINT----- 2-D3
BOOT SET, OUTER JOINT----- 2-D3
BOOT, BALL JOINT-UP ARM--- 2-D5
BOOT, CHANGE----- 2-L14
BOOT, DUST-CHANGE LEVER--- 1-E8
BOOT, MOTOR-RETRACT H/L--- 2-C11
BOOT, RACK----- 2-I4
BOSS, STEERING WHEEL----- 2-G4
BOX(L), TORQUE----- 2-L12
BOX(R), TORQUE----- 2-K12
BOX, BATTERY----- 1-C9
BOX, CONTROL-A.B.S.----- 3-C6
BOX, GLOVE----- 2-H14
BOX, RELAY-FRONT HARNESS-- 3-E7
BOX, STORAGE----- 3-N8
BOX, TOOL----- 3-F9
BRACKET----- 1-F10
BRACKET----- 1-G9
BRACKET----- 1-I6
BRACKET----- 1-K7
BRACKET NO 1, A.B.S.----- 2-L7
BRACKET NO 2, A.B.S.----- 2-L7
BRACKET(L), CABLE----- 2-H3
BRACKET(L), FRT SEAT----- 2-F15
BRACKET(L), LAMP----- 2-F13
BRACKET(L), LAMP-F. FOG--- 2-G11
BRACKET(L), LOWER-F. SIDE-- 3-L8
BRACKET(L), QUARTER TRIM-- 3-L9
BRACKET(L), RR. BUMPER----- 2-H10
BRACKET(L), SPOILER----- 3-C10
BRACKET(L), TRIM-QTR PANEL 2-D13
BRACKET(R), CABLE----- 2-H3
BRACKET(R), F. FOG LAMP--- 2-G11
BRACKET(R), FRT SEAT----- 2-F15
BRACKET(R), LAMP----- 2-D13
BRACKET(R), LOWER-F. SIDE-- 3-K8
BRACKET(R), QUARTER TRIM-- 3-L9
BRACKET(R), RR. BUMPER----- 2-H10
BRACKET(R), SPOILER----- 3-C10
BRACKET(R), TRIM-QTR PANEL 2-D13
BRACKET(R), TRUNK SIDE----- 3-L8
BRACKET, A.B.S.----- 3-D6
BRACKET, A.C.C.----- 3-F6
BRACKET, A.C.C. BOX----- 3-C6
BRACKET, ACCEL CABLE----- 1-N3
BRACKET, ACCEL WIRE----- 1-N5
BRACKET, AIR BAG----- 1-N3
BRACKET, AIR BAG----- 2-E16
BRACKET, AIR CLEANER----- 1-M4
BRACKET, AIR CLEANER----- 1-N4
BRACKET, BOOST SENSOR----- 3-I5
BRACKET, CABLE----- 2-G7
BRACKET, CENTER----- 1-M8
BRACKET, CENTER----- 2-G14
BRACKET, CENTER PANEL----- 2-G14
BRACKET, COMPRESSOR----- 1-N6
BRACKET, CONDENSER----- 3-I3
BRACKET, CONDENSER----- 3-L3
BRACKET, CONTROL UNIT----- 3-J5
BRACKET, DIFF. MOUNTING--- 2-F4
BRACKET, DIST. MODULE----- 1-F8
BRACKET, DUCT SPEAKER----- 3-K6
BRACKET, ENGINE HARNESS--- 3-F7
BRACKET, EX. MANIFOLD----- 1-C4
BRACKET, FLOOR----- 2-I13
BRACKET, FRONT----- 1-K8
BRACKET, FRONT COMB. LAMP- 2-E11
BRACKET, HANGER----- 2-E6
BRACKET, HARNESS----- 3-D7
BRACKET, HARNESS----- 3-F7
BRACKET, HEAD LAMP----- 3-G7
BRACKET, HEAD LAMP----- 2-L10
BRACKET, HOLE-ENG. WIRING-- 3-F7
BRACKET, HOSE----- 2-J7
BRACKET, INTER COOLER----- 1-D4
BRACKET, LICENCE LAMP----- 2-N11
BRACKET, MOTOR----- 2-C11
BRACKET, OIL COOLER----- 1-D9
BRACKET, OIL COOLER----- 1-J6
BRACKET, OIL COOLER----- 3-C7
BRACKET, OVERHEAD CONSOLE- 3-I8
BRACKET, PIPE----- 1-G9
BRACKET, REAR----- 1-K8
BRACKET, REAR----- 1-M8
BRACKET, REAR FINISHER--- 3-H6
BRACKET, RELAY----- 2-I11
BRACKET, RELAY----- 3-D6
BRACKET, RR. CONSOLE-NO. 1-- 2-L14
BRACKET, STABILIZER----- 2-F5
BRACKET, STEERING----- 2-G14
BRACKET, STOPPER----- 2-C7
BRACKET, SUN ROOF-FRONT--- 3-E5
BRACKET, TANK----- 3-I3
BRACKET, TRIM----- 2-M16
BRACKET, TUBE----- 1-F10
BRACKET, TUNER----- 3-H6
BRACKET, VACUUM CHAMBER--- 1-H4
BREAKER----- 3-H7
BREATHING----- 1-N9
BREATHING----- 2-J3
BREATHING, AIR-T/MISSION--- 1-D9
BRKT SET, DASH POT-THROT-- 1-H7
BRKT(L), STRUT BAR----- 1-D5
BRKT(R), STRUT BAR----- 2-L12
BRKT, FRT SIDE TRIM----- 2-L12
BRKT, JOINT-SPEAKER DUCT-- 3-K6
BRKT, MOTOR-ANTENNA----- 3-L6
BRUSH----- 1-I8
BRUSH, YOKE----- 1-L8
BULB----- 2-C12
BULB----- 2-C14
BULB----- 2-E11
BULB----- 2-E14

BRACKET(R), CABLE----- 2-H3
BRACKET(R), F. FOG LAMP--- 2-G11
BRACKET(R), FRT SEAT----- 2-F15
BRACKET(R), LAMP----- 2-D13
BRACKET(R), LOWER-F. SIDE-- 3-K8
BRACKET(R), QUARTER TRIM-- 3-L9
BRACKET(R), RR. BUMPER----- 2-H10
BRACKET(R), SPOILER----- 3-C10
BRACKET(R), TRIM-QTR PANEL 2-D13
BRACKET(R), TRUNK SIDE----- 3-L8
BRACKET, A.B.S.----- 3-D6
BRACKET, A.C.C.----- 3-F6
BRACKET, A.C.C. BOX----- 3-C6
BRACKET, ACCEL CABLE----- 1-N3
BRACKET, ACCEL WIRE----- 1-N5
BRACKET, AIR BAG----- 1-N3
BRACKET, AIR BAG----- 2-E16
BRACKET, AIR CLEANER----- 1-M4
BRACKET, AIR CLEANER----- 1-N4
BRACKET, BOOST SENSOR----- 3-I5
BRACKET, CABLE----- 2-G7
BRACKET, CENTER----- 1-M8
BRACKET, CENTER----- 2-G14
BRACKET, CENTER PANEL----- 2-G14
BRACKET, COMPRESSOR----- 1-N6
BRACKET, CONDENSER----- 3-I3
BRACKET, CONDENSER----- 3-L3
BRACKET, CONTROL UNIT----- 3-J5
BRACKET, DIFF. MOUNTING--- 2-F4
BRACKET, DIST. MODULE----- 1-F8
BRACKET, DUCT SPEAKER----- 3-K6
BRACKET, ENGINE HARNESS--- 3-F7
BRACKET, EX. MANIFOLD----- 1-C4
BRACKET, FLOOR----- 2-I13
BRACKET, FRONT----- 1-K8
BRACKET, FRONT COMB. LAMP- 2-E11
BRACKET, HANGER----- 2-E6
BRACKET, HARNESS----- 3-D7
BRACKET, HARNESS----- 3-F7
BRACKET, HEAD LAMP----- 3-G7
BRACKET, HEAD LAMP----- 2-L10
BRACKET, HOLE-ENG. WIRING-- 3-F7
BRACKET, HOSE----- 2-J7
BRACKET, INTER COOLER----- 1-D4
BRACKET, LICENCE LAMP----- 2-N11
BRACKET, MOTOR----- 2-C11
BRACKET, OIL COOLER----- 1-D9
BRACKET, OIL COOLER----- 1-J6
BRACKET, OIL COOLER----- 3-C7
BRACKET, OVERHEAD CONSOLE- 3-I8
BRACKET, PIPE----- 1-G9
BRACKET, REAR----- 1-K8
BRACKET, REAR----- 1-M8
BRACKET, REAR FINISHER--- 3-H6
BRACKET, RELAY----- 2-I11
BRACKET, RELAY----- 3-D6
BRACKET, RR. CONSOLE-NO. 1-- 2-L14
BRACKET, STABILIZER----- 2-F5
BRACKET, STEERING----- 2-G14
BRACKET, STOPPER----- 2-C7
BRACKET, SUN ROOF-FRONT--- 3-E5
BRACKET, TANK----- 3-I3
BRACKET, TRIM----- 2-M16
BRACKET, TUBE----- 1-F10
BRACKET, TUNER----- 3-H6
BRACKET, VACUUM CHAMBER--- 1-H4
BREAKER----- 3-H7
BREATHING----- 1-N9
BREATHING----- 2-J3
BREATHING, AIR-T/MISSION--- 1-D9
BRKT SET, DASH POT-THROT-- 1-H7
BRKT(L), STRUT BAR----- 1-D5
BRKT(R), STRUT BAR----- 2-L12
BRKT, FRT SIDE TRIM----- 2-L12
BRKT, JOINT-SPEAKER DUCT-- 3-K6
BRKT, MOTOR-ANTENNA----- 3-L6
BRUSH----- 1-I8
BRUSH, YOKE----- 1-L8
BULB----- 2-C12
BULB----- 2-C14
BULB----- 2-E11
BULB----- 2-E14

BULB----- 2-F14
BULB----- 2-G14
BULB----- 2-H11
BULB----- 2-I11
BULB----- 2-J11
BULB----- 2-K14
BULB----- 2-L10
BULB----- 2-L11
BULB & SOCKET----- 3-L5
BULB, FRONT FOG LAMP----- 2-K14
BULB, FRONT FOG LAMP----- 2-G11
BULB, INTERIOR MIRROR----- 2-D12
BULB, INTERIOR MIRROR----- 2-H11
BULB, INTERIOR MIRROR----- 2-N11
BULB, MODE CONTROL----- 3-E3
BULB 'B', WARNING UNIT----- 2-E14
BUMPER, BOUND----- 2-C5
BUMPER, REAR----- 2-H10
BUMPER, REAR LOWER----- 2-H10
BUSH----- 1-C7
BUSH----- 1-D8
BUSH----- 1-L11
BUSH----- 1-N6
BUSH SET----- 2-D7
BUSH, CHANGE----- 2-H6
BUSH, DAMPER----- 1-E8
BUSH, DAMPER----- 2-E4
BUSH, ELBOW JOINT----- 2-H6
BUSH, HINGE----- 2-H7
BUSH, HINGE----- 2-G15
BUSH, INNER----- 3-H8
BUSH, OUTER----- 3-F8
BUSH, PILLOW BALL----- 2-D4
BUSH, RUBBER-LWR ARM----- 2-D5
BUSH, SHIFT ROD-DIFF. LOCK 1-H7
BUSH, STABILIZER-RR----- 2-C4
BUSHING, DAMPER-LOWER----- 2-E5
BUSHING, LOWER ARM----- 2-E4
BUSHING, RUBBER----- 2-D5
BUSHING, RUBBER----- 2-E4
BUSHING, RUBBER-FRT----- 2-D5
BUTTON(L), HORN----- 2-G4
BUTTON(R), HORN----- 2-G4
CABLE(L), R.-PARK.----- 2-N7
CABLE(R), R.-PARK.----- 2-N7
CABLE, ACCEL----- 2-J6
CABLE, OPENER----- 2-C7
CABLE, PARKING-FRT----- 2-N7
CALIPER(L), PADLESS-FR----- 2-M4
CALIPER(L), PADLESS-RR----- 2-H3
CALIPER(R), PADLESS-FR----- 2-M4
CALIPER(R), PADLESS-RR----- 2-H3
CAM, CANCEL----- 3-M5
CAM, FIRST IDLE----- 1-D5
CANISTER----- 1-I4
CAP----- 1-J5
CAP----- 2-C7
CAP----- 2-E5
CAP----- 2-F12
CAP----- 2-J13
CAP----- 3-K6
CAP----- 3-K7
CAP SET, RESERVE TANK----- 2-G7
CAP(L), HOLE-TRUNK TRIM--- 3-M8
CAP(R), HOLE-TRUNK TRIM--- 3-M8
CAP, ASSIST-DOOR TRIM----- 2-L16
CAP, BLEEDER SCREW----- 2-G6
CAP, BLIND----- 2-I3
CAP, BLIND----- 1-J5
CAP, BLIND----- 1-N3
CAP, BLIND-OIL PAN----- 1-H3
CAP, CENTER----- 2-G5
CAP, DOOR TRIM----- 2-M16
CAP, FILLER----- 2-L6
CAP, HUB----- 2-M4
CAP, OIL FILLER----- 1-D3
CAP, RADIATOR----- 1-L6

CAP, RUBBER-----	2-N4	CLIP, BELTLINE MOULD-----	2-K10	CORD-----	3-L6	COVER, SERVICE HOLE-----	2-K13	ENGINE, SHORT-----	1-C3
CAP, SEAL-----	3-E8	CLIP, C.S.D. WIKE-----	2-D7	CORD SET, HI. TENSION-----	1-G8	COVER, SOCKET-HEAD LAMP---	2-L10	EVAPORATOR-----	3-G4
CAP, SPRING-----	1-G7	CLIP, COOLING UNIT-----	3-H4	CORD, EARTH-----	3-M6	COVER, SUN VISOR-----	3-I9		3-H4
CAP, SUB TANK-----	1-M6	CLIP, DRAIN HOSE-REAR-----	3-E5	CORD, EARTH-RADIO-----	3-I6	COVER, T/MISSION-----	2-L13	*****	
CAP, TANK-----	3-F8	CLIP, DRAIN HOSE-SUN ROOF--	3-E5	CORD, HIGH TENSION-----	1-G8	COVER, THERMOSTAT-----	1-K6	* *	
	3-M7	CLIP, FENDER GRILLE-----	2-G12	CORD, HIGH TENSION (L-1)---	1-G8	COVER, UNDER-----	1-D9	* *	
CAP, VANE PUMP TANK-----	2-K4	CLIP, FLEXIBLE HOSE-----	2-I6	CORD, HIGH TENSION (L-2)---	1-G8		1-G7	* *	
CARRIER, DIFFERENTIAL-----	2-K3		2-I7	CORD, HIGH TENSION (Y-1)---	1-G8	COVER, UNDER-FRONT-----	2-L13	*****	
CARRIER, FRONT-----	1-E11	CLIP, HARNESS-----	1-E10	CORD, HIGH TENSION (T-2)---	1-G8	COVER, UNDER-MAIN FUSE BLK	3-C7		
CARRIER, REAR-----	1-E11		1-F10	CORD, LAMP-----	2-L11	COVER, UNDER-REAR-----	2-L13		
CARTRIDGE, OIL FILTER-----	1-E6		3-K7	CORD, SHORT-----	2-J14	COVER, UNDER-RELAY BOX----	3-C7		
	1-F6	CLIP, HEATER UNIT-----	3-D3		3-D7	COVER, VENT.-----	1-C7		
CASE(L), BLOWER-----	3-F3	CLIP, HOSE-----	1-I4	CORE, HEATER-----	3-D3	COVER, WHEEL CORE-----	2-G4		
CASE(R), BLOWER-----	3-F3		1-N4	COVER-----	3-C7	COVER, WIPER ARM-FRONT-----	3-N7		
CASE, CHANGE CONTROL-----	1-E8		2-K4	COVER NO.1, ADJ-FRT-----	2-E15	COVER, WIPER ARM-REAR-----	3-F8		
CASE, HEATER-----	3-D3		3-H3	COVER NO.1, SIDE-F. SEAT----	2-G15	COVER 'A', FRAME-SLIDE ROOF	3-G5		
CASE, LAMP-----	2-C14	CLIP, HOSE-SUB T. & WATER H	1-M6	COVER NO.4, SIDE-F. SEAT----	2-G15	COVER 'A', HOLE-----	3-C9		
	2-L14	CLIP, M.OIL TUBE-----	1-I6	COVER SET-----	1-M8	COVER 'B', FRAME-SLIDE ROOF	3-D5		
CASE, METER-----	2-E14	CLIP, MUD GUARD-----	2-L12	COVER(L), BUMPER-----	2-G10	COVER 'B', HOLE-----	3-C9		
CASE, RELAY BOX-----	3-C7	CLIP, OIL TUBE-----	1-I6	COVER(L), DECORATION-----	3-D5	COVER 'C', HOLE-----	3-C9		
CASE, T/MISSION-----	1-F7	CLIP, PARKING CABLE-----	2-N7	COVER(L), DUST-----	2-M4	COVER 'L', HYDRAULIC UNIT---	2-L7		
	1-J9	CLIP, PIPE-----	2-D8	COVER(L), FOG LAMP-----	2-G11	COWLING, RADIATOR-----	1-L6		
CASE, WARNING UNIT-----	2-E14		2-K7	COVER(L), QTR. TRIM-----	3-M9	CUP, SECONDARY-----	2-H7		
CASE 'A', COOLING UNIT-----	3-G4		3-F8	COVER(L), RETRACTOR-----	2-D16	CUSHION(L), FRT SEAT-----	2-K15		
	3-H4		3-H3	COVER(L), RR COMB.-----	2-K11	CUSHION(R), FRT SEAT-----	2-H15		
CASE 'B', COOLING UNIT-----	3-G4		3-K3	COVER(L), SIDE-----	2-I14	CUSHION, RUBBER-----	2-G14		
	3-H4	CLIP, PROTECTOR-----	3-C7	COVER(L), TRUNK SIDE-----	3-M8		2-K15		
CASE 'C', COOLING UNIT-----	3-H4	CLIP, RR BRAKE PIPE-----	2-H12	COVER(R), BUMPER-----	2-E10		3-N8		
CATALYST, THREE WAY-----	2-D6	CLIP, RR WINDOW MOULD-----	2-J10		2-G10	CYL., CLUTCH MASTER-----	2-G6		
CD SOFT-----	3-H6	CLIP, SCUFF PLATE-----	3-K8	COVER(R), DECORATION-----	3-D5	CYL., CLUTCH RELEASE-----	2-G6		
CEILING, TOP-----	3-I8	CLIP, SLIDE-----	3-K4	COVER(R), DUST-----	2-M4	CYL., TANDEM MASTER-----	2-H7		
CHAIN, OIL PUMP-----	1-D6	CLIP, SPOILER-----	3-C10	COVER(R), FOG LAMP-----	2-G11				
CHAMBER, EXTRACTOR-----	2-G12	CLIP, TOP CEILING-----	3-I8	COVER(R), GLOVE-----	2-H14	*****			
CHAMBER, VACUUM-----	1-L5	CLIP, TRIM-----	2-L13	COVER(R), QTR. TRIM-----	3-M9	* *			
CHANGE COMPLETE-----	2-F8		3-I8	COVER(R), RETRACTOR-----	2-D16	* *			
CHANNEL(L), GLASS-----	2-G16		3-J8	COVER(R), RR COMB.-----	2-J11	* *			
CHANNEL(R), GLASS-----	2-G16		3-K4	COVER(R), SIDE-----	2-I14	*****			
CHARGE, AIR COOLER-----	1-D4		3-K8	COVER(R), SIDE NO.2-----	2-J14				
CHECKER, DOOR-----	2-I16		3-M8	COVER(R), TRUNK SIDE-----	3-M8	DAM, AIR-SKIRT-----	3-N9		
CLAMP-----	2-L4	CLIP, WASHER HOSE-----	3-M9	COVER, ACTUATOR-----	3-F6	DAM, FRT. WSHLD GLASS-----	3-M4		
CLAMP, BATTERY-----	1-C9		3-E8	COVER, AIR CLEANER-----	1-N4	DAMPER(L), FRONT-----	2-E5		
CLAMP, HOSE-----	1-F5		3-L7	COVER, BEARING-----	1-F7	DAMPER(R), FRONT-----	2-E5		
	1-G4	CLIP, WIRE-BONNET-----	2-H12	COVER, BLIND-----	1-G7	DAMPER, GLOVE BOX-----	2-H14		
	1-M4	CLIP 'A', BELTLINE MOULD---	2-K10	COVER, BLIND-EXTENSION HOU	1-H7	DAMPER, PULSATION-----	1-L7		
	3-C3	CLUTCH-----	1-C11	COVER, BOX-BATTERY-----	1-C9	DAMPER, REAR-----	2-N3		
CLAMP, SPARE TIRE-----	2-H5	CLUTCH & ONE WAY-----	1-C11	COVER, CASE-----	2-G3	DASH POT-----	1-E5		
CLAMP, WATER HOSE-----	1-K6	CLUTCH, HIGH-----	1-M10	COVER, CENTER ADAPTER-----	3-H9	DIFFERENTIAL-----	2-K3		
CLEANER, AIR-----	1-M4	CLUTCH, MAGNET-----	3-C4	COVER, CLUTCH-----	1-C7	DISC, CLUTCH-----	1-C7		
CLIP-----	1-F7		3-F4	COVER, COLUMN-LOWER-----	2-C14	DISPLAY, SECURITY-ALARM---	2-M14		
	1-G4	CLUTCH, ONE WAY-----	1-F11	COVER, COLUMN-UPPER-----	2-C14	DISTRIBUTOR, FUEL-----	1-K4		
	1-H9	CLUTCH, REAR-----	1-D11	COVER, DAMPER STAY-----	3-J4	DOWEL, TUBULAR-----	1-D3		
	1-I4	CLUTCH, REVERSE-----	1-M10	COVER, DUST-----	1-C7	DRIVING & DIFF.-----	2-J3		
	2-C8	COCK, DRAIN-----	1-L6		1-G3	DRUM, HIGH CLUTCH-----	1-N10		
	2-D3	COIL, FIELD-MAGNET CLUTCH--	3-D4		2-E3	DRUM, REVERSE-----	1-M10		
	2-E10		3-F4		2-H4	DUCT NO.1(R)-----	2-N14		
	2-E16	COIL, IGNITION-LEADING----	1-F8		2-I4	DUCT NO.2(L)-----	2-I14		
	2-F12	COIL, IGNITION-TRAILING----	1-F8		2-L6	DUCT NO.3(R)-----	2-N14		
	2-F15	COLLAR-----	1-D4	COVER, F.FOG LAMP-----	2-H11	DUCT(L), AIR-BRAKE PIPE---	2-I7		
	2-G4	COLLAR, CLUTCH REL.-----	1-C7	COVER, FRONT-----	1-H3	DUCT(L), LAP-----	2-N14		
	2-G11	COLLAR, COMP. BRKT-----	1-N6	COVER, FRONT CLUTCH-----	1-C7	DUCT(L), SHOWER-----	3-C3		
	2-G12	COLLAR, WEDGE-----	1-C7	COVER, FRONT-ALTERNATOR---	1-I8	DUCT(L), SIDE DEMIST.-----	2-N14		
	2-I16	COMPRESSOR-----	3-D4	COVER, FUSE BLOCK-----	3-H7	DUCT(L), VENTILATOR-----	2-N14		
	2-K16		3-F4	COVER, GRILLE-----	2-F10	DUCT(R), AIR-BRAKE PIPE---	2-I7		
	2-M10	COMPRESSOR, AIR CON.-----	3-C4	COVER, HOLE-----	2-J13	DUCT, AIR-----	3-C3		
	2-N7		3-E4		2-K13	DUCT, AIR-INTER COOLER---	1-D4		
	3-C5	CONDENSER-----	1-H8		2-K14	DUCT, CENTER-----	2-N14		
	3-E5		3-I3		3-H6	DUCT, FRESH AIR-----	1-M4		
	3-E8		3-I3		3-L5	DUCT, OIL COOLER-----	1-D9		
	3-G9	CONDITIONER, AIR-----	3-K3	COVER, HOLE-(C)-----	2-I14		1-I6		
	3-H3	CONNECTOR, HOSE-----	1-G4	COVER, HOLE-ANTENNA-----	2-K13	DUCT 'A', REAR SPEAKER-----	3-K6		
	3-I4		1-N3	COVER, HOLE-DOOR BODY-----	2-K16	DUCT 'B', RR SPEAKER-----	3-K6		
	3-J5	CONNECTOR, OIL COOLER-----	1-J6	COVER, HOLE-LIFT GATE-----	2-K16	DUCT 'C', RR SPEAKER-----	3-K6		
	3-K3	CONNECTOR, SHORT-----	3-I6	COVER, HOLE-RR WIPER-----	3-F8				
	3-K4	CONNECTOR, WATER HOSE-----	3-C3	COVER, INJECTOR-----	1-K4	*****			
	3-K7	CONSOLE, OVERHEAD-----	2-D12	COVER, LICENSE LAMP-----	2-N11	* *			
	3-L7	CONSOLE, REAR-----	2-L14	COVER, LOWER PANEL-----	3-D5	* *			
	3-L8	CONTROL UNIT-----	3-I5	COVER, MAIN FUSE BLOCK-----	3-C7	* *			
	3-M6	CONTROL, COOLANT FAN-----	3-C6		3-F7				
CLIP (L)-----	2-I16	CONTROL, HEATER-----	3-E3	COVER, OIL PUMP-----	1-E9	ELEMENT, AIR CLEANER-----	1-N4		
CLIP (R)-----	2-I16	CONVERTER, CATALYST-----	2-D6	COVER, PEEPING HOLE-----	1-C7	END, CONTROL LEVER-----	1-G7		
CLIP KIT, ST. GEAR-----	2-I4	CONVERTER, TORQUE-----	1-D9	COVER, REAR-----	2-K3	END, S/ROD(1ST&2ND)-----	1-D8		
CLIP SET, DRIVE SHAFT-----	2-D3	COOLER, OIL-----	1-F9	COVER, REAR-ALTERNATOR---	1-I8	END, S/ROD(3RD&4TH)-----	1-D8		
CLIP, AIR BAG-----	2-E16		1-I6	COVER, RELAY BOX-F. HARNESS	3-E7	END, SHIFT ROD(0/TOP&REV.)	1-D8		
	2-K7	CORD-----	3-E7	COVER, RR FINISHER-----	2-L11				

*****		GEAR-----	1-L8	GUIDE 'A' (L), GLASS-----	2-G16	HOOK (R), TIE DOWN-FRONT---	2-M12	HUB (R), SUPPORT-----	2-E3
* G *		GEAR SET-----	1-N8	GUIDE 'A' (R), GLASS-----	2-G16	HORN, HIGH TONE-----	3-E6	HUB, CLUTCH-----	1-N7
*****		GEAR SET, DRIVEN-SPEED---	1-G7	GUIDE 'B' (L), GLASS-----	2-G16	HORN, LOW TONE-----	3-E6	HUB, FORWARD CLUTCH-----	1-M10
		GEAR SET, FINAL-----	2-J3	GUIDE 'B' (R), GLASS-----	2-G16	HOSE-----	1-C6	*****	
		GEAR, COUNTER-----	1-M7	GUSSET (L), RR PILLAR-----	2-E13	HOSE NO. 1, BREATHER-----	2-M6	* I *	
		GEAR, COUNTER REVERSE---	1-L7	GUSSET (L), SIDE SILL OUTER	2-F13	HOSE NO. 2, WATER-----	3-C3	*****	
		GEAR, COUNTER SHAFT-----	1-L7	GUSSET (R), SIDE SILL OUTER	2-D13	HOSE NO. 3, WATER-----	3-C3	IGNITER, IG. COIL-TRAILING--	1-G8
		GEAR, DISTRIBUTOR-----	1-I3	*****		HOSE NO. 4, WATER-----	3-C3	INDICATOR-----	2-F8
		GEAR, DRIVE-----	1-H11	* H *		HOSE, AIR-----	1-F5	INDICATOR, ECONOMY-METER--	2-E14
		GEAR, DRIVE-OIL PUMP-----	1-J3	*****		HOSE, BREATHER-----	2-L6	INDICATOR, LEVEL-----	2-G7
		GEAR, DRIVEN-----	1-E6			HOSE, CLUTCH FLEXIBLE-----	2-I6	INJECTION, FUEL-M.P. ELECT.	1-K4
		GEAR, INTERNAL-----	1-E11			HOSE, DRAIN-----	2-C8	INSULATOR-----	1-N4
		GEAR, INTERNAL-STARTER---	1-K8			HOSE, DRAIN-REAR-----	3-E5	INSULATOR (L), COWL SIDE---	3-D9
		GEAR, MAIN DRIVE-----	1-J7			HOSE, DRAIN-SUN ROOF FRONT	3-E5	INSULATOR (L), F. FLOOR-----	3-D9
		GEAR, OVER TOP-----	1-N7			HOSE, EVAPORATION-----	1-I4	INSULATOR (R), COWL SIDE---	3-C9
		GEAR, PARKING-----	1-H11			HOSE, FLEXIBLE-----	2-J7	INSULATOR (R), F. FLOOR-----	3-C9
		GEAR, REVERSE-----	1-L7			HOSE, FLEXIBLE-HIGH-----	3-H3	INSULATOR, BONNET-----	2-I12
		GEAR, REVERSE IDLE-----	1-M7			HOSE, FUEL-----	1-I4	INSULATOR, BOOT-----	2-L14
		GEAR, RING-FLY WHEEL-----	1-J3			HOSE, FUEL MAIN-----	2-C8	INSULATOR, CONVERTER-----	2-D6
		GEAR, SHAFT-----	3-D8			HOSE, FUEL-MAIN PIPE-----	2-C8	INSULATOR, DASHBOARD-----	3-C9
		GEAR, SMALL SUN-----	1-G11			HOSE, JOINT-FILLER PIPE---	2-L6	INSULATOR, EX. MANIFOLD---	1-C4
		GEAR, SPEEDO. DRIVE-----	1-M7			HOSE, OIL-----	1-F9	INSULATOR, FRONT-----	2-L13
		GEAR, STATIONARY-FRT.---	1-E3			HOSE, PRESSURE-----	2-K4	INSULATOR, FUEL DIST.---	1-K4
		GEAR, STATIONARY-RR.---	1-E3			HOSE, RESERVE-----	2-G6	INSULATOR, HEAT-----	2-L13
		GEAR, STEERING-----	2-I4			HOSE, RETURN-----	2-L4	INSULATOR, HEAT-FRONT-----	2-L13
		GEAR, SUN-----	1-E11			HOSE, SIDE-DEMISTER-----	2-N14	INSULATOR, INJECTION-----	1-L4
		GEAR, 1ST-----	1-K7			HOSE, SUB TANK-----	1-M6	INSULATOR, ROD-ANTENNA---	3-K6
		GEAR, 2ND-----	1-K7			HOSE, SUCTION-----	2-L4	INSULATOR, ROOF-----	3-I8
		GEAR, 3RD-----	1-J7			HOSE, VACUUM-----	1-J5	INSULATOR, SUB-----	1-C4
		GENERATOR, SPEED PULSE---	3-K5			HOSE, VENTILATION-----	1-I4	INSULATOR, HEAT-----	2-L13
		GLASS (L), DOOR-FRT-----	2-G16			HOSE, WATER-----	1-J5	INSULATOR, HEAT-FRONT-----	2-L13
		GLASS (L), MIRROR-----	3-H9			HOSE, WATER-T/C WATER-PIPE	1-E4	INSULATOR, INJECTION-----	1-L4
		GLASS (R), DOOR-FRT-----	2-F16			HOSE, WATER-TURBOCHARGER--	1-E4	INSULATOR, ROD-ANTENNA---	3-K6
		GLASS (R), MIRROR-----	3-H9			HOUSING SET, BRG WATER PUM	1-J6	INSULATOR, ROOF-----	3-I8
		GLASS, BACK WINDOW-----	3-M4			HOUSING (L), BACK UP LAMP---	2-K11	INSULATOR, SUB-----	1-C4
		GLASS, FRONT-WARNING UNIT-	2-F14			HOUSING (L), FOG LAMP-----	2-I11	JACK-----	2-H5
		GLASS, WINDSHIELD-----	3-M4			HOUSING (R), BACK UP LAMP---	2-K11	JOINT SET, BALL-----	2-J4
		GRILLE (C), VENTILATOR-----	2-N14			HOUSING (R), FOG LAMP-----	2-I11	JOINT SET, INNER-----	2-D3
		GRILLE (L), DEF. NOZZLE---	2-H14			HOUSING (R), FOG LAMP-----	2-F11	JOINT SET, OUTER-----	2-D3
		GRILLE (L), FENDER-----	2-G12			HOUSING, CLUTCH-----	1-C7	JOINT, BACK WINDOW MOULD--	2-J10
		GRILLE (L), SIDE DEMISTER--	2-L16			HOUSING, CONVERTER-----	1-E9	JOINT, BALL-----	2-J4
		GRILLE (L), SPEAKER-----	2-M16			HOUSING, EXTENSION-----	1-F7	JOINT, DRAIN HOSE-REAR---	3-E5
		GRILLE (R), DEF. NOZZLE---	2-H14			HOUSING, FRONT-----	1-G3	JOINT, FUEL PIPE-----	2-J7
		GRILLE (R), FENDER-----	2-F12			HOUSING, GEAR-----	2-I4	JOINT, HOSE-----	3-F8
		GRILLE (R), SIDE DEMISTER--	2-L16			HOUSING, INTERMEDIATE-----	1-D3	JOINT, PIPE-----	2-G6
		GRILLE (R), SPEAKER-----	2-L16			HOUSING, REAR-----	1-G3	JOINT, RUBBER-----	1-D4
		GRILLE, COWL-----	2-F12			HOUSING, ROTOR-FRONT-----	1-D3	JOINT, STEERING-----	2-H4
		GRILLE, EXTRACT.-T.S. TRIM	3-M8			HOUSING, ROTOR-REAR-----	1-D3	JOINT 'T'-----	2-K6
		GRILLE, SPEAKER-----	2-G14			HOUSING, WAX-----	1-D5	JUNCTION (L), CORNER-Q/PANE	2-E13
		GRIP, FRT ASSIST-----	2-M16			HUB-----	1-F11	JUNCTION (R), CORNER-Q/PANE	2-C13
		GROMMET-----	2-H10			HUB SET, CLUTCH-O.T. & REV	1-N7	*****	
		GRILLE (C), VENTILATOR-----	2-N14			HUB SET, CLUTCH-1ST & 2ND-	1-K7	* K *	
		GRILLE (L), DEF. NOZZLE---	2-H14			HUB SET, CLUTCH-3RD & 4TH-	1-J7	*****	
		GRILLE (L), FENDER-----	2-G12			HUB (L), SUPPORT-----	2-E3	KEY-----	1-D6
		GRILLE (L), SIDE DEMISTER--	2-L16						1-M7
		GRILLE (L), SPEAKER-----	2-M16						2-C10
		GRILLE (R), DEF. NOZZLE---	2-H14						2-C10
		GRILLE (R), FENDER-----	2-F12						2-C10
		GRILLE (R), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (R), SPEAKER-----	2-L16						2-D10
		GRILLE, COWL-----	2-F12						2-D10
		GRILLE, EXTRACT.-T.S. TRIM	3-M8						2-D10
		GRILLE, SPEAKER-----	2-G14						2-D10
		GRIP, FRT ASSIST-----	2-M16						2-D10
		GROMMET-----	2-H10						2-D10
		GRILLE (C), VENTILATOR-----	2-N14						2-D10
		GRILLE (L), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (L), FENDER-----	2-G12						2-D10
		GRILLE (L), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (L), SPEAKER-----	2-M16						2-D10
		GRILLE (R), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (R), FENDER-----	2-F12						2-D10
		GRILLE (R), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (R), SPEAKER-----	2-L16						2-D10
		GRILLE, COWL-----	2-F12						2-D10
		GRILLE, EXTRACT.-T.S. TRIM	3-M8						2-D10
		GRILLE, SPEAKER-----	2-G14						2-D10
		GRIP, FRT ASSIST-----	2-M16						2-D10
		GROMMET-----	2-H10						2-D10
		GRILLE (C), VENTILATOR-----	2-N14						2-D10
		GRILLE (L), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (L), FENDER-----	2-G12						2-D10
		GRILLE (L), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (L), SPEAKER-----	2-M16						2-D10
		GRILLE (R), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (R), FENDER-----	2-F12						2-D10
		GRILLE (R), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (R), SPEAKER-----	2-L16						2-D10
		GRILLE, COWL-----	2-F12						2-D10
		GRILLE, EXTRACT.-T.S. TRIM	3-M8						2-D10
		GRILLE, SPEAKER-----	2-G14						2-D10
		GRIP, FRT ASSIST-----	2-M16						2-D10
		GROMMET-----	2-H10						2-D10
		GRILLE (C), VENTILATOR-----	2-N14						2-D10
		GRILLE (L), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (L), FENDER-----	2-G12						2-D10
		GRILLE (L), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (L), SPEAKER-----	2-M16						2-D10
		GRILLE (R), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (R), FENDER-----	2-F12						2-D10
		GRILLE (R), SIDE DEMISTER--	2-L16						2-D10
		GRILLE (R), SPEAKER-----	2-L16						2-D10
		GRILLE, COWL-----	2-F12						2-D10
		GRILLE, EXTRACT.-T.S. TRIM	3-M8						2-D10
		GRILLE, SPEAKER-----	2-G14						2-D10
		GRIP, FRT ASSIST-----	2-M16						2-D10
		GROMMET-----	2-H10						2-D10
		GRILLE (C), VENTILATOR-----	2-N14						2-D10
		GRILLE (L), DEF. NOZZLE---	2-H14						2-D10
		GRILLE (L), FENDER-----	2-G12						2-D10

ALPHABETICAL INDEX *** ENGLISH ***

KEY, FLY WHEEL-----	1-J3	LENS, REAR FINISHER-----	2-I11	MOULD(L), BELTLINE-----	2-K10	*****	PIECE, 2ND.-APEX SEAL-----	1-L3
KEY, PRIMARY-----	2-C10	LENS, WARNING-----	2-F14	MOULD(L), DRIP-----	2-K10	* * * * *	PILLAR(L), FRT.-7NNR-----	2-F13
KEY, SECONDARY-----	2-C10	LEVER-----	1-K8	MOULD(R), BELTLINE-----	2-K10	* * * * *	PILLAR(L), HINGE-----	2-E13
KEY, SYNCHRONIZER-----	1-K7	LEVER SET, THROTTLE BODY--	1-M8	MOULD(R), DRIP-----	2-K10	* * * * *	PILLAR(R), FRT.-INNER-----	2-D13
KEY, VANE PUMP-----	2-K4	LEVER(L), OPERATING-----	1-D5	MOULD(UP), FRT.WINDOW-----	2-J10	* * * * *	PILLAR(R), HINGE-----	2-C13
KEY, WOODRUFF-PULLEY-----	1-I3	LEVER(R), OPERATING-----	2-H3	MOULD, RR.WINDOW-----	2-J10	* * * * *	PILLAR'C'(L), REAR-INNER--	2-E13
KNOB NO. 1-----	3-E3	LEVER, CHANGE-----	2-H3				PILLAR'C'(R), REAR-INNER--	2-C13
KNOB(L), KNUCKLE-----	2-G15	LEVER, CONTROL-----	1-E8				PIN-----	1-K11
KNOB(R), KNUCKLE-----	2-G15	LEVER, OPENER-----	1-G7	*****				1-L9
KNOB, BASS/TREBLE-----	3-H6	LEVER, PARKING BRAKE-----	2-C7	* * * * *				1-L9
KNOB, CHANGE LEVER-----	1-E8	LEVER, SELECT-----	2-N7	* * * * *				2-D7
	2-F8		1-K11					
KNOB, FAN SWITCH-----	3-E3		2-F8			PAD-----	PIN, CHECKER-----	2-I16
KNOB, TRIPMETER-----	2-F14	LEVER, THROTTLE-----	1-D5	NOZZLE(L), SIDE-DEMISTER--	2-G14	PAD NO.1, GARNISH-UPPER---	PIN, DOWEL-----	1-G3
KNOB, VOLUME-TUNER & DECK-	3-H6	LEVER, WIPER-COMB. SWITCH-	3-M5	NOZZLE(L), WASHER-----	3-M7	PAD SET, RR CALIPER-----	PIN, DRIVEN GEAR-----	1-E6
KNUCKLE(L), RECLINING-----	2-J15	LID(L), ARM REST-TRIM-----	2-M16	NOZZLE(R), SIDE-DEMISTER--	2-G14	PAD SET, FRT CALIPER-----	PIN, GUIDE-----	2-H3
KNUCKLE(L), STEERING-----	2-M4	LID(L), LAMP-----	2-C11	NOZZLE(R), WASHER-----	3-L7	PAD(L), CUSHION-FRT-----	PIN, GUIDE-F.SIDE TRIM---	3-L8
KNUCKLE(R), RECLINING-----	2-G15	LID(L), OUTER-STRAGE BOX--	3-N8	NOZZLE, DEFROSTER-----	2-N14	PAD(R), CUSHION-FRT-----	PIN, INTER LOCK-----	1-D8
KNUCKLE(R), STEERING-----	2-M4	LID(L), TRUNK SIDE-----	3-L8	NOZZLE, WASHER-----	3-F8	PAD(R), TIRE HOUSE-----	PIN, LOCATOR-----	2-N16
		LID(R), LAMP-----	2-N10	NUT-----	1-D5	PAD, CHANGE BOOT-----	PIN, LOCK-----	2-H3
		LID(R), OUTER-STRAGE BOX--	3-N8		1-E10	PAD, CRASH-----	PIN, PAD-FRONT BRAKE-----	2-N4
		LID(R), TRUNK SIDE-----	3-L8		1-F4	PAD, FUEL TANK-----	PIN, SNAP-----	2-D7
		LID, FUEL FILLER-----	2-C7		1-K9			2-F7
		LIGHTER, CIGAR-----	3-L5		2-C3	PAD, PEDAL-----		2-F8
		LINK SET, MODE-----	3-D3		2-C4	PAD, PROTECTOR-HARNES-----		1-D3
		LINK SET, TEMP-----	3-D3		2-C6	PAD, REAR SEAT-----		1-D3
		LINK(L), FRONT STABILIZER--	2-F5		2-D4	PAD, ROOF-----		1-G3
		LINK(R), FRONT STABILIZER--	2-F5		2-D5	PAN, FLOOR-CENTER-----	PIN, TUBULAR-----	1-K8
		LINK, CONNECTING-----	2-H3		2-E4	PAN, FLOOR-FRONT-----	PIPE-----	1-N4
		LINK, CONTROL-----	2-C4		2-E5	PAN, FLOOR-REAR-----	PIPE NO.1, BRAKE-A.B.-----	2-I7
		LINK, CONTROL-STAB-----	2-C4		2-E6	PAN, OIL-----	PIPE NO.1, COOLER-----	3-H3
		LINK, LOWER-FRONT-----	2-E4		2-E16			3-K3
		LINK, RECYCLE & FRESH-----	3-F3		2-F3	PANEL(L), APRON & FRAME---	PIPE NO.2, BRAKE-A.B.-----	2-I7
		LINK, TOE CONTROL-----	2-D4		2-F5	PANEL(L), COWL SIDE-----	PIPE NO.2, COOLER-----	3-H3
		LINK, WIPER-----	3-N7		2-H7	PANEL(L), FENDER-FRT-----		3-K3
		LOCK(L), DOOR-----	2-I16		2-M4	PANEL(L), FENDER-REAR-----	PIPE NO.3, BRAKE-A.B.-----	2-I7
		LOCK(R), DOOR-----	2-I16		3-E8	PANEL(L), FLOOR SIDE-----	PIPE NO.3, COOLER-----	3-H3
		LOCK, BONNET-----	2-H12		3-K3	PANEL(L), OUT.-FRT DOOR---		3-K3
		LOCK, GLOVE LID-----	2-H14		1-I8	PANEL(L), REAR PILLAR-----	PIPE NO.4, BRAKE-A.B.-----	2-L7
		LOCK, LIFT GATE-----	3-J4	NUT SET-----	3-E5	PANEL(L), RECESS-----	PIPE NO.4, COOLER-----	3-H3
		LOUVER(R), VENT. GRILLE----	2-N14	NUT, ADJUST-S/ROOF FRAME--	2-F10	PANEL(L), SHROUD-SIDE-----	PIPE NO.5, COOLER-----	3-H3
				NUT, CLIP-----	2-H10	PANEL(L), SIDE SEAL-----		3-K3
					2-K7	PANEL(L), SIDE-CRASH PAD--	PIPE(L), BRAKE-FRONT-----	2-J7
					2-K12	PANEL(L), SWITCH-----	PIPE(L), BRAKE-REAR-----	2-I7
					3-N9	PANEL(L), WHEEL APRON-----	PIPE(R), BRAKE-FRONT-----	2-I7
					1-J6	PANEL(L), WHEEL HOUSE-----		2-J7
					1-E4	PANEL(R), APRON & FRAME---	PIPE(R), BRAKE-REAR-----	2-I7
					2-J14	PANEL(R), COWL SIDE-----	PIPE, AIR-----	1-F5
					2-C5	PANEL(R), FENDER-FRT-----		1-G4
					2-N3	PANEL(R), FENDER-REAR-----	PIPE, AIR INTAKE-----	1-D4
					2-E7	PANEL(R), FLOOR SIDE-----		1-G4
					2-F7	PANEL(R), OUT.-FRT DOOR---	PIPE, AIR INTAKE-INT.COOLE	1-J5
					3-C9	PANEL(R), REAR PILLAR-----	PIPE, AIR-B.A.C.V. & A.I.H.-	1-J5
					3-F9	PANEL(R), RECESS-----	PIPE, AIR-VALVE ACTUATOR--	1-N5
					3-M6	PANEL(R), SHROUD-SIDE-----	PIPE, BRAKE-----	2-I7
					2-G5	PANEL(R), SIDE SILL-----	PIPE, BRAKE-FRT-----	2-J7
					1-J3	PANEL(R), SIDE-CRASH PAD--	PIPE, BRAKE-REAR-----	2-J7
					2-J3	PANEL(R), WHEEL APRON-----	PIPE, CLUTCH-----	2-I6
					1-N7	PANEL(R), WHEEL HOUSE-----	PIPE, COOLER-HIGH-----	3-K3
					1-M7	PANEL, CENTER-----	PIPE, COOLING UNIT-----	3-G4
					3-K6	PANEL, CONSOLE-----		3-H4
					2-F8		PIPE, DRAIN-ANTENNA-----	3-K6
					2-K14	PANEL, COWL-----	PIPE, EVAPORATION-----	2-C8
					1-K11	PANEL, DASH-LOWER-----	PIPE, EVAPORATOR-----	2-D8
					2-F10	PANEL, DASH-UPPER-----	PIPE, FILLER-----	2-K6
					2-I11	PANEL, LOWER-----	PIPE, FILLER NO.2-----	2-L6
					2-G14	PANEL, PEAR END-----	PIPE, FUEL-MAIN-----	2-C8
					2-H10	PANEL, ROOF-----	PIPE, FUEL-RETURN-----	2-C8
					2-H10	PANEL, SLIDING ROOF-----	PIPE, HEATER-----	3-C3
					2-N10	PANEL, SWITCH-----	PIPE, HEATER UNIT-----	3-D3
					3-N7	PARTS KIT, INN.-BRAKE-----	PIPE, INNER-----	2-K6
						PARTS KIT, INN.-CLUTCH-----	PIPE, JOINT-----	1-M6
						PARTS KIT, INNER-----	PIPE, OIL-----	1-F4
						PARTS SET-----		1-F9
							PIPE, OIL FILLER-----	1-E3
						PARTS SET, ST. WHEEL-----	PIPE, OIL LEVEL GAUGE-----	1-D3
						PASS, OIL-----	PIPE, OIL OUTLET-F.COVER--	1-F4
							PIPE, OIL-OILPUMP-----	1-F7
							PIPE, PRESSURE-----	2-J4
							PIPE, REAR WASHER-UPPER---	3-F8
							PIPE, RELIEF-----	1-M4
							PIPE, RETURN-----	2-J4
								2-K4
								2-K4

ALPHABETICAL INDEX *** ENGLISH ***

PIPE, SCREEN WASHER-----	3-L7	PLATE, SEPARATOR-----	1-D10	PROTECTOR, VACUUM TUBE-----	1-I4	RESISTOR-----	3-I5	RING, STOP-----	1-E5
PIPE, VACUUM-----	1-N5	PLATE, STABILIZER-----	1-F5	PROTECTOR 'A' (L), BELT LINE-----	2-K10	RESISTOR, BLOWER UNIT-----	3-F3	RING, SYNCHRONIZER-----	1-C8
	2-H7	PLATE, STABILIZER-RR-----	2-C4	PROTECTOR 'A' (R), BELT LINE-----	2-K10	RESISTOR, INTERLOCK-----	3-C6		1-K7
PIPE, VINYL-----	3-G8	PLATE, THRUST-----	1-J3	PROTR, MOULD-FRT WINDOW-----	2-J10	REST, FOOT-----	2-D7	RING, THRUST WASHER-----	1-C8
PIPE, WASHER-FRONT WIPER--	3-L7	PLATE, WINDOW-----	2-F14	PULLEY-----	1-I8		2-F7	RING, WIRE-----	1-C7
PIPE, WATER-----	1-E4	PLATE 'E', SIDE-----	1-I10	PULLEY, CRANKSHAFT-----	1-I3	RET, ACCUM-----	1-N9	RIVET-----	2-C11
PIPE, WATER IN -T/C-----	1-E4	PLAYER, COMPACT DISC-----	3-H6	PULLEY, IDLE-----	1-N6	RETAINER-----	1-D11		2-N11
PISTON, ACCUMULATOR-----	1-J10	PLUG-----	1-H3	PULLEY, MAGNET CLUTCH-----	3-D4		1-F9		3-H5
	1-N9		1-H7		3-F4	RETAINER, CHAMBER-EXTRACTO	2-G12	RIVET, BLIND-----	2-E10
PISTON, BAND SERVO-----	1-K9		1-I10	PULLEY, VANE PUMP-----	2-K4	RETAINER, FASCIA-----	2-E10	RIVET, MUD GUARD-----	2-L12
PISTON, CALIPER-FRT-----	2-N4		1-J9	PULLEY, WATER PUMP-----	1-K6	RETAINER, LOCK CYL.-----	2-J16	RIVET, SEAL PLATE-SHROUD--	2-M12
PISTON, CLUTCH-----	1-M10	PLUG SET, SPARK-----	2-K13	PUMP, AIR-----	1-F5	RETAINER, SERVO-----	1-K9	ROD, PARKING-----	1-K11
PISTON, FLOATING-----	2-H7	PLUG, BLIND-----	1-G8	PUMP, FUEL-----	2-K6		1-N9	ROD, PUSH-----	2-D7
PISTON, HIGH CLUTCH-----	1-N10	PLUG, CAP-----	1-G3	PUMP, FUEL-SUP-----	2-K6	RETAINER, SERVO SPRING----	1-J9		2-G6
PISTON, LOW & REVERSE-----	1-H11	PLUG, COMPRESSOR-----	1-D8	PUMP, METERING OIL-----	1-E6	RETAINER, SPRING-----	1-H11	ROD, RETRACTABLE-----	2-N10
PISTON, O.W. VALVE-----	2-G6		3-C4	PUMP, OIL-----	1-D6	RETAINER, SPRING-CLU. ONE W	1-D11	ROD, SELECTOR-REAR-----	2-F8
PISTON, PRIMARY-----	2-H7	PLUG, CORNER SEAL-----	1-L3		1-E9	RETAINER, SPRING-PSSTN STEM	1-L9	ROD, SHIFT (1ST&2ND)-----	1-D8
PISTON, REVERSE-----	1-N10	PLUG, DRAIN-----	1-G3	PUMP, VANE-----	2-K4	RING-----	1-K6	ROD, SHIFT (3RD&4TH)-----	1-D8
PIVOT, ROLLER-----	1-F9		2-F6	PUMP, WASHER-----	3-F8	RING SET-KEY CYLINDER-----	2-C14	ROD, SHIFT-OVER TOP & REVE	1-D8
PLATE-----	1-E11		2-I16	PUMP, WATER-----	3-M7	RING SET, 'O'-----	1-C3	ROTOR-----	1-D6
	1-J3		2-J13		1-J6		1-D3		1-J8
	1-J10		2-F7				1-D5		1-M3
	2-F10		2-K6				1-E6	ROTOR, SENSOR-RR A.B.S.---	2-E3
PLATE NO. 1 (L), SET-F.-----	2-F10		2-K13	*****			1-F3		2-M4
PLATE NO. 1 (R), SET-F.-----	2-F10		2-L12	*					

SCREW, GROMMET-----	2-H10	SHAFT, DRIVE-----	2-D3	SPEEDOMETER-----	2-F14	STOPPER, CONNECTOR-----	1-I6	TERMINAL, BACK WIND. GLASS	3-M4
SCREW, ID. ADJUST-TH. BODY-	3-N9	SHAFT, DRIVE NO. 1-----	3-C8	SPINDLE, ADJUSTER-----	2-H3	STOPPER, FILLER LID-----	2-C7	THERMOSTAT SET-----	1-K6
SCREW, LAMP-----	1-D5	SHAFT, DRIVE NO. 2-----	3-N7	SPINDLE, SELECT-----	1-H7	STOPPER, LOWER ARM-----	2-E4	THERMOSTAT, COOLING UNIT--	3-G4
SCREW, REAR SIDE-----	2-H11	SHAFT, DRIVEN GEAR-----	3-C8	SPINDLE, SELECT LOCK-----	1-G7	STOPPER, RACK-ST. GEAR-----	2-I4	TIRE-----	2-G5
SCREW, RR. COMB.-----	2-J11	SHAFT, ECCENTRIC-----	1-E6	SPOILER(L), SIDE-----	1-H7	STOPPER, WHEEL-----	3-F9	TRAY, ASH-----	2-M14
SCREW, TAPPING-----	2-E11	SHAFT, ENG. ABSORBER-----	2-H4	SPOILER(R), SIDE-----	3-N9	STRAINER-----	2-K4	TRAY, BATTERY-----	1-C9
	2-E16	SHAFT, INPUT-----	1-F9	SPOILER, REAR-----	3-C10	STRAINER, OIL-----	1-D6	TRAY, REAR PACKAGE-----	3-K8
	2-J14	SHAFT, INTERMED.-----	2-H4	SPRING-----	1-D11	STRAP-----	3-K8	TRIM(C), FRT. BACK-----	2-C16
	2-N14	SHAFT, MAIN-----	1-J7		1-E8	STRAP, AIR PUMP-----	1-F5		2-N15
SCREW, TAPPING-DOOR LOCK--	2-I16	SHAFT, MANUAL-----	1-K11		1-E9	STRAP, ALTERNATOR-----	1-G8	TRIM(L), 'A' PILLAR-----	3-J8
SCREW, TAPPING-MUD GUARD--	2-N6	SHAFT, OIL PUMP-----	1-D6		1-E10	STRIPER-----	2-H14	TRIM(L), DOOR-----	2-N16
SCREW, WINDOW REGULATOR--	2-J16	SHAFT, PARKING PAWL-----	1-K11		1-G7		2-J16	TRIM(L), FRONT SIDE-----	3-L8
SEAL & BOOT SET, CAL. -RR--	2-G3	SHAFT, PROPELLER-----	2-C3		1-H3	STRIKER, LOCK-----	3-J4	TRIM(L), LIFT GATE-SIDE---	3-L4
SEAL KIT-----	2-H6	SHAFT, PULLEY-----	1-F8		1-I3	STRUT, BAND-----	1-J9	TRIM(L), QUARTER-----	3-M9
SEAL KIT, CALIPER-FRT-----	2-N4		1-N6		1-L11	STUD-----	1-C4	TRIM(L), SEAT BACK-----	2-M15
SEAL KIT, ST. GEAR-----	2-I4	SHAFT, REV. IDLE GEAR-----	1-M7		2-G3		1-G3	TRIM(L), SEAT CUSHION-----	2-K15
SEAL KIT, VANE PUMP-----	2-K4	SHEET-----	2-J16		2-G6		1-G9		2-L15
SEAL SET, OIL-----	1-M3	SHEET, FRT. DAMPER-----	2-C5		2-I14	STUD, CLUTCH CYL.-----	2-G6	TRIM(L), TRUNK SIDE-----	3-M8
SEAL, 'O' RING-----	1-E11		2-N3	SPRING SET-----	2-L14	STUD, EX. MANIFOLD-----	1-C4	TRIM(R), 'A' PILLAR-----	3-J8
	1-L9	SHEET, RUBBER-----	2-C5	SPRING SET, THROTTLE BODY-	1-N8	STUD, HOUSING-----	1-G3	TRIM(R), DOOR-----	2-N16
SEAL, APEX-----	1-L3		2-N3	SPRING(L), LEVER-----	1-D5	SUN VISOR(L)-----	3-H9	TRIM(R), FRONT SIDE-----	3-L8
SEAL, CORNER-----	1-L3	SHEET, SPRING-----	1-D8	SPRING(R), LEVER-----	2-G3	SUN VISOR(R)-----	3-H9	TRIM(R), LIFT GATE-SIDE---	3-K4
SEAL, DUST-BALL JOINT-----	2-J4		1-D10	SPRING, ACCUMULATOR-----	1-N9	SUPPORT, CLUTCH RELEASE---	2-I6	TRIM(R), QUARTER-----	3-L9
SEAL, FLANGE-----	1-G9	SHEET, TUBE-----	2-I7	SPRING, ADJUST-----	2-M10	SUPPORT, MOUNTING-----	2-G3	TRIM(R), SEAT BACK-----	2-J15
SEAL, LATHE CUT-----	1-L10	SHIM, ADJUST-----	1-J7	SPRING, APEX SEAL-----	1-L3	SUPPORTER, ACTUATOR-----	1-K11	TRIM(R), SEAT CUSHION-----	2-H15
	1-N10		1-L7	SPRING, AUDIO-----	3-H6	SW. PRESSURE-LIQUID TANK-	3-L3		2-I15
SEAL, MANUAL SHAFT LEVER--	1-L9		2-K3	SPRING, BACK UP LAMP-----	2-L11	SWITCH-----	1-L8	TRIM(R), TRUNK SIDE-----	3-M8
SEAL, OIL-----	1-D7	SHIM, ADJUST-COUNTER SHAFT	1-M7	SPRING, BRUSH-----	1-L8		1-N8	TRIM, LIFTGATE-LOWER-----	3-L4
	1-E9	SHIM, LOWER PANEL FRONT---	3-E5		1-N8		2-E14	TRIM, LIFTGATE-UPPER-----	3-L4
	1-F3	SHIM, WATER PIPE BRACKET--	1-K6	SPRING, CANCEL CAM-----	3-M5	SWITCH, AUTOCRUISE-----	2-G4	TRIM, SLIDING ROOF-----	3-D5
	1-F7	SHUTTING(L), SLIDING ROOF-	3-D5	SPRING, CENTER PANEL-----	2-K14	SWITCH, BACK UP LAMP-----	3-H5	TRIM, TRUNK END-----	3-M8
	1-H3	SHUTTING(R), SLIDING ROOF-	3-D5		2-L16	SWITCH, CLUTCH-----	2-D7	TUBE, BACK UP LAMP-----	2-K11
	1-I3	SILENCER, FLOOR-----	3-E9	SPRING, CLOCK-----	3-M5	SWITCH, CLUTCH CUT-----	2-D7	TUBE, CORRUGATE-----	3-L7
	1-L9	SILENCER, MAIN-----	2-E6	SPRING, CLUTCH COLLAR-----	1-C7	SWITCH, COMBINATION-----	3-M5	TUBE, HEAD LAMP-----	2-E11
	2-J3	SKIRT(L), FRONT AIR DAM---	3-N9	SPRING, COIL-FRONT-----	2-C5	SWITCH, DIMMER-----	3-M5		2-L10
	2-K3	SKIRT(R), FRONT AIR DAM---	3-N9	SPRING, COIL-REAR-----	2-N3	SWITCH, DOOR-----	3-E6	TUBE, LAMP-FRONT COMB.---	2-I11
SEAL, OUTER-----	1-N10	SLEEVE-----	2-D5	SPRING, CORNER SEAL-----	1-L3	SWITCH, FAN-HEATER CONTROL	3-E3	TURB. METERING OIL-----	1-E6
SEAL, PISTON-----	1-F11		2-E3	SPRING, FRONT FOG LAMP-----	2-H11	SWITCH, FOG-FRONT-----	2-M14	TUBE, OIL FILTER-UPPER---	1-M9
	1-H11		2-F3	SPRING, FRT. COMB.-----	2-E11	SWITCH, GLOVE TRAY-----	2-H14	TUBE, OIL LEVEL-----	1-M9
	1-K9	SLEEVE, ACCUMULATOR-----	1-D10	SPRING, FRT. - INNER-----	1-M3	SWITCH, HAZARD-----	3-E3	TUBE, VACUUM-----	1-L5
	1-L10	SLEEVE, BEARING-FRONT-----	1-L8	SPRING, FRT. - OUTER-----	1-M3	SWITCH, IGNITION-----	2-C10		1-M5
	1-M10		1-N8	SPRING, O.W. VALVE-----	2-G6	SWITCH, INHIBITOR-----	3-J5	TUBE, VACUUM-TURBO CHARGER	1-E4
SEAL, RING-----	1-F9	SLEEVE, BEARING-REAR-----	1-K8	SPRING, OUTER-APEX SEAL---	1-L3	SWITCH, LIGHT & TURN-----	3-M5	TURBOCHARGER-----	1-E4
SEAL, SHAFT-COMPR.-----	3-C4		1-M8	SPRING, PAWL RETURN-----	1-K11	SWITCH, MAIN-----	3-L5		
	3-E4	SLEEVE, CLUTCH HUB-----	1-C8	SPRING, PISTON RETAINER---	1-E11	SWITCH, OVER DRIVE CONTROL	2-F8		
SEAL, SIDE-----	1-G9	SLEEVE, LOCK UP-----	1-I10		1-H11	SWITCH, PARK & NEUTRAL---	3-H5		
	1-M3	SLEEVE, PLUG REGULATOR---	1-H10	SPRING, PISTON RETURN-----	1-J9	SWITCH, PARKING LAMP-----	2-N7		
SEAL, WATER-PUMP-----	1-J6	SOCKET-----	2-E14		1-K9	SWITCH, POWER WINDOW---	3-N5		
SEAT(L), FRONT-----	2-E15		2-L11	SPRING, REAR-INNER-----	1-N9	SWITCH, RETRACTOR-----	3-L5		
	2-F15	SOCKET, AIR BLEED-----	1-L4	SPRING, REAR-OUTER-----	1-M3	SWITCH, RMT. MIRROR-----	3-L5		
SEAT(R), FRONT-----	2-E15	SOCKET, BACK UP LAMP-----	2-K11	SPRING, RETURN-----	1-M3	SWITCH, RR. DEF.-----	2-M14	UNIT(L), HEAD LAMP-----	2-L10
SELECTOR-----	1-G7	SOCKET, F. COMB. LAMP-----	2-E11	SPRING, RING-----	1-N10	SWITCH, STOP-LAMP-----	2-E7	UNIT(R), HEAD LAMP-----	2-L10
SENSOR(L), AIR BAG-----	2-E16	SOCKET, RR. SIDE TURN LAMP-	2-L11	SPRING, RING-----	1-G9		2-F7	UNIT, A.C. CONTROL-----	3-C6
SENSOR(L), FRT-A.B.S.-----	2-M7	SOCKET, RR. COMB.-----	2-J11	SPRING, SIDE SEAL-----	1-L3	SWITCH, THERMO-----	2-D6	UNIT, CENTRAL PROCESSING--	3-C6
SENSOR(L), RR-A.B.S.-----	2-M7	SOCKET, SIDE TURN-----	2-F11	SPRING, SYNCHRO. KEY-----	1-K7			UNIT, COOLING-----	3-G4
SENSOR(R), AIR BAG-----	2-E16	SOLENOID-----	1-H10	SPRING, SYNCHRO. KEY-----	1-C8				3-H4
SENSOR(R), FRT-A.B.S.-----	2-M7	SPACER-----	1-D9	SPRING, SYNCHRONIZER-----	1-K7			UNIT, DIAGNOSIS-AIR BAG---	3-C6
SENSOR(R), RR-A.B.S.-----	2-M7		1-G4	SPRING, THERMO PELLET-E/S-	1-I3			UNIT, DOOR LOCK & TIMER---	3-D6
SENSOR, AIR BAG-----	2-E16		1-I6	SPRING, TRIM-----	3-J8			UNIT, DRIVE-----	3-C5
SENSOR, AIR BAG-INNER-----	2-E16		1-J3	SPRING, UPPER PLATE-----	3-K8			UNIT, FOG LAMP-----	2-F11
SENSOR, CRANKSHAFT POSI.---	3-I5		1-K11	SPRING, VALVE-----	1-F10			UNIT, HEAT GAUGE-----	3-I5
SENSOR, IN. AIR TEMP-----	3-I5		1-L7		1-G10			UNIT, HYDRAULIC-ABS-----	2-L7
SENSOR, KNOCK-----	3-J5		1-M7		1-H10			UNIT, WIPER-COMB. SWITCH--	3-M5
SENSOR, M.A.P.-----	3-H5		2-C5		2-G3				
SENSOR, OIL LEVEL-----	3-H5		2-E10	SPRING, V, REAR BRAKE-----	2-F5				
SENSOR, OXYGEN-----	3-J5		2-L3	STABILIZER, FRONT-----	2-C4				
SENSOR, REVOLUTION-----	3-J5		2-L7	STABILIZER, RR-----	1-K8				
SENSOR, STEERING PRESSURE-	2-K4		2-M3	STARTER-----	1-M8				
SENSOR, TEMP. -ENG. COOLANT-	1-L4		2-N3		1-I8				
	3-I5	SPACER, ACTUATOR-----	3-F6		3-K4				
SENSOR, THROTTLE POSITION-	1-E5	SPACER, BONNET STAY-----	2-H12		2-H12				
SENSOR, WATER LEVEL-----	1-M6	SPACER, CONTROL CABLE-----	1-L11		2-H12				
SET, TANK-----	2-G7	SPACER, DOWEL-----	1-K11		1-K9				
SHADE, SUN-----	3-E5	SPACER, WINDOW-----	3-M4		2-C5				
SHAFT-----	1-J11	SPEAKER(L), LOUD-DOOR-----	3-L6		2-C6				
	1-K8	SPEAKER(L), REAR-----	3-M6		2-N3				
	1-M8	SPEAKER(R), LOUD-DOOR-----	3-L6		1-K8				
	2-K4	SPEAKER(R), LOUD-RR-----	3-M6		2-N3				
SHAFT, CLUTCH-----	1-L8	SPEAKER, FRONT-----	3-L6	STOPPER SET-----	1-K8	TAPE, PROTECTOR-STOPPER---	3-K4	VALVE, AIR CONTROL-----	1-F5
	1-N8	SPEAKER, REAR-----	3-K6	STOPPER, BUMP-----	2-N3	TAPE, SEAL-SLDG. ROOF FRAME	3-C5	VALVE, CHECK-----	1-F5
SHAFT, CYL. -COMPRESSOR---	3-C4			STOPPER, CALIPER-RR-----	2-H3	TAPE, SOFT-DEF. NOZZLE---	2-N14		1-K5
	3-E4					TERMINAL-----	1-M9		2-D6
						TERMINAL SET-----	1-J8		2-M6
									3-L7

ALPHABETICAL INDEX *** ENGLISH ***

VALVE, CONTROL-----	1-D10	WEATHERSTRIP, S/ROOF-----	3-F5
	1-H4	WEDGE, LIFTGATE-----	3-J4
VALVE, CONVR RELIEF-----	1-H10	WEIGHT, BALANCE-----	1-J3
VALVE, DUTY SOLENOID-----	1-N3	WEIGHT, COUNTER-----	1-J3
VALVE, EXPANSION-----	3-G4	WEIGHT, DISC WHEEL-ALUMI--	2-G5
	3-H4		2-H5
VALVE, EXTRACT CHAMBER----	2-G12	WELT(L), SEAMING-----	2-H16
VALVE, FUEL VAPOR-----	2-M6	WELT(R), SEAMING-----	2-H16
VALVE, IDLE AIR CONTROL---	1-N5	WELT, SEAMING-----	3-C5
VALVE, LOCK UP CONTROL----	1-J10	WHEEL DISK-TEMPORARY-----	2-G5
VALVE, MANUAL-----	1-D10	WHEEL, DISC-ALUMI-----	2-H5
VALVE, MODIFIER-----	1-D10	WHEEL, FLY-----	1-I3
VALVE, NON RETURN-----	2-L6	WHEEL, SPROCKET-----	1-D6
VALVE, ORIFICE CHECK-----	1-D10	WIRE-----	2-H5
VALVE, P.B.-----	2-M7	WIRE, A.C.C.-----	3-F6
VALVE, P.C.V.-----	1-K5	WIRE, EARTH-----	3-G7
VALVE, RELIEF-----	3-C4	WIRE, EARTH-FILLER PIPE---	2-L6
	3-E4	WIRE, EARTH-HYD. UNIT-----	2-M7
VALVE, SHIFT-----	1-G10	WIRE, EARTH-REAR DEFFOGER-	3-D7
	1-H10	WIRE, RELEASE-----	2-H15
VALVE, SOL.-AIR BLEED EXT	1-K5	WIRE, RELEASE-BONNET-----	2-H12
VALVE, SOLENOID-----	1-F5	WIRING, ENGINE-----	3-F7
	1-G5	WIRING, FLOOR-----	3-J7
	1-L5	WRENCH, HUB NUT-----	3-F9
VALVE, SOLENOID-A.C. VALVE	1-F5	WTHSTP ,LIFT GATE-----	3-J4
VALVE, SPOOL-----	1-I10	WTHSTP(L), GLASS-F. DOOR---	2-G16
VALVE, ST. GEAR-----	2-J4	WTHSTP(R), GLASS-F. DOOR--	2-G16
VALVE, 3RD LOCK UP-----	1-I10		
VALVE, 3WAY-----	1-J5		

		* *	
		* Y *	
		* *	

WALL(L), SIDE-----	2-L14	YOKE-----	1-K8
WALL(R), SIDE-----	2-L14		1-M8
WARNING, HEAT-----	2-K14	YOKE SET,SUPPORT-ST. GEAR	2-I4
WASHER-----	1-E10		
	2-F6		
	2-F8		
	2-G15		
	2-I4		
	2-J3		
	2-N10		
	3-D4		
	3-D8		
	3-F4		
WASHER SET-----	1-K8		
	1-M8		
WASHER, HYD. UNIT-----	2-L7		
WASHER, LOCK-PUMP FILTER--	2-K6		
WASHER, PLAIN-----	1-H11		
	1-K9		
	1-M9		
	2-E3		
WASHER, PLAIN-LOWER ARM---	2-M4		
WASHER, PLAIN-REAR BRAKE--	2-E3		
WASHER, SETTING-----	2-F16		
WASHER, SLEEVE-REAR BRAKE-	2-C5		
	2-D4		
	2-E3		
WASHER, SPEAKER-----	3-K6		
WASHER, SPRING-----	2-G3		
WASHER, STOP-----	2-H4		
WASHER, THRUST-----	1-E9		
	1-I11		
	1-J3		
	1-L7		
	1-N7		
WASHER, THRUST LOCK-OVER T	1-N7		
WASHER, THRUST-REVERSE IDL	1-M7		
WASHER, TOOTHED-----	3-D8		
WASHER, TRUST-----	1-L10		
WASHER, WAVE-CHANGE CONT.C	1-E8		
WAX, THERMO-----	1-D5		
WEATHERSTRIP(L), DOOR----	2-H16		
WEATHERSTRIP(L), DOOR-LOW.	2-G16		
WEATHERSTRIP(L), INN.-----	2-L16		
WEATHERSTRIP(R), DOOR----	2-G16		
WEATHERSTRIP(R), DOOR-LOW.	2-G16		
WEATHERSTRIP(R), INN.-----	2-L16		
WEATHERSTRIP, BONNET-REAR-	2-I12		

MODEL IDENTIFICATION

This parts catalog has been compiled to cover the following models.

(1/1)

Model No.	Specifications of vehicles																							VIN (Chassis No.)				
	Basic spec.	Eng. line	Turbo	T/mission	Speed		Body	Roof			Suspension	Diff.	Brake	Airbag	Production period		Model year	U.S.A.		Guam & Saipan								
					4 speed	5 speed		W/O sun roof	Steel sun roof	Glass sun roof					Hard suspension	Limited slip diff.		Antilock brake system	Air bag	From	To	1995	Production for U.S.A.		Grade	Production for Guam & Saipan	Grade	
																											TOURING	R2
(US)	(13)	(TB)	(MT)	(AT)	(4S)	(5S)	(CP)	(W/O SR)	(ST)	(GS)	(NS)	(HS)	(LS)	(AL)	(AB)			(BS)	(R3)	(BS)	(R2)	(TG)						
FD31	US	13	TB	MT		5S	CP	W/O SR			NS		LS	AL	AB	Jul. '94	Jan. '98	→	Yes	BS		Yes	BS		FD333-400001~500000			
FD32	US	13	TB	MT		5S	CP	W/O SR				HS	LS	AL	AB	Jul. '94	Jan. '98	→	Yes		R3	Yes		R2	FD333-400001~500000			
FD33	US	13	TB		AT	4S		CP	W/O SR		NS		LS	AL	AB	Jul. '94	Jan. '98	→	Yes	BS		Yes	BS		FD333-400001~500000			
FD34	US	13	TB	MT		5S	CP			GS	NS		LS	AL	AB	Jul. '94	Jan. '98	→	Yes	BS		Yes		TG	FD333-400001~500000			
FD35	US	13	TB		AT	4S		CP		GS	NS		LS	AL	AB	Jul. '94	Jan. '98	→	No			Yes		TG	FD333-400001~500000			
FD36	US	13	TB	MT		5S	CP		ST		NS		LS	AL	AB	Jul. '94	Jan. '98	→	No			Yes	BS		FD333-400001~500000			

AUFA06

BODY PAINTS AND INTERIOR COLORS

THIS LIST SHOWS COMBINATION OF BODY PAINT AND INTERIOR COLOR. USING THIS LIST YOU WILL BE ABLE TO FIND OUT NECESSARY COLOR CODE OF PART YOU NEED IN THE TEXT.

BODY PAINT		INTERIOR COLOR CODE	
NAME	CODE		
Brilliant black	PZ	F E 5	F E 6
Vintage red	NU	F E 5	F E 6
Silver stone metallic	3L	F E 5	
Montego blue metallic	M8	F E 5	F E 6
Chaste white	PT	F E 5	F E 6

NOTE:
COLORS OF INTERIOR CODES
ARE AS FOLLOWS.

FE5	Black
FE6	Tan

AUFA06

COMPLETE ASSEMBLY PARTS NUMBERS

Engine

Specifications of vehicles		Parts number
T/mission	Suspension	
Manual T/mission	Normal suspension	N3D8 - 02 - 000
	Hard suspension	N3E1 - 02 - 000
Automatic T/mission	※	N3D9 - 02 - 000

T/mission

(1/1)

Specifications of vehicles	Parts number
T/mission	
Manual T/mission	R564 - 03 - 000
Automatic T/mission	BV65 - 19 - 090J

Cabin


Specifications of vehicles		Parts number
Roof	Suspension	
W/O sunroof	Normal suspension	FD31 - 07 - 000
	Hard suspension	FD32 - 07 - 000
Steel sunroof	※	FD36 - 07 - 000
Glass sunroof		FD34 - 07 - 000

The ※ mark in the above chart does not affect on part number selection.
Complete assemblies are available and manufactured in accordance with current production specifications only.

AUFA06

VEHICLE IDENTIFICATION SYSTEM FOR RX-7 SERIES (1995)

VIN (= Vehicle Identification Number) for RX-7series (1995 ~ Year Model) consists of WMI(= World Manufacturer Identifier), VDS(= Vehicle Description Section) and VIS(= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.




* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

** Miscellaneous Identification Code identifies major components such as engine, brake system, cab type, etc.

LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet(engine hood), refer to the illustration shown right.



[Note]

If the VIN(Chassis) reference number in the PCM(Parts Catalog Microfiche) appeared as:

FD333 - 400001

...the vehicle's VIN would be e.g. JM1FD333*S0400001.

ABBREVIATIONS

The following abbreviations are used throughout Mazda Microfiche parts catalog: in the illustration, tex, section number index, alphabetical index.

English(1/3)

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
1ST	First	B.S.V.	Bleed Solenoid Valve	D. GRV	Dark Gray
2ND	Second	BTHR	Breather	DIAPH	Diaphragm
2D.	2-Door	BUMP.	Bumper	DIFF.	Differential
2-SEAT	2-Seater	BURQ.	Burglar	DISC/B	Disc Brake
3D.	3-Door	BY.A.C.V.	Bypass Air Control Valve	DIST	Distributor
3RD	Third			DMPR	Dumper
3-SP	3-Speed	[C]		DOHC	Double Overhead
4D.	4-Door	G. or (G)	Center		Camshaft
4-SP or 4-SPD	4-Speed	CALIF.	California	D.P.	Dual Proportioning
4/5-SP	4-Speed/5-Speed	C/AREA	Cold Area	DRUM/B	Drum Brake
4TH	Fourth	CAN.	Canada	D/TIRE or D.TIRE	Double Tire
5D.	5-Door	CARB.	Carburettor		(=Dual Tire)
5-LINK	5-Link Suspension	CAT	Catalyst	D.T. TOP	Detachable Top
5-SP or 5-SPD	5-Speed	C.DISC	Compact Disc	DUMP.	Dump Truck
10TH-ANNIV.	10th-Anniversary	CE	Conventional Engine	DX	Deluxe
[A]			(=Reciprocating Gasoline Engine)	D. YLW	Dark Yellow
..A	..Ampere			[E]	
A.A.S. or A.A.SUSP	Automatic Adjusting Suspension	C.E.D.	Consolidated Emission Directive	ECE	Economic Commission for Europe
ABS.	Absorber	C.G.R.	Constant Gear Ratio	ECON.	Economy
A.B.S.	Anti lock Brake System	CH	Coach	E.C.P.S. SYS	Electric Control Power Steering System
A.B.S.V.	Air Bleed Solenoid Valve	CHG	Change	EGI	Electric Gasoline Injection
A.C.	Air Conditioner	CHMBR	Chamber		
A.C.G.	Automatic Cruise Controls	CHK	Check	E.G.R.	Exhaust Gas Recirculation
ACCEL.	Accelerator	CLQ.	Cooling	ELECT.	Electric
ACTR	Actuator	CLNR	Cleaner	EM.	Emulsion Controls
A.C.V.	Air Control Valve	C/LTR	Cigarette Lighter	ENEGY or ENGY	Energy
ADJ.	Adjuster or Adjustable or Adjusting	CLU	Clutch	ENG.	Engine
ADJ.SUSP	Adjustable Suspension	..CM	..Centimeter (s)	EQLZR	Equalizer
AIR P.	Air Pipe	C.MEMBER	Crossmember	EQUIP.	Equipment
AIR CON.	Air Conditioner	CNTNR	Container	EX.	Exhaust
ALTN	Alternator	COMB.	Combination	EXC.	Except
ALUMI.	Aluminum	COMP.	Companion	EXC.10TH-ANNIV.	EXC.10th-Anniversary
AMP.	Amplifier	COMPR	Compressor	EXT.	Extension
ANALOG	Analogue	COMPS.	Compass	EXTRACT.	Extractor
ANNIV.	10th Anniversary	CONDNSR	Condenser	[F]	
ANT	Antenna	CONN.	Connector or Connecting Console	F.-	Front-
ARG	Argent	CONS.	Console	..F	..feet (..foot)
A.S. ABSORBER	Adjust Shock Absorber	CONT.	Control	FED.	Federal
ASH	Ashtray	CONV.	Conventional	FINIS	Finisher
ASSY	Assembly	CONVR	Converter	F.I.P.	Fuel Injection Pump
AT	Automatic Transmission	COVR.	Cover	FLEX	Flexible
ATT	Attachment	CPE	Coupe	F.I.MIXER	Fuel Injection Mixer
AUS	Austria	CPT.	Complete Assembly	FIX.	Fixing
AUST.	Australia	CPU	Computer	F/LID	Filler Lid
AUTO	Automatic	C.P.UNIT	Central Processing Unit	F.L.DECK	Fuel Logic Deck
[B]		CRK	Crank	FOLD.	Folding
BAL.	Balance	CRUST	Cruster	FRA	France
BAT	Battery	C/SHIFT	Column Shift	FRT	Front
B.COLOH	Body Color	CTR.	Center	F/SHIFT	Floor Shift
B/DOOR	Back Door	CUSH.	Cushion	FULL CON.	Fully Controlled
BDY	Body	CYL.	Cylinder	[G]	
BELT.	Beltline	D or DR	Door	..G	..Gram(s)
BLK	Black	D-	Diameter	GARN	Garnish
BLU	Blue	DBL CAB	Double Cab	GAS.	Gasoline
BLU/GRY	Bluish Gray		(=Crew Cab)	GASOH	Gasohol
BLU.M	Blue Metallic	D. BLUE	Dark Blue	GEN	General
BLVA	Bolivia	D BRN	Dark Brown	G HATCH	Glass Hatch
BRG	Bearing	DE	Desert Engine	GLD M	Gold Metallic
BRKT	Bracket	DEF	Defroster	GLS	Glass
BRN	Brown	DEFG	Defogger	GOV	Governor
BRT	Britain (=Great Britain)	DES	Design	GRN	Green
		DEMIST	Demister	GRY	Gray

English(2/3)

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
GRY/GRN	Greish Green	L.C.DISPLAY	Liquid Crystal Display	O.T.	Over Top
[H]		L/EGI	Less Electric Gasoline Injection	OUT.	Outer
H	Head	L/EM	Less Emission Controls	[P]	
HARN.	Harness	L.H.D.	Left Hand Drive	..P	..Panel
H.A.C.	High. Altitude Compensator	LH. SIDE	Left Hand Side	(P)	Primary
		LKOUT	Lockout	PARK or PARKG	Parking
H.A.COMPENSATOR	High. Altitude Compensator	L. NOSE	Long Nose	PASS.	Passenger
HB	Hatchback	L/NVGT. CPU	Less Navigation computer	P.B.	Proportioning Brake
H.B. RE	Hatchback Release			P.C.V.	Positive Crankcase Ventilation
HC-AT	Hydro Control Automatic T/Mission	LO.	Low	PHILPPNS	Philippines
		L.S. VALVE	Load Sensing Valve	PLR.	Pillar
H/DUTY	Heavy Duty	L/PARTITION	Less Partition	PMV	Pivot
HEA. or HEAT.	Heater	L.P.G.	L.P. Gas (=Liquefied Petroleum Gas)	PKG.	Package
HL. -	High -	L.S.D. or L.S. DIFF	Less Slip Differential	PNEUMA.	Pneumatic
HL.ALT.	High Altitude	..L.T.	..Liter(s) Tank	PNL.	Panel
H.I.C.	Head Injury Criteria	L/TAIGATE	Less Tailgate	PNT	Point
HIGHT	High-Tension	LVR	Lever	POSIT.	Positive
HL or H.L. or H/LAMP	Head Lamp	LWR	Lower	POW. WINDOW	Power Window
H. KONG	Hong Kong	LRG.	Large	P.P.	Polypropylene (Plastics)
HNGR	Hanger	LX-P	LX with Performance Package	PRACT.	Practical
..HP	..Horsepower(s)			PRESS	Pressure
H.P.R.	High Penetration Resisted	[M]		PROTN	Protection
HSG	Housing	..M	..Meter(s)	PROTH.	Protector
HT, H/T or H/TOP	Handtop	MA. CYL.	Master Cylinder	PORTGL	Portugal
HWI	Hawai	MAINT.	Maintain or Maintenance	P.S.	Power Steering
[I]		MAP	Manifold Absolute Pressure	P.SOUND	Premium Sound
ID.	Inner Diameter	M.A. SUSP	Muki-Adjustable Suspension	PSTN	Piston
IG or IGN.	Ignition			PTC	Positive Temperature Coefficient
IL	Island	M. EAST	Middle East	P.T.O.	Power Take Off
ILLUMI.	Illumination	M/F	Maintenance Free	PU	Pickup
IMMOBI.	Immobilizer	MIR	Mirror	PW or P. WINDOW	Power Window
IN.	Inlet	ML	Mainland	PWRGT LIFTH	Power Gate Lifter
IND.	Indicator	MLD. or MLDG.	Moulding	PWT.	Powertrain
INHIB.	Inhibitor	..MM	..Millimeter(s)	[Q]	
INJ.	Injection	M.P.	Multipoint	QTR.	Quarter
INN	Inner	MPX.	Multiplex	QTY	Quantity
INS.	Insulation	MRN	Maroon	[R]	
INSP.	Inspection	MT. & MTG.	Mounting	R	Final Gear Ratio
INST.	Instrument	MT	Manual Transmission	..R or (R)	..Right
INT.	Interior	[N]		RAD.	Radiator
INT.COOLER	Inter Cooler	N-	Number of Teeth	RE	Rotary Engine
INTER	Intermediate	NARR	Narrow	RECIPRO	Reciprocating Engine
INTMT. or INTERMIT.	Intermittent	N.C.	Normal Close		(=Conventional Engine)
I.R.S. or I.R. SUSP	Independent Rear Suspension	N.O.	Normal Open	REFRIGER	Refrigerator Van
		NO.	Number	REG. or REGU.	Regular
I.S.C.	Idle Speed Control	NON-SP.	Non-Special Equipment	REG. GAS	Regular Gasoline
IVRY	Ivory	NON-TILT	Non-Tilting	REGUL.	Regulator
[K]		NOR.	Normal	REL.	Release
..KG	..Kilogram(s)	NOZ.	Nozzle	REM. CON.	Remote Controlled
..KM	..Kilometer(s)	N.S.W.	New South Wales (Aust.)	RET.	Return
..KW	..Kilowatt(s)	NVGT. CPU	Navigation Computer	RETAIN.	Retaining
[L]		N.Z.	New Zealand	RETRACT	Retractable
L or (L)	Left	[O]		REV.	Reverse
L -	Length -	O	Over	R.H.D.	Right Hand Drive
..L	..Liter(s)	OD.	Outer Diameter	PUEHKO	Puehko
..L.T	..Liter(s) Tank	O.FLTR	Oil Filter	R.H. SIDE	Right Hand Side
L/	Less.. (=Without..)	O.H.	Over Head	REINF.	Reinforcement
L/A A. SUSP	Less Automatic Adjusting Suspension	OHC	Overhead Camshaft	R. or RR.	Rear
		OIL CONSUMP.	Oil Consumption	[S]	
L/A C.	Less Air Conditioner	OP	Optional	..S	..Side
L/BODY	Long Body	ORD. BY	Order By	..)	Secondary
L/BOX	Long Box	O.S.	Overize	SAFE.	Safety
L/CPMT	Luggage Compartment				

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
S. AFRICA	South Africa	TURB.	Turbocharge		
SAUDI	Saudi Arabia	TWN	Twin		
S/BODY	Short Body	☐ U			
S/BOX	Short Box	U.K.	The United Kingdom		
SDN	Sedan	U. LONG	Ultra Long		
S/DUTY	Standard Duty	UND	Under		
SELECT.	Selective Use	UP	Upper		
SEN.	Sensor	URETANE	Urethane Rubber		
SERV.	Service	U.S.	Undersize		
S.FORK	Shift Fork	☐ V			
SG., SGN or SIG.	Signal	..V	..Volt(s)		
SHIFT	Shift	..V.	Valve		
SHRD	Shroud	VAC.	Vacuum		
SHTR	Shutter	V.CHAMBER	Vacuum Chamber		
SILV. M or SILVER M.	Silver Metallic	Vent.	Ventilator or Ventilation		
SING	Singapore	V.G.R.	Variable Gear Ratio		
SILEN	Silencer	VHL	Vinyl		
SLDG	Sliding	☐ V			
SLN	Saison	..W	..Watt(s)		
SML.	Small	W. or WIND	Window		
S. NOSE	Short Nose	W-	Width-		
SOL.	Solenoid	W/L.	Wht., or Use w/Lt		
SP.	Speed	W/O L.S. 'ALVE	W/O Load Sensing Valve		
SPEC.	Specification	W/O OIL CONSUMP.	W/O Oil Consumption		
SPEEDO.	Speedometer	W/O P.T.O.	W/O Power Take-Off		
SPG.	Spring	WARN.	Warning		
SPK.	Speaker (=Loud-speaker)	WAS.	Washer		
SPLR	Spoiler	W/AUTO BELT	With Automatic Shoulder Belt		
ST.	Steering	W/CHASSIS	Windshield Chassis		
STAB.	Stabilizer	WAT	Water		
STD	Standard	WGN	Wagon		
S/TIRE or S. TIRE	Single Tire	WHL	Wheel		
STYL	Styled	WHT	White		
SUB-TRNS	Sub-transmission	WIND.	Window		
SUN SHLD	Sun Shield	WIP.	Wiper		
SURGT	Surge Tank	W/O AUTO BELT	Without Automatic Shoulder Belt		
SUP GAS	Super Gasoline	W/O.	Without		
SUSP	Suspension	WOOF	Woofer		
S.V	Solenoid Valve	W. PUMP	Water Pump		
SW.	Switch	WSHLD or WNDSHLD	Windshield		
S. WASHER	Screen Washer (Windshield Washer)	WSTR or WTHSTR	Weatherstrip		
SWD.	Sweden	W/T	With Tube (Tire)		
SYNC.	Synchronizer	☐ Y			
☐ T		YLW	Yellow		
..T	..Ton(s)	YLW/GRN	Yellowish Green		
T-.	Thickness-	YLW/WHIT	Yellowish White		
TACH. & TACHOM	Tachometer	☐ Z			
T ADJUST	Time Adjusting	Z.TEMP	Zone Tempered		
TACHOZ TACHOM.	Tachometer				
T.BELT	Timing Belt				
T/CEILING	Top Ceiling				
TEMP.	Temperature				
T/F	Transfer				
TH	Throttle				
THAI	Thailand				
THERM.	Thermostat				
THROT.	Throttle				
T/L	Tubeless				
T/MISSION	Transmission				
TRD CLMT	Tonk Climates				
TRK	Truck				
TRQ GLIDE	Torque Glide				
T TOBAGO	Tonded and Tobago				